

# **GLK-Class**

Operator's Manual



#### **Symbols**

Registered trademarks:

- Bluetooth<sup>®</sup> is a registered trademark of Bluetooth SIG Inc.
- DTS is a registered trademark of DTS, Inc.
- Dolby and MLP are registered trademarks of DOLBY Laboratories.
- BabySmart<sup>™</sup>. ESP<sup>®</sup> and PRE-SAFE<sup>®</sup> are registered trademarks of Daimler AG.
- HomeLink<sup>®</sup> is a registered trademark of Prince.
- iPod® and iTunes® are registered trademarks of Apple Inc.
- Logic7<sup>®</sup> is a registered trademark of Harman International Industries.
- Microsoft<sup>®</sup> and Windows media<sup>®</sup> are registered trademarks of Microsoft Corporation.
- SIRIUS is a registered trademark of Sirius XM radio Inc.
- · HD Radio is a registered trademark of iBiquity Digital Corporation.
- Gracenote<sup>®</sup> is a registered trademark of Gracenote, Inc.
- ZAGATSurvey<sup>®</sup> and related brands are registered trademarks of ZagatSurvey, HC.

In this Operator's Manual, you will find the following symbols:

#### **↑** WARNING

Warning notes draw your attention to hazards that endanger your health or life, or the health or life of others.

#### $\Phi$ **Environmental note**

Environmental notes provide you with information on environmentally aware actions or disposal.

Notes on material damage alert you to dangers that could lead to damage to your vehicle.

- 1 Practical tips or further information that could be helpful to you.
- This symbol indicates an instruction that must be followed.
- Several of these symbols in succession indicate an instruction with several steps.
- (▷ page) This symbol tells you where you can find more information about a
- $\triangleright$ This symbol indicates a warning or an instruction that is continued on the next page.
- Display This font indicates a display in the multifunction display/COMAND display.

Parts of the software in the vehicle are protected by copyright © 2005 The FreeType Project http://www.freetype.org. All rights reserved.



#### Welcome to the world of Mercedes-Benz

We urge you to read this Operator's Manual carefully and familiarize yourself with the vehicle before driving. For your own safety and a longer vehicle life, follow the instructions and warning notices in this manual. Ignoring them could result in damage to the vehicle or personal injury to you or others.

Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

The equipment or product designation of your vehicle may vary depending on:

- Model
- Order
- Country specification
- Availability

Mercedes-Benz therefore reserves the right to introduce changes in the following areas:

- design
- equipment
- · technical features

The equipment in your vehicle may therefore differ from that shown in the descriptions and illustrations.

The following are integral components of the vehicle:

- Operator's Manual
- Maintenance Booklet
- Equipment-dependent supplements

Keep printed copies of the documents in the vehicle at all times. If you sell the vehicle, always pass the documents on to the new owner.

The technical documentation team at Daimler AG wishes you safe and pleasant motoring.

Mercedes-Benz USA, LLC

Mercedes-Benz Canada, Inc.

A Daimler Company



Maintenance and care ...... 297

Breakdown assistance ...... 311

Wheels and tires ...... 327

ndex 4	At a glance 29
Introduction 22	Safety 39
	Opening and closing 73
	Seats, steering wheel and mirrors 95
	Lights and windshield wipers 109
	Climate control 125
	Driving and parking 139
	On-board computer and displays 215
	Stowage and features



1, 2, 3		Air bags	
115 V socket	281	Display message	238
12 V socket	201	Front air bag (driver, front	
see Sockets		passenger)	
360° camera		Important safety notes	
Function/notes	102	Knee bag	. 44
•	193	PASSENGER AIR BAG OFF	
4ETS		indicator lamp	. 47
see ETS/4ETS (Electronic		Pelvis air bag	
Traction System)		Safety guidelines	
		Side impact air bag	. 45
A		Window curtain air bag	. 46
ABS (Anti-lock Braking System)		Air-conditioning system	
Display message	232	see Climate control	
Function/notes		Air filter (display message)	246
Important safety notes		AIR FLOW	132
Warning lamp		Air vents	
Activating/deactivating cooling		Glove box	137
with air dehumidification	131	Important safety notes	137
Active Blind Spot Assist		Rear	138
Activating/deactivating (on-		Setting	137
board computer)	225	Setting the center air vents	137
Display message		Setting the side air vents	137
Function/information	202	see Climate control	
Trailer towing	205	Alarm system	
Active Driving Assistance package .	202	see ATA (Anti-Theft Alarm system)	
Active Lane Keeping Assist	202	Anti-lock braking system	
Activating/deactivating (on-		see ABS (Anti-lock Braking System)	
board computer)	225	Anti-theft alarm system	
Display message		see ATA (Anti-Theft Alarm system)	
Function/information		Approach/departure angle	168
Trailer towing 202		Ashtray	
Active light function		Assistance menu (on-board	
Active Parking Assist	110	computer)	224
Canceling	188	ASSYST PLUS	
Detecting parking spaces	185	Displaying a service message	298
Display message	249	Hiding a service message	
Exiting a parking space	187	Notes	
Important safety notes	184	Resetting the service interval	
Parking	186	display	298
Towing a trailer	188	Service message	
	100	Special service requirements	
Adaptive Highbeam Assist	212	ATA (Anti-Theft Alarm system)	_//
Display message		Activating/deactivating	71
Function/notes	114	Function	
Switching on/off (on-board	227	Switching off the alarm	
computer)		owntoning on the dialin	. / 1
Additives (engine oil)	370		



ATTENTION ASSIST		В	
Activating/deactivating		Packup lamp	
Display message		Backup lamp	120
Function/notes	197	Changing bulbs	
Audio menu (on-board		Display message  Bag hook	
computer)	222		2/4
Audio system		Ball coupling	210
see separate operating instructions		Installing	
Authorized Centers		Removing	
see Qualified specialist workshop		Storing	
Authorized Mercedes-Benz Center		BAS BLUS (Broke Assist System)	. 00
see Qualified specialist workshop		BAS PLUS (Brake Assist System	4 5
Authorized workshops		PLUS)	. 00
see Qualified specialist workshop		Battery (SmartKey)	7-
AUTO lights		Checking	
Display message	242	Important safety notes	
see Lights		Replacing	. //
Automatic engine start (ECO start/		Battery (vehicle)	21/
stop function)	145	Charging	
Automatic engine switch-off (ECO		Display message	
start/stop function)	145	Important safety notes	
Automatic headlamp mode	111	Jump starting	318
Automatic transmission		Blinds	
Automatic drive program	152	see Roller sunblind	
Changing gear	151	Blind Spot Assist	005
DIRECT SELECT lever	148	Activating/deactivating	
Display message	254	Display message	
Driving tips	151	Notes/function	198
Emergency running mode	154	Trailer towing	200
Engaging drive position	150	see Active Blind Spot Assist	
Engaging neutral	149	BlueTEC	450
Engaging park position		Adding DEF	
automatically	149	BlueTEC (DEF)	309
Engaging reverse gear	149	Brake Assist	
Engaging the park position	149	see BAS (Brake Assist System)	
Kickdown	151	Brake fluid	
Overview	148	Display message	
Problem (malfunction)	154	Notes	3/(
Program selector button	151	Brake lamps	0.46
Pulling away	143	Display message	240
Shift ranges	152	Brakes	, ,
Starting the engine	143	ABS	
Steering wheel paddle shifters	152	BAS	
Trailer towing	151	BAS PLUS	
Transmission position display	149	Brake fluid (notes)	
Transmission positions	150	Display message	232
Automatic transmission		Driving tips	164
emergency mode	154	Important safety notes	164

Maintenance	165	Cargo compartment floor	
Parking brake 161	, 165	Opening/closing	277
Warning lamp		Stowage well (under)	277
Breakdown		Cargo net	
see Flat tire		•	276
see Towing away/tow-starting			275
Bulbs			273
see Changing bulbs		_	304
000 0110119119 001100		CD player/CD changer (on-board	
С			222
		Center console	
California		Lower section	35
Important notice for retail	0.4	Upper section	34
customers and lessees	. 24	Central locking	
Calling up a malfunction		Automatic locking (on-board	
see Display messages		computer)	228
Car		Locking/unlocking (SmartKey)	
see Vehicle		Changing bulbs	
Care			118
Carpets			118
Car wash			116
Display			118
Exterior lights			117
Gear or selector lever			118
Interior	308		120
Matte finish			118
Notes			119
Paint	305	Child-proof locks	117
Plastic trim	308	Important safety notes	63
Power washer	304	Rear doors	
Rear view camera	307	Children	00
Roof lining	310	In the vehicle	58
Seat belt		Restraint systems	
Seat cover	309	Special seat belt retractor	
Sensors	307	Child seat	01
Steering wheel	308	LATCH-type (ISOFIX) child seat	
Tail pipes	307	anchors	61
Trim pieces	309		
Washing by hand	304	Top Tether  Cigarette lighter	
Wheels	305		200
Windows	306	Cleaning	207
Wiper blades	306	Mirror turn signal	
Wooden trim	309		308
Cargo compartment cover	274	Climate control	100
Cargo compartment		, ,	132
enlargement	272	Automatic climate control (3-	400
-		,	130
		8 ,	132
		Cooling with air dehumidification	1.4.1



Defrosting the windows	135	Coolant (engine)	
Defrosting the windshield	134	Checking the level	302
Dual-zone automatic climate		Display message	243
control	127	Filling capacity	371
Important safety notes	126	Important safety notes	371
Indicator lamp	132	Temperature gauge	216
Maximum cooling	135	Warning lamp	265
Notes on using automatic climate		Cooling	
control 128,	131	see Climate control	
	126	Cornering light function	
Problems with cooling with air		Changing bulbs	118
dehumidification	132	Display message	
Problem with the rear window		Function/notes	114
defroster	136	Crash-responsive emergency	
Rear control panel	130	lighting	116
Refrigerant		Cruise control	110
Refrigerant filling capacity		Cruise control lever	170
Setting the air distribution	133	Deactivating	171
Setting the airflow	134	Display message	251
Setting the air vents	137	Driving system	169
Setting the temperature	133	Function/notes	169
Switching air-recirculation mode	100	Important safety notes	169
on/off	136	Setting a speed	170
Switching on/off	131	Storing and maintaining current	170
Switching residual heat on/off	136	speed	170
Switching the rear window	100	Cup holder	170
defroster on/off	135	Center console	278
Switching the ZONE function on/	100	Important safety notes	
off	13/	Rear compartment	
Coat hooks		Customer Assistance Center (CAC)	
Cockpit	2/0		
Overview	30	Customer Relations Department	. 2/
see Instrument cluster	. 50	D	
Collapsible spare wheel		D	
Inflating	360	Dashboard	
see Emergency spare wheel	300	see Instrument cluster	
COMAND		Dashboard lighting	
		see Instrument cluster lighting	
see separate operating instructions  Combination switch	112	Data	
	112	see Technical data	
Collibrating	205	Daytime running lamps	
Calibrating		Display message	242
Calling up		Switching on/off (on-board	
Setting	<b>2</b> 94	computer)	227
Consumption statistics (on-board	210	Switching on/off (switch)	111
Computer)		Dealerships	
Convenience closing feature		see Qualified specialist workshop	
Convenience opening feature	. ŏ/	Declarations of conformity	. 26
			-



DEF		Doors
Adding	158	Automatic locking (on-board
Display message		computer) 228
Filling capacity	369	Automatic locking (switch) 80
Important safety notes	369	Central locking/unlocking
Delayed switch-off		(SmartKey) 74
Exterior lighting (on-board		Control panel 37
computer)	227	Display message 255
Interior lighting	228	Emergency locking 81
Diagnostics connection	. 26	Emergency unlocking 81
Diesel	368	Important safety notes 79
Digital speedometer	220	Opening (from inside) 79
DIRECT SELECT lever		Drinking and driving 162
see Automatic transmission		Drinks holder
Display (cleaning instructions)	308	see Cup holder
Display messages		Drive program
ASSYST PLUS	298	Automatic 152
Calling up (on-board computer)	231	Display 149
Driving systems		Display (DIRECT SELECT lever) 149
Engine		Driver's door
General notes		see Doors
Hiding (on-board computer)	231	Driving abroad
KEYLESS-GO	256	Mercedes-Benz Service 299
Lights		Symmetrical low beam 110
Safety systems		Driving in mountainous terrain
SmartKey		Approach/departure angle 168
Tires	252	Driving lamps
Vehicle	254	see Daytime running lamps
Distance display (on-board		Driving off-road
computer)	224	see Off-road driving
Distance recorder	219	Driving safety systems
see Trip odometer		ABS (Anti-lock Braking System) 64
Distance warning (warning lamp)	267	BAS (Brake Assist System) 65
DISTRONIC PLUS		BAS PLUS (Brake Assist System
Activation conditions	173	PLUS) 65
Deactivating	177	Electronic brake force distribution 69
Display message	250	ESP® (Electronic Stability
Displays in the multifunction		Program) 66, 67
display	176	ETS/4ETS (Electronic Traction
Driving tips		System)
Function/notes	171	Important safety information 64
Important safety notes	171	Overview 64
Setting the specified minimum		PRE-SAFE® Brake 69
distance	175	Driving systems
Warning lamp	267	360° camera
- :		Active Blind Spot Assist 202



Active Driving Assistance		E	
package	202	EASY-ENTRY feature	
Active Lane Keeping Assist	205		220
Active Parking Assist	184	Activating/deactivating Function/notes	
ATTENTION ASSIST	197	EASY-EXIT feature	102
Blind Spot Assist	198		103
Cruise control	169	Crash-responsive Function/notes	
Display message	247	Switching on/off	
DISTRONIC PLUS	171	EBD (electronic brake force	227
HOLD function	179	distribution)	
Lane Keeping Assist	200	Display message	223
Lane Tracking package	198	Function/notes	
PARKTRONIC	180	ECO display	09
Rear view camera	188	Function/notes	163
Driving tips		On-board computer	
Automatic transmission	151	ECO start/stop function	220
Brakes	164	Automatic engine start	145
Break-in period	140	Automatic engine switch-off	
DISTRONIC PLUS	177	Deactivating/activating	
Downhill gradient	164	General information	
Drinking and driving	162	Important safety notes	
Driving abroad	110	Electronic Stability Program	
Driving in winter	166	see ESP® (Electronic Stability Progr	ram)
Driving on flooded roads	166	Emergency release	aiiij
Driving on sand	168	Driver's door	<b>Q</b> 1
Driving on wet roads	166	Vehicle	
Driving over obstacles	168	Emergency spare wheel	01
Exhaust check	162	General notes	360
Fuel	162	Important safety notes	
General	162	Storage location	
Hydroplaning	166	Stowing	
lcy road surfaces	166	Technical data	
Limited braking efficiency on	1 4 1	Emergency Tensioning Devices	002
salted roads	164 167	Function	58
Off-road driving Snow chains	331	Safety guidelines	
	110	Emergency unlocking	
Symmetrical low beam Tire ruts		Tailgate	85
Towing a trailer		Emissions control	00
Traveling uphill		Service and warranty information	23
Wet road surface		Engine	
DVD audio (on-board computer)		Check Engine warning lamp	264
DVD video (on-board computer)		Display message	
D V D Video (oii-board computer)	220	ECO start/stop function	
		Engine number	
		Irregular running	
		Jump-starting	
		Starting problems	147



Starting the engine with the		Setting	104
SmartKey	143	Storing settings (memory	
Starting with KEYLESS-GO	143	function)	106
Switching off	160	Storing the parking position	105
Tow-starting (vehicle)	323		
Engine, jump starting		F	
see Jump starting (engine)		Filler cap	
Engine electronics		see Fuel filler flap	
Problem (malfunction)	147	First-aid kit	312
Engine oil		Flat tire	312
Adding	301		212
Additives	370	MOExtended run-flat system	
Checking the oil level	300	Preparing the vehicle	312
Checking the oil level using the		see Emergency spare wheel	005
dipstick	301	Floormat	295
Display message	245	Fog lamps	
Filling capacity	370	Switching on/off	111
Notes about oil grades	369	Folding the rear bench seat	
Notes on oil level/consumption	300	forwards/back	272
Viscosity	370	Fording	
ESP® (Electronic Stability	0, 0	On flooded roads	166
Program)		Front fog lamps	
9 ,	67	Display message	241
Deactivating / Activating / AMC	. 07	Switching on/off	111
Deactivating/activating (AMG	4.0	Fuel	
vehicles)		Additives	367
Display message		Consumption statistics	
ETS/4ETS		Displaying the current	
Function/notes	0, 6/	consumption	220
Important safety information		Displaying the range	
Trailer stabilization		Driving tips	162
Warning lamp	261	Fuel gauge	
ETS/4ETS (Electronic Traction		Grade (gasoline)	
System)	. 66	Important safety notes	366
Exhaust check	162	Premium-grade unleaded gasoline .	367
Exhaust tail pipe (cleaning		Problem (malfunction)	157
instructions)	307		
Exterior lighting		Quality (diesel)	368
Setting options	110	Refueling	154
see Lights		Tank content/reserve fuel	366
Exterior mirrors		Fuel filler flap	455
Adjusting	103	Opening/closing	155
Dipping (automatic)	105	Fuel filter (display message)	246
Folding in/out (automatically)	104	Fuel level	
Folding in/out (electrically)	104	Calling up the range (on-board	
Folding in when locking (on-board	104	computer)	220
	230		
computer) Out of position (troubleshooting)			
	100		



Fuel tank		Adjusting (rear)	. 99
Capacity	366	Installing/removing (rear)	100
Problem (malfunction)	157	see NECK-PRO head restraints/	
see Fuel tank		NECK-PRO luxury head restraints	
Fuse allocation chart (vehicle tool		Heating	
kit)	312	see Climate control	
Fuses		High-beam headlamps	
Allocation chart	323	Changing bulbs	118
Before changing		Display message	241
Dashboard fuse box		Switching Adaptive Highbeam	
Fuse box in the cargo		Assist on/off	114
compartment	324	Switching on/off	113
Fuse box in the engine	021	Hill start assist	144
compartment	324	HOLD function	
Important safety notes		Deactivating	180
see Fuses	020	Display message	247
366 i u363		Function/notes	179
C		Hood	1/ 9
G			200
Garage door opener		Closing	300
Clearing the memory	294	Display message	255
Important safety notes		Important safety notes	299
Opening/closing the garage door		Opening	300
Programming (button in the rear-		Hydroplaning	166
3 31			
view mirror)	291		
view mirror)  Gear or selector lever (cleaning	291	I	
Gear or selector lever (cleaning		I	
Gear or selector lever (cleaning guidelines)	308	I Ignition lock see Key positions	
Gear or selector lever (cleaning guidelines)	308 . 22	see Key positions	71
Gear or selector lever (cleaning guidelines)	308 . 22	see Key positions Immobilizer	. 71
Gear or selector lever (cleaning guidelines)	308 . 22 271	see Key positions Immobilizer Indicator lamps	. 71
Gear or selector lever (cleaning guidelines)	308 . 22 271	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps	. 71
Gear or selector lever (cleaning guidelines)	308 . 22 271	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster	
Gear or selector lever (cleaning guidelines)	308 . 22 271	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview	. 31
Gear or selector lever (cleaning guidelines)	308 . 22 271	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings	. 31 22 <i>6</i>
Gear or selector lever (cleaning guidelines)	308 . 22 271	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps	. 31 226 . 32
Gear or selector lever (cleaning guidelines)	308 . 22 271	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting	. 31 226 . 32 227
Gear or selector lever (cleaning guidelines)	308 . 22 271 350	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting	. 31 226 . 32 227 115
Gear or selector lever (cleaning guidelines)	308 . 22 271 350	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting Automatic control	. 31 226 . 32 227
Gear or selector lever (cleaning guidelines)	308 . 22 271 350 113 303	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting Automatic control Delayed switch-off (on-board	. 31 226 . 32 227 115
Gear or selector lever (cleaning guidelines)	308 . 22 271 350 113 303 113	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting Automatic control Delayed switch-off (on-board computer)	. 31 226 . 32 227 115 116
Gear or selector lever (cleaning guidelines)	308 . 22 271 350 113 303 113 372	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting Automatic control Delayed switch-off (on-board computer) Emergency lighting	. 31 226 . 32 227 115 116
Gear or selector lever (cleaning guidelines)	308 . 22 271 350 113 303 113	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting Automatic control Delayed switch-off (on-board computer) Emergency lighting Manual control	. 31 226 . 32 227 115 116
Gear or selector lever (cleaning guidelines) Genuine Glove box GTW (Gross Trailer Weight) (definition)  H  Handbrake see Parking brake Hazard warning lamps Headlamps Adding fluid to cleaning system Cleaning system (function) Cleaning system (notes) Fogging up see Automatic headlamp mode	308 . 22 271 350 113 303 113 372	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting Automatic control Delayed switch-off (on-board computer) Emergency lighting Manual control Overview	. 31 226 . 32 227 115 116 228 116 116
Gear or selector lever (cleaning guidelines) Genuine Glove box GTW (Gross Trailer Weight) (definition)  H  Handbrake see Parking brake Hazard warning lamps Headlamps Adding fluid to cleaning system Cleaning system (function) Cleaning system (notes) Fogging up see Automatic headlamp mode Head restraints	308 . 22 271 350 113 303 113 372 115	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting Automatic control Delayed switch-off (on-board computer) Emergency lighting Manual control Overview Reading lamp	. 31 226 . 32 227 115 116
Gear or selector lever (cleaning guidelines) Genuine Glove box GTW (Gross Trailer Weight) (definition)  H  Handbrake see Parking brake Hazard warning lamps Headlamps Adding fluid to cleaning system Cleaning system (function) Cleaning system (notes) Fogging up see Automatic headlamp mode Head restraints Adjusting	308 . 22 271 350 113 303 113 372 115	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting Automatic control Delayed switch-off (on-board computer) Emergency lighting Manual control Overview	. 31 226 . 32 227 115 116 228 116 116
Gear or selector lever (cleaning guidelines) Genuine Glove box GTW (Gross Trailer Weight) (definition)  H  Handbrake see Parking brake Hazard warning lamps Headlamps Adding fluid to cleaning system Cleaning system (function) Cleaning system (notes) Fogging up see Automatic headlamp mode Head restraints	308 . 22 271 350 113 303 113 372 115	see Key positions Immobilizer Indicator lamps see Warning and indicator lamps Instrument cluster Overview Settings Warning and indicator lamps Instrument cluster lighting Interior lighting Automatic control Delayed switch-off (on-board computer) Emergency lighting Manual control Overview Reading lamp	. 31 226 . 32 227 115 116 228 116 115



J		High-beam headlamps	113
Jack		Light switch	110
Storage location	312	Low-beam headlamps Parking lamps	111 112
Using		Rear fog lamp	112
Jump starting (engine)		Setting the brightness of the	112
		display/switch (on-board	
K			227
KEYLESS-GO		Standing lamps	112
Convenience closing feature	ΩΩ	Switching Adaptive Highbeam	–
Display message			227
Locking		Switching the daytime running	
Start/Stop button		lamps on/off (on-board	
Starting the engine		computer)	227
Unlocking		Switching the daytime running	
Key positions		lamps on/off (switch)	111
KEYLESS-GO	141	Switching the exterior lighting	
SmartKey		delayed switch-off on/off (on-	
Kickdown		1 /	227
Driving tips	151	Switching the surround lighting	
Knee bag	. 44	on/off (on-board computer)	
		Turn signals	112
L		see Changing bulbs	
Lamps		see Interior lighting	
see Warning and indicator lamps		see Lights	212
		Light sensor (display message)	
I ANG KEGNING ASSIST		l anding guidalinas	
Lane Keeping Assist Activating / deactivating	225		270
Activating/deactivating	225 248	Locking	2/0
Activating/deactivating Display message	248	Locking see Central locking	270
Activating/deactivating  Display message  Function/information	248	Locking see Central locking Locking (doors)	
Activating/deactivating  Display message  Function/information  Lane Tracking package	248 200	Locking see Central locking Locking (doors) Automatic	80
Activating/deactivating  Display message  Function/information	248 200 198	Locking see Central locking Locking (doors) Automatic	80
Activating/deactivating	248 200 198	Locking see Central locking Locking (doors) Automatic Emergency locking From inside (central locking	80 81
Activating/deactivating	248 200 198 . 61	Locking see Central locking Locking (doors) Automatic Emergency locking From inside (central locking button)	80 81
Activating/deactivating Display message Function/information  Lane Tracking package  LATCH-type (ISOFIX) child seat anchors  License plate lamp (display	248 200 198 . 61	Locking see Central locking Locking (doors) Automatic	80 81
Activating/deactivating Display message Function/information  Lane Tracking package  LATCH-type (ISOFIX) child seat anchors License plate lamp (display message)	248 200 198 . 61 241	Locking see Central locking Locking (doors) Automatic	80 81
Activating/deactivating Display message Function/information Lane Tracking package LATCH-type (ISOFIX) child seat anchors License plate lamp (display message) Light function, active	248 200 198 . 61 241	Locking see Central locking Locking (doors) Automatic	80 81 80
Activating/deactivating Display message Function/information Lane Tracking package LATCH-type (ISOFIX) child seat anchors License plate lamp (display message) Light function, active Display message Lights Activating/deactivating the	248 200 198 . 61 241 242	Locking see Central locking  Locking (doors) Automatic	80 81 80
Activating/deactivating	248 200 198 . 61 241 242	Locking see Central locking  Locking (doors) Automatic	80 81 80 228
Activating/deactivating Display message Function/information  Lane Tracking package  LATCH-type (ISOFIX) child seat anchors License plate lamp (display message) Light function, active Display message Lights Activating/deactivating the interior lighting delayed switch-off Active light function	248 200 198 . 61 241 242	Locking see Central locking  Locking (doors) Automatic	80 81 80 228
Activating/deactivating Display message	248 200 198 . 61 241 242 228 113 111	Locking see Central locking  Locking (doors) Automatic	80 81 80 228
Activating/deactivating Display message Function/information Lane Tracking package LATCH-type (ISOFIX) child seat anchors License plate lamp (display message) Light function, active Display message Lights Activating/deactivating the interior lighting delayed switch-off Active light function Automatic headlamp mode Cornering light function	248 200 198 . 61 241 242 228 113 111 114	Locking see Central locking Locking (doors) Automatic Emergency locking From inside (central locking button) Locking centrally see Central locking Locking verification signal (on- board computer) Low-beam headlamps Changing bulbs Display message Setting for driving abroad (symmetrical)	80 81 80 228
Activating/deactivating Display message Function/information Lane Tracking package LATCH-type (ISOFIX) child seat anchors License plate lamp (display message) Light function, active Display message Lights Activating/deactivating the interior lighting delayed switch-off Active light function Automatic headlamp mode Cornering light function Display message	248 200 198 . 61 241 242 228 113 111 114 239	Locking see Central locking Locking (doors) Automatic	80 81 80 228 118 239
Activating/deactivating Display message Function/information  Lane Tracking package  LATCH-type (ISOFIX) child seat anchors  License plate lamp (display message)  Light function, active Display message  Lights  Activating/deactivating the interior lighting delayed switch-off Active light function Automatic headlamp mode Cornering light function Display message Driving abroad	248 200 198 . 61 241 242 228 113 111 114 239 110	Locking see Central locking Locking (doors) Automatic	80 81 80 228 118 239 110 111
Activating/deactivating Display message Function/information  Lane Tracking package  LATCH-type (ISOFIX) child seat anchors  License plate lamp (display message)  Light function, active Display message  Lights  Activating/deactivating the interior lighting delayed switch-off Active light function Automatic headlamp mode Cornering light function Display message Driving abroad Fog lamps	248 200 198 . 61 241 242 228 113 111 114 239 110 111	Locking see Central locking Locking (doors) Automatic	80 81 80 228 118 239
Activating/deactivating Display message Function/information  Lane Tracking package  LATCH-type (ISOFIX) child seat anchors  License plate lamp (display message)  Light function, active Display message  Lights  Activating/deactivating the interior lighting delayed switch-off Active light function Automatic headlamp mode Cornering light function Display message  Driving abroad Fog lamps Hazard warning lamps	248 200 198 . 61 241 242 228 113 111 114 239 110 111 113	Locking see Central locking Locking (doors) Automatic	80 81 80 228 118 239 110 111
Activating/deactivating Display message Function/information  Lane Tracking package  LATCH-type (ISOFIX) child seat anchors  License plate lamp (display message)  Light function, active Display message  Lights  Activating/deactivating the interior lighting delayed switch-off Active light function Automatic headlamp mode Cornering light function Display message Driving abroad Fog lamps	248 200 198 . 61 241 242 228 113 111 114 239 110 111 113	Locking see Central locking Locking (doors) Automatic	80 81 80 228 118 239 110 111

М		MOExtended run-flat system	313
M+C times	220	Mounting wheels	
	330	0	356
Maintenance see ASSYST PLUS		Mounting a new wheel	355
		1 0	353
Malfunction message		0	354
see Display messages		5	355
Matte finish (cleaning	205	Securing the vehicle against	
instructions)	303	rolling away	353
mbrace	207	MP3	
Call priority		Operation	222
Display message	234	see separate operating instructions	
Downloading destinations	207	Multifunction display	
(COMAND)  Downloading routes	287	Function/notes	218
Emergency call		Permanent display	227
Geo fencing		Multifunction steering wheel	
Important safety notes		Operating the on-board computer .	217
Locating a stolen vehicle	289	Overview	. 33
MB info call button			_
Remote vehicle locking		N	
Roadside Assistance button		Navigation	
Search & Send		Menu (on-board computer)	221
Self-test		see separate operating instructions	
Speed alert		NECK-PRO head restraints	
System		Operation	52
Triggering the vehicle alarm		Resetting after being triggered	
Vehicle remote malfunction	_ / .	NECK-PRO luxury head restraints	
diagnosis	289	Operation	. 52
Vehicle remote unlocking		Resetting after being triggered	
Mechanical key		Notes on breaking-in a new	
Function/notes	. 76	vehicle	140
Locking vehicle			
Unlocking the driver's door		0	
Memory card (audio)			
Memory function		Occupant Classification System	
Message memory (on-board		(OCS)	E 4
computer)	231	Faults	
Messages		Operation	
see Display messages		System self-test	. 50
Mirrors		Occupant safety	E 0
see Exterior mirrors		Children in the vehicle	
see Rear-view mirror		System overview  OCS	40
see Vanity mirror (in the sun visor)			. 51
Mobile phone		Faults Operation	
Menu (on-board computer)	223	System self-test	
Modifying the programming		Gystem sen-test	50
(SmartKey)	. 75		



Odometer	219	Panorama roof with power tilt/	
see Trip odometer		sliding panel	
Off-road driving		Opening/closing	. 91
Checklist after driving off-road	167	Opening/closing the roller	
Checklist before driving off-road	167	sunblind	. 92
General information	167	Problem (malfunction)	
Important safety notes	167	Resetting	
Traveling uphill	168	Panorama sliding sunroof	. / _
Oil	100	Important safety notes	. 89
see Engine oil		Parking	
On-board computer		Important safety notes	
Assistance menu	221	The state of the s	161
Audio menu		Parking brake Position of exterior mirror, front-	101
Convenience submenu			105
		passenger side	105
Displaying a service message		Rear view camera	188
Display messages		see PARKTRONIC	
Factory settings submenu		Parking aid	404
Important safety notes		Active Parking Assist	184
Instrument cluster submenu	226	see Exterior mirrors	
Lighting submenu		see PARKTRONIC	
Menu overview		Parking brake	
Message memory		Display message	
Navigation menu	221	Notes/function	161
Operation		Parking lamps	
Service menu	226	Changing bulbs	118
Settings menu	226	Switching on/off	112
Standard display	219	PARKTRONIC	
Telephone menu	223	Deactivating/activating	182
Trip menu	219	Driving system	180
Vehicle submenu	228	Function/notes	180
Video DVD operation	223	Important safety notes	180
Opening and closing the side trim		Problem (malfunction)	184
panels	119	Range of the sensors	181
Operating system		Trailer towing	183
see On-board computer		Warning display	182
Outside temperature display	217	PASSENGER AIRBAG OFF	
Overhead control panel		Problems (malfunction)	238
Override feature		PASSENGER AIR BAG OFF indicator	
Rear side windows	63	lamp	47
Real side Wildows	. 00	Plastic trim (cleaning instructions) .	
P		Power washers	
		Power windows	504
Paint code number	364	see Side windows	
Paintwork (cleaning instructions)	305		
Panic alarm		PRE-SAFE® (anticipatory occupant	
		protection)	
		Display message	
		Operation	. 52



PRE-SAFE® Brake	Important safety notes 154
Activating/deactivating 225	Refueling process 155
Display message 235	see Fuel
Function/notes 69	Remote control
Warning lamp 267	Garage door opener 291
Program selector button 151	Programming (garage door
Protection of the environment	opener) 291
General notes 22	Reporting safety defects 27
Pulling away	Reserve (fuel tank)
Automatic transmission 143	see Fuel
	Reserve fuel
Q	Display message 245
Qualified encoiclist workshop 27	Warning lamp 264
Qualified specialist workshop 27	see Fuel
R	Residual heat (climate control) 136
ĸ	Restraint system
Radar sensor system	see SRS (Supplemental Restraint
Activating/deactivating 229	System)
Display message 247	Reversing feature
Radio	Panorama sliding sunroof 90
Selecting a station 222	Roller sunblinds 91
see separate operating instructions	Side windows 86
<b>Reading lamp</b> 115	Roadside Assistance (breakdown) 24
Rear compartment	Roller blind
Setting the airflow	see Roller sunblind
Setting the air vents 138	Roller sunblind
Rear fog lamp	Opening/closing
Display message 241	Panorama roof with power tilt/
Switching on/off 112	sliding panel 91
Rear view camera	Roof carrier
Cleaning instructions	Roof lining and carpets (cleaning guidelines) 310
Function/notes	9 ,
Switching on/off	Roof load (maximum) 373 Route (navigation)
Rear-view mirror	
Anti-glare (manual)	see Route guidance (navigation)  Route guidance (navigation)
Dipping (automatic)	Noute guidance (navigation) 221
Rear window defroster	6
Problem (malfunction)	S
Switching on/off	Safety
Rear window wiper	Children in the vehicle 58
Replacing the wiper blade	Child restraint systems 58
Refrigerant (air-conditioning	Occupant Classification System
system)	(OCS) 47
Important safety notes	Overview of occupant safety
Refueling	systems 40
Fuel gauge 31	Safety system
i uci gauge 3 I	see Driving safety systems



Seat belts	Settings
Adjusting the driver's and front-	Factory (on-board computer) 230
passenger seat belt 56	On-board computer 226
Adjusting the height 56	Setting the air distribution 133
Belt force limiters 58	Setting the airflow 134
center rear-compartment seat 57	Side impact air bag 45
Cleaning 309	Side marker lamp (display
Correct usage 55	message) 241
Emergency Tensioning Devices 58	Side windows
Fastening 56	Cleaning 306
Important safety guidelines 54	Convenience closing feature 88
Releasing 57	Convenience opening feature 87
Safety guidelines 41	Important safety information 86
Switching belt adjustment on/off	Opening/closing 87
(on-board computer) 229	Problem (malfunction) 89
Warning lamp 257	Resetting 89
Warning lamp (function) 57	Sliding sunroof
see Seat belts	see Panorama roof with power
Seats	tilt/sliding panel
Adjusting (electrically) 98	SmartKey
Adjusting lumbar support 100	Changing the battery 77
Adjusting the 4-way lumbar	Changing the programming
support 101	Checking the battery 77
Adjusting the head restraint 99	Convenience closing feature 88
Cleaning the cover 309	Convenience opening feature 87
Correct driver's seat position 96	Display message 256
Folding the backrest (rear	Door central locking/unlocking 74
compartment) forwards/back 272	Important safety notes 74
Folding the rear bench seat	Loss 78
forwards/back 272	Mechanical key 76
Important safety notes 97	Positions (ignition lock) 141
Seat heating problem 101	Problem (malfunction) 78
Storing settings (memory	Starting the engine
function) 106	Snow chains
Switching seat heating on/off 101	Sockets
Sensors (cleaning instructions) 307	Center console 280
Service menu (on-board computer) . 226	General notes 280
Service products	Luggage compartment 281
Brake fluid 370	Rear compartment 281
Coolant (engine) 371	Spare wheel
DEF special additives	Storage location 360
Engine oil 369	Stowing 361
Fuel 365	Specialist workshop 27
Important safety notes 365	Special seat belt retractor 61
Refrigerant (air-conditioning	Speed, controlling
system) 372	see Cruise control
Washer fluid 372	



Speedometer	Summer opening
Digital 220	see Convenience opening feature
In the Instrument cluster 31	Summer tires 330
Segments 217	Sun visor 278
Selecting the unit of	Surround lighting (on-board
measurement 226	
see Instrument cluster	SUV
SPORT handling mode	(Sport Utility Vehicle) 25
Activating/deactivating (AMG	Switching air-recirculation mode
vehicles)	_
SRS	Switching off the alarm (ATA) 71
see SRS (Supplemental Restraint	
System)	T
SRS (Supplemental Restraint	•
System)	Tachometer 216
Display message	Tailgate
Introduction 41	Display message 254
Warning lamp 263	Emergency unlocking 85
Warning lamp (function)	Important safety notes 82
Standing lamps	Limiting the opening angle 85
Changing bulbs 118	Opening/closing (automatically
Display message	from inside) 84
Switching on/off 112	Opening/closing (automatically
Start/stop function	from outside) 83
	Opening/closing (from outside) 82
see ECO start/stop function	Opening dimensions 373
Starting (engine)	Tail lamne
Steering (display message)	Display message 240
Steering wheel	Tank content
Adjusting (electrically)	Fuel gauge 31
Adjusting (manually) 102	Technical data
Button overview	( anacities 365
Buttons (on-board computer) 217	Emergency spare wheel 362
Cleaning	Information 364
Important safety notes	Tires /whools 357
Paddle shifters	Trailer loads 374
Storing settings (memory	Vehicle data
function)	TELEAID
Steering wheel paddle shifters 152	Call priority
Stowage areas	Downloading destinations
Stowage compartments	(COMAND) 287
Armrest (under) 271	Downloading routes 200
Cup holders 278	Emergency call
Glove box	Geo fencing
Important safety information 271	Important eafaty notes 293
Rear 272	Locating a stolen vehicle 200
Stowage net 272	MR info call button 206
<b>Stowage net</b>	Remote vehicle locking 288



Roadside Assistance button	286	Bar (definition)	349
Search & Send	288	Changing a wheel	352
Self-test	284	Characteristics	349
Speed alert	290	Checking	329
System	284	Definition of terms	349
Triggering the vehicle alarm	291	Direction of rotation	352
Vehicle remote malfunction		Display message	252
diagnosis	289	Distribution of the vehicle	
Vehicle remote unlocking	288	occupants (definition)	352
Telephone		DOT, Tire Identification Number	
Accepting a call	223	(TIN)	348
Display message	255	DOT (Department of	
Menu (on-board computer)	223	Transportation) (definition)	349
Number from the phone book	224	GAWR (Gross Axle Weight Rating)	
Redialing	224	(definition)	350
Rejecting/ending a call	223	GTW (Gross Trailer Weight)	
Temperature		(definition)	350
Coolant	216	GVW (Gross Vehicle Weight)	
Outside temperature	217	(definition)	350
Setting (climate control)	133	GVWR (Gross Vehicle Weight	
Theft deterrent systems		Rating) (definition)	350
ATA (Anti-Theft Alarm system)	. 71	Important safety notes	328
Immobilizer	. 71	Increased vehicle weight due to	
Time		optional equipment (definition)	349
see separate operating instructions		Kilopascal (kPa) (definition)	350
Tire pressure		Labeling (overview)	345
Calling up (on-board computer)	336	Load bearing index (definition)	351
Checking manually	335	Load index	348
Display message	252	Load index (definition)	350
Maximum		M+S tires	330
Notes	333	Maximum loaded vehicle weight	
Pressure loss warning	335	(definition)	350
Recommended	331	Maximum load on a tire	
see Tire pressure		(definition)	351
Tire pressure loss warning system		Maximum permissible tire	
Important safety notes	335	pressure (definition)	350
Restarting	336	Maximum tire load	343
Tire pressure monitoring system		Maximum tire load (definition)	350
Checking the tire pressure		MOExtended tires	313
electronically		Optional equipment weight	
Function/notes	336	(definition)	351
Restarting	338	PSI (pounds per square inch)	
Warning lamp	268	(definition)	
Warning message	338	Replacing	352
Tires		Service life	330
Aspect ratio (definition)	351	Sidewall (definition)	
Average weight of the vehicle		Speed rating (definition)	350
occupants (definition)	349	Storing	352



Structure and characteristics		Storing the ball coupling	213
(definition)	349	Trailer loads	374
Summer tires		Towing away	
Temperature	345	With both axles on the ground	322
TIN (Tire Identification Number)		Tow-starting	
(definition)	351	Emergency engine starting	323
Tire bead (definition)	351	Important safety notes	320
Tire pressure (definition)	351	Trailer coupling	
Tire pressures (recommended)	349	see Towing a trailer	
Tire size (data)		Trailer loads and drawbar	
Tire size designation, load-bearing		noseweights	212
capacity, speed rating	346	Trailer towing	
Tire tread		Active Blind Spot Assist	205
Tire tread (definition)		Active Lane Keeping Assist 202,	
Total load limit (definition)		Blind Spot Assist	
Traction		PARKTRONIC	183
Traction (definition)		Permissible trailer loads and	
Tread wear		drawbar noseweights	212
TWR (permissible trailer drawbar		Transfer case	154
noseweight) (definition)	351	Transmission	
Uniform Tire Quality Grading		see Automatic transmission	
Standards	344	Transmission position display	149
Uniform Tire Quality Grading		Transmission position display	
Standards (definition)	349	(DIRECT SELECT lever)	149
Unladen weight (definition)	350	Transporting the vehicle	322
Wear indicator (definition)		Traveling uphill	
Wheel rim (definition)		Brow of hill	169
see Flat tire		Driving downhill	169
Top Tether	. 62	Maximum gradient-climbing	,
Towing		capability	169
Important safety guidelines	320	Trim pieces (cleaning instructions) .	309
Installing the towing eye		Trip computer (on-board	
Removing the towing eye	321	computer)	219
With the rear axle raised	322	Trip odometer	
Towing a trailer		Calling up	219
Active Parking Assist	188	Resetting (on-board computer)	
Cleaning the trailer tow hitch		see Trip odometer	
Coupling up a trailer	210	Turn signals	
Decoupling a trailer	212	Changing bulbs (front)	119
Driving tips		Display message	240
Important safety notes		Switching on/off	112
Installing the ball coupling	210	see Turn signals	–
Lights display message		TWR (Tongue Weight Rating)	
Mounting dimensions		(definition)	351
Power supply		Type identification plate	
Removing the ball coupling		see Vehicle identification plate	
Shift range			



U	Coolant 265
Unleaking	Distance warning 267
Unlocking	DISTRONIC PLUS 267
Emergency unlocking	ESP <sup>®</sup> 261
From inside the vehicle (central	ESP <sup>®</sup> OFF
unlocking button) 80	Fuel tank 264
V	Overview 32
V	PASSENGER AIR BAG OFF
Vanity mirror (in the sun visor) 279	indicator lamp 47
Vehicle	Reserve fuel 264
Data acquisition 28	Seat belt
Display message 254	SRS 263
Emergency locking 81	Tire pressure monitor 268
Emergency unlocking 81	<b>Warranty</b>
Equipment	Washer fluid
Individual settings 226	Display message 255
Limited Warranty 28	Wheel bolt tightening torque 356
Loading 339	Wheel chock
Locking (in an emergency) 81	Wheels
Locking (SmartKey) 74	Changing a wheel 352
Lowering 356	Checking 329
Maintenance 24	Cleaning 305
Parking for a long period 161	Cleaning (warning) 353
Pulling away 143	Emergency spare wheel
Raising	Important safety notes
Reporting problems	Interchanging/changing 352
Securing from rolling away	Mounting a new wheel
Towing away 320	Mounting a wheel
Transporting	Removing a wheel
Unlocking (in an emergency)	Storing
Unlocking (SmartKey)	Tightening torque
Vehicle data	Wheel size/tire size
Vehicle data	Window curtain air bag
Vehicle dimensions	Display message
Vehicle emergency locking 81	Operation 46
Vehicle identification number	Windows
see VIN	see Side windows
Vehicle identification plate	Windshield
Vehicle tool kit	Defrosting
Video (DVD)	see Windshield Windshield washer fluid
VIN 304	
W	see Windshield washer system Windshield washer system
W	Notes
Warning and indicator lamps	Windshield wipers
ABS 259	Problem (malfunction) 124
Brakes 259	Rear window wiper 121
Check Engine 264	iteal williauw wipel 121



Replacing the wiper blades	121
Switching on/off	120
Winter driving	
Important safety notes	330
Slippery road surfaces	166
Snow chains	331
Winter tires	
M+S tires	330
Wiper blades	
Cleaning	306
Important safety notes	121
Replacing (rear window)	122
Replacing (windshield)	122
Wooden trim (cleaning	
instructions)	309
Workshops	
see Qualified specialist workshop	



## Protection of the environment

#### General notes

## φ

#### **Environmental note**

Daimler's declared policy is one of comprehensive environmental protection.

The objectives are for the natural resources that form the basis of our existence on this planet to be used sparingly and in a manner that takes the requirements of both nature and humanity into account.

You too can help to protect the environment by operating your vehicle in an environmentally responsible manner.

Fuel consumption and the rate of engine, transmission, brake and tire wear are affected by these factors:

- operating conditions of your vehicle
- · your personal driving style

You can influence both factors. You should bear the following in mind:

Operating conditions:

- avoid short trips as these increase fuel consumption.
- always make sure that the tire pressures are correct.
- do not carry any unnecessary weight.
- remove roof racks once you no longer need them.
- a regularly serviced vehicle will contribute to environmental protection. You should therefore adhere to the service intervals.
- always have service work carried out at a qualified specialist workshop.

Personal driving style:

- do not depress the accelerator pedal when starting the engine.
- do not warm up the engine when the vehicle is stationary.
- drive carefully and maintain a safe distance from the vehicle in front.
- avoid frequent, sudden acceleration and braking.

- change gear in good time and use each gear only up to <sup>2</sup>/<sub>3</sub> of its maximum engine speed.
- switch off the engine in stationary traffic.
- keep an eye on the vehicle's fuel consumption.

## Environmental concerns and recommendations

Wherever the operating instructions require you to dispose of materials, first try to regenerate or re-use them. Observe the relevant environmental rules and regulations when disposing of materials. In this way you will help to protect the environment.

## **Genuine Mercedes-Benz parts**



#### **Environmental note**

Daimler AG also supplies reconditioned major assemblies and parts which are of the same quality as new parts. They are covered by the same Limited Warranty entitlements as new parts.

- Air bags and Emergency Tensioning Devices, as well as control units and sensors for these restraint systems, may be installed in the following areas of your vehicle:
  - doors
  - door pillars
  - · door sills
  - seats
  - cockpit
  - instrument cluster
  - · center console

Do not install accessories such as audio systems in these areas. Do not carry out repairs or welding. You could impair the operating efficiency of the restraint systems.



Have aftermarket accessories installed at a qualified specialist workshop.

You could jeopardize the operating safety of your vehicle if you use parts, tires and wheels as well as accessories relevant to safety which have not been approved by Mercedes. This could lead to malfunctions in safety-relevant systems, e.g. the brake system. Use only genuine Mercedes-Benz parts or parts of equal quality. Only use tires, wheels and accessories that have been specifically approved for your vehicle.

Genuine Mercedes-Benz parts are subject to strict quality control. Every part has been specifically developed, manufactured or selected for and adapted to Mercedes-Benz vehicles. Only genuine Mercedes-Benz parts should therefore be used.

More than 300,000 different genuine Mercedes-Benz parts are available for Mercedes-Benz models.

All authorized Mercedes-Benz Centers maintain a supply of genuine Mercedes-Benz parts for necessary service and repair work. In addition, strategically located parts delivery centers provide quick and reliable parts service.

Always specify the vehicle identification number (VIN) (▷ page 364) and the engine number (▷ page 365) when ordering genuine Mercedes-Benz parts.

#### Operator's Manual

#### **General notes**

Before you first drive off, read this Operator's Manual carefully and familiarize yourself with your vehicle.

For your own safety and a longer vehicle life, follow the instructions and warning notices in this manual. Disregarding them may lead to damage to the vehicle or personal injury.

Vehicle damage resulting from the disregard of the instructions is not covered by the Mercedes-Benz Limited Warranty.

### Vehicle equipment

This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of going to print. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions. The equipment in your vehicle may therefore differ from some of the descriptions or illustrations.

The original purchase agreement lists all systems installed in your vehicle.

Contact an authorized Mercedes-Benz Center if you have any questions about equipment or operation.

The Operator's Manual and Maintenance Booklet are important documents and should be kept in the vehicle.

## Service and vehicle operation

#### Service and literature

Your vehicle is covered under the terms of the warranties printed in the Service and Warranty Information booklet. Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:

- New Vehicle Limited Warranty
- Emission Systems Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control Systems Warranty
- State warranty enforcement laws (lemon laws)



## Information for customers in California

Under California law you may be entitled to a replacement of your vehicle or a refund of the purchase price or lease price, if after a reasonable number of repair attempts Mercedes-Benz USA, LLC and/or its authorized repair or service facilities fail to fix one or more substantial defects or malfunctions in the vehicle that are covered by its express warranty. During the period of 18 months from original delivery of the vehicle or the accumulation of 18,000 miles (approximately 29,000 km) on the odometer of the vehicle, whichever occurs first, a reasonable number of repair attempts is presumed for a retail buyer or lessee if one or more of the following occurs:

- (1) the same substantial defect or malfunction results in a condition that is likely to cause death or serious bodily injury if the vehicle is driven, that defect or malfunction has been subject to repair two or more times, and you have directly notified Mercedes-Benz USA, LLC in writing of the need for its repair,
- (2) the same substantial defect or malfunction of a less serious nature than category (1) has been subject to repair four or more times and you have directly notified us in writing of the need for its repair, or
- (3) the vehicle is out of service by reason of repair of the same or different substantial defects or malfunctions for a cumulative total of more than 30 calendar days.

Please send your written notice to: Mercedes-Benz USA, LLC Customer Assistance Center One Mercedes Drive Montvale, NJ 07645-0350

#### Maintenance

The Service and Warranty Booklet describes all the necessary maintenance work which should be done at regular intervals.

Always have the Service and Warranty Booklet with you when you bring the vehicle to an authorized Mercedes-Benz Center. The service advisor will record every service for you in the Service and Warranty Booklet.

#### **Roadside Assistance**

The Mercedes-Benz Roadside Assistance Program offers technical help in the event of a breakdown. Calls to the toll-free Roadside Assistance Hotline are answered by our agents 24 hours a day, 365 days a year.

## 1-800-FOR-MERCedes(1-800-367-6372) (USA)

#### 1-800-387-0100 (Canada)

For additional information, refer to the Mercedes-Benz Roadside Assistance Program brochure (USA) or the "Roadside Assistance" section in the Service and Warranty booklet (Canada). You will find both in your vehicle literature portfolio.

## Change of address or change of ownership

In the event of a change of address, please send us the "Notification of Address Change" in the Service and Guarantee booklet or simply call the Mercedes-Benz Customer Assistance Center (USA) at the hotline number

1-800-FOR-MERCedes (1-800-367-6372) or Customer Service Center (Canada) at 1-800-387-0100. This will assist us in contacting you in a timely manner should the need arise.

If you sell your Mercedes, please leave the entire literature in the vehicle so that it is available to the next owner.



If you have purchased a used car, please send us the "Notification of Used Car Purchase" in the Service and Guarantee booklet or simply call the Mercedes-Benz Customer Assistance Center (USA) at the hotline number 1-800-FOR-MERCedes(1-800-367-6372) or Customer Service (Canada) at 1-800-387-0100.

#### Vehicle operation outside the USA and Canada

If you plan to operate your vehicle in foreign countries, please be aware that:

- service facilities or replacement parts may not be readily available.
- unleaded fuel for vehicles with a catalytic converter may not be available. Leaded fuel may cause damage to the catalytic converter.
- the fuel may have a considerably lower octane rating. Unsuitable fuel can cause engine damage.

Some Mercedes-Benz models are available for delivery in Europe through our European Delivery Program. For details, consult an authorized Mercedes-Benz Center or write to one of the following addresses.

#### In the USA

Mercedes-Benz USA, LLC European Delivery Department One Mercedes Drive Montvale, NJ 07645-0350

#### In Canada

Mercedes-Benz Canada, Inc. European Delivery Department 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

## **Sports Utility Vehicle**



#### **↑** WARNING

Due to the high center of gravity, the vehicle may start to skid and roll over in the event of an abrupt steering maneuver and/or when the vehicle's speed is not adapted to the road conditions. There is a risk of an accident.

Always adapt your speed and driving style to the vehicle's driving characteristics and to the prevailing road and weather conditions.

Utility vehicles have a significantly higher rollover rate than other types of vehicles.

Failure to operate this vehicle safely may result in an accident, rollover of the vehicle, and severe or fatal injury.

In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt.

You and all vehicle occupants should always wear your seat belts.

## Operating safety

## Important safety notes



#### **↑** WARNING

If you do not have the prescribed service/ maintenance work or any required repairs carried out, this can result in malfunctions or system failures. There is a risk of an accident.

Always have the prescribed service/ maintenance work as well as any required repairs carried out at a qualified specialist workshop.



#### **↑** WARNING

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect, for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.



#### **↑** WARNING

Modifications to electronic components, their software as well as wiring can impair their function and/or the function of other



networked components. In particular, systems relevant to safety could also be affected. As a result, these may no longer function as intended and/or jeopardize the operating safety of the vehicle. There is an increased risk of an accident and injury.

Never tamper with the wiring as well as electronic components or their software. You should have all work to electrical and electronic equipment carried out at a qualified specialist workshop.

There is a risk of damage to the vehicle if:

- the vehicle becomes stuck, e.g. on a high curb or an unpaved road
- vou drive too fast over an obstacle, e.g. a curb or a hole in the road
- a heavy object strikes the undercarriage or parts of the chassis.

In situations like this, the body, the undercarriage, chassis parts, wheels or tires could be damaged without the damage being visible. Components damaged in this way can unexpectedly fail or, in the case of an accident, no longer withstand the strain they are designed to.

If the underbody paneling is damaged, combustible materials such as leaves, grass or twigs can gather between the underbody and the underbody paneling. If these materials come in contact with hot parts of the exhaust system for an extended period, they can catch fire.

Have the vehicle checked and repaired immediately at a qualified specialist workshop. If on continuing your journey you notice that driving safety is impaired, pull over and stop the vehicle immediately, paying attention to road and traffic conditions. In such cases, visit a qualified specialist workshop.

## **Declarations of conformity**

### Vehicle components which receive and/or transmit radio waves

USA: "The wireless devices of this vehicle comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) These devices may not cause harmful interference, and 2) These devices must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

Canada: "The wireless devices of this vehicle comply with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) These devices may not cause interference, and (2) These devices must accept any interference, including interference that may cause undesired operation of the device."

### **Diagnostics connection**

The diagnostics connection is only intended for the connection of diagnostic equipment at a qualified specialist workshop.



### ♠ WARNING

If you connect equipment to the diagnostics connection in the vehicle, it may affect the operation of the vehicle systems. As a result. the operating safety of the vehicle could be affected. There is a risk of an accident.

Do not connect any equipment to a diagnostics connection in the vehicle.



#### 

Objects in the driver's footwell can restrict the pedal travel or obstruct a depressed pedal. The operating and road safety of the vehicle is jeopardized. There is a risk of an accident.



Make sure that all objects in the vehicle are stowed correctly, and that they cannot enter the driver's footwell. Install the floormats securely and as specified in order to ensure sufficient clearance for the pedals. Do not use loose floormats.

If the engine is switched off and equipment on the diagnostics connection is used, the starter battery may discharge.

Connecting equipment to the diagnostics connection can lead to emissions monitoring information being reset, for example. This may lead to the vehicle failing to meet the requirements of the next emissions test during the main inspection.

#### Qualified specialist workshop

An authorized Mercedes-Benz Center is a qualified specialist workshop. It has the necessary specialist knowledge, tools and qualifications to correctly carry out the work required on your vehicle. This is especially the case for work relevant to safety.

Observe the notes in the Maintenance Booklet.

Always have the following work carried out at an authorized Mercedes-Benz Center:

- · work relevant to safety
- · service and maintenance work
- · repair work
- alterations, installation work and modifications
- · work on electronic components

## Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to contact an authorized Mercedes-Benz Center immediately to have the problem diagnosed and rectified. If the problem is not resolved to your satisfaction, please discuss the problem

again with a Mercedes-Benz Center or contact us at one of the following addresses.

#### In the USA

Customer Assistance Center Mercedes-Benz USA, LLC One Mercedes Drive Montvale, NJ 07645-0350

#### In Canada

Customer Relations Department Mercedes-Benz Canada, Inc. 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

### Reporting safety defects

USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mercedes-Benz USA, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at

1-888-327-4236(TTY: 1-800-424-9153); go to **http://www.safercar.gov**; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590.

You can also obtain other information about motor vehicle safety from

http://www.safercar.gov



## **Limited Warranty**

I Follow the instructions in this manual about the proper operation of your vehicle as well as about possible vehicle damage. Damage to your vehicle that arises from culpable contraventions against these instructions is not covered either by the Mercedes-Benz Limited Warranty or by the New or Used-Vehicle Warranty.

#### Data stored in the vehicle

## Information about electronic data acquisition in the vehicle

(Including notice pursuant to California Code § 9951)

Your vehicle records electronic data. If your vehicle is equipped with mbrace (Canada: TELE AID), data is transmitted in the event of an accident.

This information helps, for example, to test vehicle systems after an accident and to continually improve vehicle safety.

Daimler AG can access this data and submit it:

- for safety research or vehicle diagnosis purposes
- · with the consent of the vehicle owner
- on the instruction of prosecuting authorities
- for use in arbitration of disputes that involve Daimler AG, its affiliates or its sales and service organizations
- as otherwise required or permitted by law.

Please check your mbrace (Canada: TELE AID) purchase agreement to find out more about data that can be recorded and transmitted by this system.

## Information on copyright

### **General information**

Information on license for free and opensource software used in your vehicle and its electronic components is available on the following website:

http://www.mercedes-benz.com/ opensource



Dashboard	30
Instrument cluster	31
Multifunction steering wheel	33
Center console	34
Overhead control panel	36
Door control panel	37

## Dashboard




	Function	Page
1	Steering wheel paddle shifters	152
2	Combination switch	112
3	Instrument cluster	31
4	Horn	
5	PARKTRONIC warning display	180
6	Overhead control panel	36
7	Operating the climate control systems	126
8	Ignition lock Start/Stop button	141 141

		3.10-4470-31
	Function	Page
9	Adjusting the steering wheel manually	102
10	Adjusting the steering wheel electrically	102
11)	Cruise control lever	170
12	Parking brake	161
13	Diagnostics connection	26
14)	Opening the hood	300
(15)	Releasing the parking brake	161
16	Light switch	110
(2) (3) (4) (5)	Cruise control lever Parking brake Diagnostics connection Opening the hood Releasing the parking brake	170 161 26 300 161



## Instrument cluster

## **Displays and controls**




P54.32-9961-31

	Function	Page
1	Fuel gauge	
2	Coolant temperature	216
3	Speedometer with segments	217

	Function	Page
4	Multifunction display	218
5	Tachometer	216

 Adjust the instrument cluster lighting using the on-board computer (▷ page 227).

## Warning and indicator lamps



	Function	Page
1	<b>₽</b> ESP <sup>®</sup>	261
2	Distance warning	267
3	ESP® OFF	261
4	Brakes (USA only)	259
5	® Brakes (Canada only)	259
6	<b>♦</b> Turn signals	112
7	(a) ABS	259
8	<b>⋟</b> SRS	263
9	Check Engine	264
10	(!) Tire pressure monitor	268
11)	🐐 Seat belt	257

	Function	Page
(12)	Diesel engine:	143
(13)	Coolant	265
14)	High-beam headlamps	113
(15)	Low-beam headlamps	111
16	₹00€ Parking lamps	112
17	☐ Rear fog lamp	112
18	Front fog lamps	111
19	Reserve fuel	264



## Multifunction steering wheel




	Function	Page
1	Multifunction display	218
2	Audio/COMAND display; see the separate operating instructions	
3	Switches on the Voice Control System; see the separate operating instructions	
4	Rejects or ends a call Exits phone book/redial memory  Makes or accepts a call Switches to the redial memory  + - Adjusts the volume  Mute	223

	Function	Page
5	Selects a menu	217
	Selects a submenu or scrolls through lists  OK	217
	Confirms your selection	217
	Hides display messages	231
6	Back Switches off the Voice Control System; see the separate operating instructions	217



## **Center console**

## Center console, upper section




	Function	Page
1	A Hazard warning lamps	113
2	ATA indicator lamp	71
3	PASS OFF Indicator lamp	47
4	₹ ESP®	66
5	COMAND; see the separate operating instructions	

	Function	Page
6	₩ Seat heating	101
7	ECO ECO start/stop function	144
8	PARKTRONIC	180



# Center console, lower section




	Function	Page
1	Stowage compartment	271
	Ashtray	279
	Cigarette lighter	280
	Socket	280
2	Cup holder	278

	Function	Page
3	Stowage compartment	271
4	Audio/COMAND controller; see the separate operating instructions	



# Overhead control panel




	Function	Page
1	Switches the rear- compartment interior lighting on/off	116
2	Switches the automatic interior lighting control on/off	116
3	M Switches the right-hand reading lamp on/off	115
4	Opens/closes the panorama roof with power tilt/sliding panel with roller sunblinds	91
5		286
6	ু <b>sos</b> SOS button (mbrace system)	284
7	Rear-view mirror	103

10	2.00-20/0-31
Function	Page
Integrated electronic compass	294
Buttons for the garage door opener	293
Microphone for mbrace (emergency call system), telephone and the Voice Control System <sup>1</sup>	
Roadside Assistance call button (mbrace system)	286
Mand reading lamp on/off	115
Switches the front interior lighting on/off	116
	Function Integrated electronic compass Buttons for the garage door opener Microphone for mbrace (emergency call system), telephone and the Voice Control System¹  Roadside Assistance call button (mbrace system)  Switches the left-hand reading lamp on/off  Switches the front

<sup>1</sup> The Voice Control system is only available in combination with COMAND. Observe the additional operating instructions.

# Door control panel



	Function	Page
1	Opens the door	79
2	Unlocks/locks the vehicle	80
3	Adjusts the seats electrically	98
4	M 1 2 3 Stores settings for the seat, exterior mirrors and steering wheel	106
5	Selects the left exterior mirror	103
6	Folds the exterior mirrors in/out	104
7	Selects the right exterior mirror	103

	Function	Page
8	Adjusts the exterior mirrors	103
9	Opens/closes the front side windows	87
10	回 Opens/closes the rear side windows	87
11)	deactivates/ deactivates the override feature for the side windows in the rear compartment	63
12	ত্ত্য Opens/closes the tailgate	84





Useful information	40
Panic alarm	40
Occupant safety	40
Children in the vehicle	58
Driving safety systems	64
Theft deterrent locking system	71

# **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (⊳ page 27).

### Panic alarm



- ► To activate: press PANIC button (1) for approximately one second. An alarm sounds and the exterior lighting flashes.
- ► To deactivate: press PANIC button (1) again.

or

- ▶ Insert the SmartKey into the ignition lock. or
- ▶ Press the KEYLESS-GO Start/Stop button. The KEYLESS-GO key must be in the vehicle.

# **Occupant safety**

### Overview of occupant safety

In this section, you will learn the most important facts about the restraint system components of the vehicle.

The restraint system consists of:

- · seat belts
- · child restraint systems
- LATCH-type (ISOFIX) child seat anchors Additional protection is provided by:
- SRS (Supplemental Restraint System)
- NECK-PRO head restraints/NECK-PRO luxury head restraints
- air bag system components with:
  - PASSENGER AIR BAG OFF indicator lamp
  - front-passenger seat with Occupant Classification System (OCS)

The different air bag systems work independently of each other. The protective functions of the system work in conjunction with each other. Not all air bags are always deployed in an accident.

### **↑** WARNING

Modifications to or work improperly conducted on restraint system components or their wiring, as well as tampering with interconnected electronic systems, can lead to the restraint systems no longer functioning as intended.

Air bags or Emergency Tensioning Devices (ETDs), for example, could deploy inadvertently or fail to deploy in accidents although the deceleration threshold for air bag deployment is exceeded. Therefore, never modify the restraint systems. Do not tamper with electronic components or their software.

For information on infants and children. traveling with you in the vehicle restraint systems for infants and children, see "Children in the vehicle" (> page 58).



# SRS (Supplemental Restraint System)

### Introduction

SRS consists of:

- The SRS warning lamp
- Air bags
- Air bag control unit (with crash sensors)
- Emergency Tensioning Devices
- · Belt force limiters

SRS reduces the risk of occupants coming into contact with the vehicle's interior in the event of an accident. It can also reduce the effect of the forces to which occupants are subjected during an accident.

### SRS warning lamp

SRS functions are checked regularly when you switch on the ignition and when the engine is running. Therefore, malfunctions can be detected in good time.

The SRS warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out no later than a few seconds after the engine is started.

The SRS components are in operational readiness when the SRS warning lamp goes out while the engine is running.

## **↑** WARNING

The SRS self-check has detected a malfunction if the SRS indicator lamp:

- · does not light up at all
- does not go out after approximately four seconds after the engine is started
- · comes on after the engine was started or while driving.

For your safety, Mercedes-Benz strongly recommends that you have the system checked as soon as possible at an authorized Mercedes-Benz Center. SRS may otherwise fail to activate when it is needed in the event of an accident, which could lead to serious or fatal injuries. SRS might also be activated

unexpectedly and unnecessarily, which could also result in injury.

In addition, work carried out improperly on SRS may render SRS inoperative or cause unintended air bag deployment. Work on the SRS system should only be carried out by qualified specialist personnel. Consult an authorized Mercedes-Benz Center.

If it is necessary to modify an air bag system to accommodate a person with disabilities, contact an authorized Mercedes-Benz Center for details. USA only: for further information contact our Customer Assistance center at 1-800-FOR-MERCedes (1-800-367-6372).

# Safety guidelines for seat belts, **Emergency Tensioning Devices (ETDs)** and air bags



### **↑** WARNING

- Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced. Their anchoring points must also be checked. Only use seat belts installed or supplied by an authorized Mercedes-Benz Center.
- Air bags and pyrotechnic Emergency Tensioning Devices (ETDs) contain perchlorate material, which may require special handling and regard for the environment. Check your national disposal guidelines. California residents, see www.dtsc.ca.gov/HazardousWaste/ Perchlorate/index.cfm.
- Air bags and ETDs are designed to function on a one-time-only basis. An air bag or ETD that has deployed must be replaced.
- Do not pass seat belts over sharp edges. They could tear.
- Do not make any modification that could change the effectiveness of the seat belts.
- Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.
- · No modifications of any kind may be made to any components or wiring of the SRS.



- Do not change or remove any component or part of the SRS.
- Do not install additional trim material, seat covers, badges, etc. over the steering wheel hub, front-passenger front air bag cover, outer sides of the seat backrests. door trim panels, or door frame trims.
- Do not install additional electrical/ electronic equipment on or near SRS components and wiring.
- Keep area between air bags and occupants free of objects (e.g. packages, purses, umbrellas, etc.).
- Do not hang items such as coat hangers from the coat hooks or handles over the door. These items may be thrown around in the vehicle and cause head and other injuries when the window curtain air bag is deployed.
- Air bag system components will be hot after an air bag has inflated. Do not touch them.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.
- Improper repair work on the SRS creates a risk of rendering the SRS inoperative or causing unintended air bag deployment. Work on the SRS must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center
- For your protection and the protection of others, when scrapping the air bag unit or ETD, our safety instructions must be followed. These instructions are available from any authorized Mercedes-Benz Center.
- Given the considerable deployment speed, required inflation volume, and the material of the air bags, there is the possibility of abrasions or other, potentially more serious injuries resulting from air bag deployment.

If you sell your vehicle, Mercedes-Benz

strongly recommends that you inform the

subsequent owner that the vehicle is equipped with SRS. Also, refer them to the applicable section in the Operator's Manual.

### Air bags

# Important safety notes



### **↑** WARNING

Air bags are designed to reduce the incidence of injuries and fatalities in certain situations:

- frontal impacts (driver's and frontpassenger front air bags and driver's knee
- side impacts (side impact air bags, window curtain air bags and pelvis air bags)
- rollover (window curtain air bags) However, no system available today can completely eliminate injuries and fatalities.

When the air bags are deployed, a small amount of powder is released. The powder generally does not constitute a health hazard and does not indicate that there is a fire in the vehicle. In order to prevent potential breathing difficulties, you should leave the vehicle as soon as it is safe to do so. If you have any breathing difficulty but cannot get out of the vehicle after the air bag inflates. then get fresh air by opening a window or door.



# / WARNING

In order to reduce the potential danger of injuries caused during the deployment of the front air bags, the driver and front passenger must always be correctly seated and wear their seat belts.

For maximum protection in the event of a collision, you must always be in the normal seat position with your back against the backrest. Fasten your seat belt and make sure that it is correctly positioned on your body.



As the air bag inflates with considerable speed and force, a proper seating position and correct positioning of the hands on the steering wheel will help to keep you at a safe distance from the air bag. Occupants who are not wearing their seat belt, are not seated properly or are too close to the air bag can be seriously injured or killed by an air bag, as it inflates with great force instantaneously:

- · sit with the seat belt fastened correctly and in a position that is as upright as possible with your back against the backrest.
- move the driver's seat as far back as possible, still permitting proper operation of vehicle controls. The distance from the center of the driver's chest to the center of the air bag cover on the steering wheel must be at least 10 inches (25 cm). You should be able to accomplish this by adjusting the seat and steering wheel. If you have any difficulties, please contact an authorized Mercedes-Benz Center.
- do not lean your head or chest close to the steering wheel or dashboard.
- only hold the steering wheel on the outside. Placing hands and arms inside the rim can increase the risk and potential severity of hand/arm injury if the driver front air bag inflates.
- adjust the front-passenger seat as far back as possible from the dashboard when the seat is occupied.
- · occupants, especially children, should never place their bodies or lean their heads in the area of the door where the side impact air bag inflates. This could result in serious or fatal injuries should the side impact air bag be deployed. Always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint or booster seat recommended for the size and weight of the child.

Failure to follow these instructions can result in severe injuries to you or other occupants.

If you sell your vehicle, it is important that you make the buyer aware of this safety information. Be sure to give the buyer this Operator's Manual.

### **↑** WARNING

Accident research shows that the safest place for children in an automobile is in a rear seat. A side impact air bag related injury may occur if occupants, especially children, are not properly seated or restrained when next to a side impact air bag which needs to deploy rapidly in a side impact in order to do its job. To help avoid the possibility of injury, please follow these guidelines:

- Always sit as upright as possible (1) and use the seat belts properly. Make sure that children 12 years old and under use an appropriately sized child restraint, infant restraint, or booster seat recommended for the size and weight of the child.
- (2) Always wear seat belts properly.

The air bags are only deployed if the air bag control unit detects the need for deployment. Only in the event of such a situation, will the air bags provide their supplemental protection.

If the driver and front passenger do not wear their seat belts, it is not possible for the air bags to provide their supplemental protection.

In the event of other types of impacts and impacts below air bag deployment thresholds, the air bags will not deploy. The driver and passenger will then be protected to the extent possible by a properly fastened seat belt. A properly fastened seat belt is also needed to provide the best possible protection if the vehicle rolls over.

Air bags are not a substitute for seat belts. Always wear your seat belt, regardless of whether or not your vehicle is equipped with air bags.



It is important to your safety and that of your passenger to have deployed air bags replaced and to have any malfunctioning air bags repaired. This will help to make sure the air bags will continue to provide supplemental crash protection for occupants .

# Front air bags

The front air bags increase protection for the driver's and front-passenger's head and chest.



Driver's air bag ① deploys in front of the steering wheel; front-passenger front air bag ② deploys in front of and above the glove box.

They are deployed:

- in the event of certain frontal impacts
- if the system determines that air bag deployment can offer additional protection to that provided by the seat belt
- · if the seat belt is fastened
- independently of other air bags in the vehicle

If the vehicle rolls over, the front air bags are generally not deployed. If the system detects high vehicle deceleration in a longitudinal direction, the front air bags are deployed.

Your vehicle has adaptive, two-stage front air bags. In the event of a collision, the air bag control unit evaluates the vehicle deceleration. In the first deployment stage, the front air bag is filled with enough propellant gas to reduce the risk of injuries. The front air bag is fully deployed if a second

deployment threshold is exceeded within a few milliseconds.

The deployment of the front-passenger front air bag is also influenced by the weight category of the front passenger, which is determined by the Occupant Classification System (OCS) (▷ page 47).

The lighter the passenger-side occupant, the higher the vehicle deceleration rate required (predicted at the start of the impact) for second stage inflation of the front-passenger front air bag. In the second stage, the front air bags are inflated with the maximum amount of propellant gas available.

The front air bags are not deployed in situations where a low impact severity is predicted. You will then be protected by the fastened seat belt.

The front-passenger front air bag will only be deployed if:

- the system, based on the OCS weight sensor readings, detects that the frontpassenger seat is occupied
- the 🎉 PASS. OFF indicator lamp on the center console is not lit (▷ page 47)
- the air bag control unit predicts a highimpact severity.

# Driver's knee bag



Driver's knee bag ① increases the driver's protection against:

- · knee injuries
- thigh injuries
- · lower leg injuries



Driver's knee bag (1) deploys under the steering column. If, during a frontal collision, the system determines that air bag deployment can offer additional protection to that provided by the seat belt, driver's knee bag (1) is deployed along with the driver's air bag. Driver's knee bag (1) operates best in conjunction with correctly positioned and fastened seat belts.

# Side impact air bags



### **↑** WARNING

The pressure sensors for side impact air bag control are located in the doors. Do not modify any components of the doors or door trim panels including, for example, the addition of door speakers.


Improper repair work on the doors or the modification or addition of components to the doors create a risk of rendering the side impact air bags inoperative or causing unintended air bag deployment. Work on the doors must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.

### **↑** WARNING

Only use seat covers which have been tested and approved by Mercedes-Benz for your vehicle model. Using seat covers or other seat coverings can cause a malfunction of the side impact air bags and/or the pelvis air bags. Contact an authorized Mercedes-Benz Center for availability.

When deployed, the side impact air bags offer additional protection for the thorax of the vehicle occupants on the side of the vehicle on which the impact occurs. However, they do not protect the:

- head
- neck
- arms



Side impact air bags (1) deploy next to the outer seat cushions.

Side impact air bags (1) are deployed:

- on the side on which an impact occurs
- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- independently of the use of the seat belt
- independently of the front air bags
- independently of the ETDs

If the vehicle rolls over, the side impact air bags are generally not deployed. Exception: if the system detects high vehicle deceleration or acceleration in a lateral direction and determines that deployment can offer additional protection to that provided by the seat belt.

Side impact air bags (1) will not deploy in side impacts which do not exceed the system's preset deployment thresholds for lateral acceleration/deceleration. You will then be protected by the fastened seat belt.

The side impact air bag on the frontpassenger side is not deployed in the following situations:

- OCS has detected that the front-passenger seat is unoccupied.
- the front-passenger seat belt is not fastened.

The side impact air bag on the frontpassenger side will deploy if the frontpassenger seat belt is fastened, regardless of whether the front-passenger seat is occupied



### Pelvis air bags



# **↑** WARNING

Only use seat covers which have been tested and approved by Mercedes-Benz for your vehicle model. Using seat covers or other seat coverings can cause a malfunction of the side impact air bags and/or the pelvis air bags. Contact an authorized Mercedes-Benz Center for availability.

Pelvis air bag deployment enhances the level of protection of the vehicle occupants on the side of the vehicle on which the impact occurs.



Pelvis air bags (1) deploy next to and below the outer seat cushions. They are deployed:

- on the side on which an impact occurs
- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- independently of the use of the seat belt
- independently of the front air bags
- independently of the ETDs

If the vehicle rolls over, the pelvis air bags are generally not deployed. Exception: if the system detects high vehicle deceleration or acceleration in a lateral direction and determines that deployment can offer additional protection to that provided by the seat belt.

Pelvis air bags (1) will not deploy in side impacts which do not exceed the system's preset deployment thresholds for lateral

acceleration/deceleration. You will then be protected by the fastened seat belt.

The pelvis air bag on the front-passenger side is not deployed in the following situations:

- OCS has detected that the front-passenger seat is unoccupied.
- the front-passenger seat belt is not fastened.

The pelvis air bag on the front-passenger side will deploy if the front-passenger seat belt is fastened, regardless of whether the frontpassenger seat is occupied or not.

### Window curtain air bags

The window curtain air bags enhance the level of protection for the head, but not chest or arms, of the vehicle occupants on the side of the vehicle on which the impact occurs.

The window curtain air bags are integrated into the side of the roof frame and deploy in the area from the A-pillar to the C-pillar.



Window curtain air bags (1) are deployed:

- on the side on which an impact occurs
- at the start of an accident with a high rate of lateral vehicle deceleration or acceleration, e.g. in a side impact
- regardless of whether the front-passenger seat is occupied
- independently of the use of the seat belt
- if the vehicle rolls over and the system determines that window curtain air bag



deployment can offer additional protection to that provided by the seat belt

• independently of the front air bags
Window curtain air bags ① will not deploy in
the event of impacts which do not exceed the
system's preset deployment thresholds for
vehicle acceleration/deceleration. You will
then be protected by the fastened seat belt.

# Occupant Classification System (OCS)

# How the Occupant Classification System works

The Occupant Classification System (OCS) categorizes the occupant on the front-passenger seat by means of a weight sensor. The front-passenger front air bag is deactivated automatically for certain weight categories. The \*\*State\*\* indicator lamp shows you the current status. If the \*\*State\*\* indicator lamp lights up, the front-passenger air bag is disabled.

The system does not deactivate:

- the side impact air bag
- the pelvis air bag
- the window curtain air bag
- the Emergency Tensioning Devices

To be classified correctly, the front passenger must sit:

- with the seat belt fastened correctly
- in a position that is as upright as possible with their back against the seat backrest
- · with their feet on the floor

If the front-passenger's weight is transferred to another object in the vehicle (e.g. by leaning on armrests), OCS may not be able to approximate the occupant's weight category. If the front-passenger seat, the seat cover or the seat cushion are damaged, have the necessary repair work carried out at an authorized Mercedes-Benz Center.

For safety reasons, Mercedes-Benz recommends that you only use seat accessories that have been approved by Mercedes-Benz.

Both the driver and the front passenger should always observe the highest passenger indicator lamp to determine whether or not the front passenger is positioned correctly.

# **↑** WARNING

In the event of a collision, the air bag control unit will not allow front-passenger front air bag deployment when the OCS has classified the front-passenger seat occupant as weighing as much as or less than a typical 12-month-old child in a standard child restraint or if the front-passenger seat is classified as being empty.

When the OCS senses that the front-passenger seat occupant is classified as being up to or less than the weight of a typical 12-month-old child in a standard child restraint, the indicator lamp will illuminate when the engine is started and remain illuminated, indicating that the front-passenger front air bag is deactivated.

When the OCS senses that the front-passenger seat is classified as being empty, the indicator lamp will illuminate when the engine is started and remain illuminated, indicating that the front-passenger front air bag is deactivated.



weight sensor readings from the front-passenger seat, remain illuminated or go out. With the high passenger indicator lamp illuminated, the front-passenger front air bag is deactivated. With the highest indicator lamp out, the front-passenger front air bag is activated.

When the OCS senses that the front-passenger seat occupant is classified as an adult or someone larger than a small individual, the indicator lamp will illuminate for approximately 6 seconds when the engine is started and then go out, indicating that the front-passenger front air bag is activated.

If the 🎉 land indicator lamp is not illuminated, the front-passenger front air bag is activated and will be deployed:

- in the event of certain frontal impacts
- if impact exceeds a preset deployment threshold
- independently of the side impact air bags If the front-passenger front air bag is deployed, the rate of inflation will be influenced by:
- the rate of relevant vehicle deceleration as assessed by the air bag control unit
- the front passenger's weight category as identified by OCS

For further information, see "Air bag display messages" (▷ page 238).

# **↑** WARNING

According to accident statistics, children are safer when properly restrained on the rear seats than on the front-passenger seat. Thus, we strongly recommend that children be placed in the rear seats whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriate infant restraint, toddler restraint, or booster seat

recommended for the size and weight of the child.

The infant or child restraint must be properly secured with the vehicle's seat belt, the seat belt and Top Tether strap, or lower anchors and Top Tether strap, fully in accordance with the child seat manufacturer's instructions.

Occupants, especially children, should always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

Children can be killed or seriously injured by an inflating air bag. Note the following important information when circumstances require you to place a child in the frontpassenger seat:

- Your vehicle is equipped with air bag technology designed to deactivate the front-passenger front air bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the front-passenger seat.
- A child in a rear-facing child restraint on the front-passenger seat will be seriously injured or even killed if the front-passenger front air bag inflates in a collision which could occur under some circumstances, even with the air bag technology installed in your vehicle. The only means to eliminate this risk completely is never to place a child in a rear-facing child restraint in the frontpassenger seat. We therefore strongly recommend that you always place a child in a rear-facing child restraint on the rear seat.
- If you install a rear-facing child restraint on the front-passenger seat, make sure the indicator lamp is illuminated, indicating that the front-passenger front air bag is deactivated. Should the indicator lamp not illuminate or go out while the restraint is installed, please check installation. Periodically check the



make sure that the handle driving to make sure that the handle driving to lamp is illuminated. If the handle driving indicator lamp goes out or remains out, do not transport a child on the front-passenger seat until the system has been repaired.

A child in a rear-facing child restraint on the front-passenger seat will be seriously injured or even killed if the front-passenger front air bag inflates.

- If you place a child in a forward-facing child restraint on the front-passenger seat:
  - move the seat as far back as possible
  - use the proper child restraint recommended for the age, size and weight of the child
  - secure child restraint with the vehicle's seat belt according to the child seat manufacturer's instructions
- For children larger than the typical 12month-old child, the front-passenger front air bag may or may not be activated.

If the driver's air bag deploys, this does not mean that the front-passenger front air bag will also deploy.

The OCS may have detected that the seat:

- is either empty or occupied by a person with a weight up to that of a typical twelvemonth-old child seated in a standard child restraint
- is occupied by a small individual, such as a young teenager or a small adult
- is occupied by a child in a child restraint system, whose weight is greater than that of a typical twelve-month-old child.

These are examples of when the OCS deactivates the front-passenger front air bag. Deactivation takes place although the collision fulfills the criteria for deploying the driver's air bag.



# **↑** WARNING

If the red SRS warning lamp in the instrument cluster and the Market indicator lamp light up simultaneously, the OCS is malfunctioning. The front passenger front air bag will be deactivated in this case. Have the system checked by qualified technicians as soon as possible. Contact an authorized Mercedes-Benz Center.

Only have the seat repaired or replaced at an authorized Mercedes-Benz Center.

In order to ensure proper operation of the air bag system and OCS:

- Sit with the seat belt properly fastened in a position that is as upright as possible with your back against the seat backrest.
- When seated, a passenger should not position him/herself in such a way as to cause the passenger's weight to be lifted from the seat cushion as this may result in the OCS being unable to correctly approximate the passenger's weight category.
- Read and observe all warnings in this chapter.



# System self-test

The RASS OFF Indicator lamp lights up if you:

- turn the SmartKey to position 1 or 2 in the ignition lock
- on vehicles with KEYLESS-GO, press the Start/Stop button once or twice

When an adult is sitting correctly on the frontpassenger seat and is categorized by the OCS system as an adult, the Ass of indicator lamp lights up and goes off again after approximately six seconds.

If the passenger seat is not occupied and the OCS system detects this, the RASS OFF indicator lamp remains lit and does not go off.

### **↑** WARNING

If the ARBAGOFF indicator lamp does not illuminate, the system is not functioning. You must contact an authorized Mercedes-Benz Center before seating any child on the front passenger seat.

For further information, see "Problems with the Occupant Classification System" (⊳ page 51).

### **↑** WARNING

Never place anything between seat cushion and child seat (e.g. a pillow), since it reduces the effectiveness of the OCS. The underside and rear side child restraint system must be placed entirely on the seat cushion and the backrest of the front-passenger seat backrest.

If necessary, adjust the tilt of the passenger seat backrest.

An incorrectly mounted child seat could cause injuries to the child in case of an accident, instead of increasing protection for the child. Follow the manufacturer's instructions for installation of child restraint systems.



### **Problems with the Occupant Classification System**

### **Problem** Possible causes/consequences and ▶ Solutions The ARBAG OFF The OCS is malfunctioning. indicator lamp lights up ▶ Have the OCS checked as soon as possible at an authorized and stays on. Mercedes-Benz Center. The person on the ▶ Observe the additional display messages in the multifunction front-passenger seat: display (⊳ page 238). · has the weight of a typical adult has been determined by the system not to be a child



### **↑** WARNING

If the 🔀 📠 indicator lamp illuminates and remains illuminated when the weight of a typical adult or someone larger than a small individual has been detected on the passenger seat, do not allow any occupant to use the passenger seat until the system has been repaired.

### **Problem** Possible causes/consequences and ▶ Solutions The AIR BAG OFF The OCS is malfunctioning. indicator lamp does not ▶ Make sure there is nothing between the seat cushion and the light up and/or does child seat. not stay on. ▶ Check the installation of the child restraint system. The front-passenger ▶ Make sure that no objects are applying additional weight onto seat is: the seat. unoccupied ▶ If the RASS OFF indicator lamp remains off, have the OCS · occupied with a system checked as soon as possible at an authorized Mercedesweight up to that of a Benz Center. Do not transport a child on the front-passenger typical twelveseat as long as the OCS is not functioning. month-old child in a ▶ Observe the additional display messages in the multifunction



standard child

restraint system

If the 🔀 📠 indicator lamp does not illuminate or remains out with the weight of a typical 12-month-old child in a standard child restraint or less, or is unoccupied, on the front-passenger seat, do not transport a child on the front-passenger seat until the system has been repaired.

display (⊳ page 238).



# PRE-SAFE® (anticipatory occupant protection system)



### **↑** WARNING

The PRE-SAFE® system reduces the impact of an accident on vehicle occupants, as long as their seat belts have been fastened correctly. Although your vehicle is equipped with a PRE-SAFE® system, the possibility of injury in the event of an accident cannot be ruled out. You should therefore always drive carefully and adapt your driving style to the prevailing road, weather and traffic conditions.

PRE-SAFE® takes preemptive measures to protect occupants in certain hazardous situations.

PRF-SAFF® intervenes:

- if BAS PLUS intervenes powerfully on vehicles with DISTRONIC PLUS
- if. on vehicles with DISTRONIC PLUS, the radar sensor system detects an imminent danger of collision in certain situations
- in critical driving situations, e.g. when physical limits are exceeded and the vehicle understeers or oversteers severely

If the seat belts are not released:

▶ When the vehicle is stationary, move the backrest or seat back slightly. The seat belt pre-tensioning is reduced and the locking mechanism is released.

# **↑** WARNING

Make sure that nobody can become trapped as you adjust the seat.

Make sure that there are no objects in the footwell or behind the seats when resetting the seats. There is a risk that the seats and/or the objects could be damaged.

More information about seat belt adjustment, a convenience function integrated into PRE-SAFE®, can be found in the "Seat belt adjustment" section (⊳ page 56).

# NECK-PRO head restraints/NECK-PRO luxury head restraints

NECK-PRO head restraints / NECK-PRO luxury head restraints increase protection of the driver's and front-passenger's head and neck. In the event of a rear collision of a certain severity, the NECK-PRO head restraints/NECK-PRO luxury head restraints on the driver's and the front-passenger seats are moved forwards and upwards. This provides better head support.



### **↑** WARNING

Do not attach any objects (e.g. a coat hanger) to the NECK-PRO head restraints / NECK-PRO luxury head restraints. Otherwise, the NECK-PRO head restraints/NECK-PRO luxury head restraints may not function properly and in the event of a rear-end collision may not offer the protection they are designed to provide.



### **↑** WARNING

Seat or head restraint covers can cause a malfunction when the NECK-PRO head restraints/NECK PRO luxury head restraints are activated or when the side impact air bags or pelvis air bags are deployed, or they can prevent this completely. The NECK-PRO head restraints/NECK PRO luxury head restraints or side impact air bags/pelvis air bags can therefore not provide the intended protection. Do not use any seat or head restraint covers.

If the NECK-PRO head restraints/NECK-PRO luxury head restraints have been triggered in an accident, reset the NECK-PRO head restraints/NECK-PRO luxury head restraints on the driver's and front-passenger seats (⊳ page 53). Otherwise, the additional protection will not be available in the event of another rear-end collision. NECK-PRO head restraints/NECK-PRO luxury head restraints that have been triggered are moved forwards and can no longer be adjusted.



### **↑** WARNING

For your protection, drive only with properly positioned head restraints.

Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.

# Resetting triggered NECK-PRO head restraints/NECK-PRO luxury head restraints

### Important safety notes



### **↑** WARNING

For reasons of safety, have the NECK-PRO head restraints/NECK-PRO luxury head restraints checked at an authorized Mercedes-Benz Center after a rear-end collision

### **↑** WARNING

When pushing back the NECK-PRO head restraint cushion, make sure your fingers do not become caught between the head restraint cushion and the cover. Failure to observe this could result in injuries.

### **NECK-PRO** head restraints


1 Resetting the NECK-PRO head restraints requires a lot of strength. If you have difficulty resetting the NECK-PRO head restraints, have this work carried out at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.



- ► Tilt the top of the NECK-PRO head restraint cushion forwards in the direction of arrow (1).
- ▶ Push the NFCK-PRO head restraint cushion. down in the direction of arrow (2) as far as it will go.
- ► Firmly push the NECK-PRO head restraint cushion back in the direction of arrow (3) until the cushion engages.
- ▶ Repeat this procedure for the second NECK-PRO head restraint.

### **NECK-PRO luxury head restraints**

1 If you have difficulty resetting the NECK-PRO luxury head restraints, have this work carried out at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.



- ▶ Remove resetting tool (1) from the vehicle document wallet.
- ► Slide resetting tool (1) into guide (2) between the NECK-PRO luxury head



restraint and the rear cover of the head restraint.

- ▶ Push resetting tool (1) downwards until you hear the head restraint deployment mechanism engage.
- ▶ Pull out resetting tool ①.
- ► Firmly press the NECK-PRO luxury head restraint cushion back (3) until it engages.
- ▶ Repeat this procedure for the second NECK-PRO luxury head restraint.
- ▶ Put resetting tool (1) back into the vehicle document wallet

### Seat belts

# Important safety notes

The use of infant or child restraints is required by law in all 50 states, the District of Columbia, all U.S. territories and all Canadian provinces.

Even where this is not the case, all vehicle occupants should have their seat belts fastened when the vehicle is in motion.

 See "Children in the vehicle" (⊳ page 58) for further information on infants and children traveling in the vehicle as well as on child restraint systems.

# **↑** WARNING

Always fasten your seat belt before driving off. Always make sure all of your passengers are properly restrained. You and your passengers should always wear seat belts.

Failure to wear and properly fasten and position your seat belt greatly increases your risk of injuries and their likely severity in an accident.

If you are ever in an accident, your injuries can be considerably more severe without your seat belt properly buckled. Without your seat belt buckled, you are much more likely to hit the interior of the vehicle or be ejected from it. You can be seriously injured or killed.

In the same crash, the possibility of injury or death is lessened if you are properly wearing your seat belt. The air bags can only protect as intended if the occupants are properly wearing their seat belts.

### **↑** WARNING

Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the seat belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The seat backrest and seat belt provide the best restraint when the wearer is in a position that is as upright as possible and the seat belt is properly positioned on the body.



### **↑** WARNING

Never let more people ride in the vehicle than there are seat belts available. Make sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.



### **↑** WARNING

Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced and their anchoring points must also be checked.

Only use seat belts which have been approved by Mercedes-Benz.

Do not make any modifications to the seat belts. This can lead to unintended activation of the ETDs or to their failure to activate when necessary.

Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.

Have all work carried out only by qualified technicians. Contact an authorized Mercedes-Benz Center.



### Correct use of the seat belts

# **↑** WARNING

LISE SEAT BELTS PROPERLY

- · Seat belts can only work when used properly. Never wear seat belts in any other way than as described in this section, as that could result in serious injuries in the event of an accident.
- Each occupant should wear their seat belt at all times, because seat belts help reduce the likelihood of and potential severity of injuries in accidents, including rollovers. The integrated restraint system includes SRS (driver front air bag, driver's side knee bag, front-passenger front air bag, side impact air bags, pelvis air bags, window curtain air bags for the side windows), Emergency Tensioning Devices, seat belt force limiters, and front seat knee bolsters.

The system is designed to enhance the protection offered to properly belted occupants in certain frontal (front air bags. driver's side knee bag and ETDs) and side (side impact air bags, window curtain air bags, and ETDs) impacts which exceed preset deployment thresholds and in certain rollovers (window curtain air bags and ETDs).

• Never wear the shoulder belt under your arm, across your neck or off your shoulder. In a frontal crash, your body would move too far forward. That would increase the chance of head and neck injuries. The seat belt would also apply too much force to the ribs or abdomen, which could severely injure internal organs such as your liver or spleen.

Adjust the seat belt so that the shoulder section is located as close as possible to the middle of the shoulder. It should not touch the neck. Never pass the shoulder portion of the seat belt under your arm. For this purpose, you can adjust the height of the seat belt outlet.

- Position the lap belt as low as possible on your hips and not across the abdomen. If the lap belt is positioned across your abdomen, it could cause serious injuries in a crash.
- Never wear seat belts over rigid or breakable objects in or on your clothing, such as eyeglasses, pens, keys etc., as these might cause injuries.
- · Make sure the seat belt is always fitted snugly. Take special care of this when wearing loose clothing.
- Never use a seat belt for more than one person at a time. Do not fasten a seat belt around a person and another person or other objects at the same time.
- Seat belts should not be worn twisted. In a crash, you would not have the full width of the seat belt to distribute impact forces. The twisted seat belt against your body could cause injuries.
- Pregnant women should also always use a lap-shoulder belt. The lap belt portion should be positioned as low as possible on the hips to avoid any possible pressure on the abdomen.
- Place the seat backrest in a position that is as upright as possible.
- Check your seat belt during travel to make sure it is properly positioned.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.
- When using a seat belt to secure infant restraints, toddler restraints, or children in booster seats, always follow the child seat manufacturer's instructions.



### **↑** WARNING

Do not pass seat belts over sharp edges. They could tear.

Do not allow the seat belt to get caught in the door or in the seat adjustment mechanism. This could damage the seat belt.



Never attempt to make modifications to seat belts. This could impair the effectiveness of the seat belts.

# Fastening seat belts

### **↑** WARNING

According to accident statistics, children are safer when properly restrained on the rear seats than on the front-passenger seat. Thus, we strongly recommend that children be placed in the rear seat whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriately sized child restraint system or booster seat recommended for the size and weight of the child. For additional information, see the "Children in the vehicle" section.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/or the child is not properly secured in the child restraint.



- ▶ Adjust the seat and move the backrest to an almost vertical position (▷ page 96).
- ▶ Pull the seat belt smoothly through belt sash guide ①.
- Without twisting it, guide the shoulder section of the seat belt across the middle

- of your shoulder and the lap section across your pelvis.
- ► Engage belt tongue ② in buckle ③.
- ▶ If necessary, adjust the seat belt to the appropriate height (▷ page 56).
- ▶ If necessary, pull upwards on the shoulder section of the seat belt to tighten the belt across your body.

All seat belts except the driver's seat belt are equipped with a special seat belt retractor to securely fasten child restraint systems in the vehicle. For further information on special seat belt retractors, see ( $\triangleright$  page 61).

For more information about releasing the seat belt with release button 4, see "Releasing seat belts" ( $\triangleright$  page 57).

### Seat belt adjustment

The seat-belt adjustment function adjusts the driver's and front-passenger seat belt to the upper body of the occupants.

The belt strap is tightened slightly when:

 you engage the belt tongue in the belt buckle and you then turn the SmartKey to position 2 in the ignition lock.


The seat-belt adjustment will apply a retraction force if any slack is detected between the occupant and the seat belt. Do not hold on to the seat belt tightly while it is adjusting. You can switch the seat-belt adjustment on and off in the on-board computer (> page 229).

The seat-belt adjustment is an integral part of the PRE-SAFE® convenience function. More information about PRE-SAFE® can be found in the "PRE-SAFE® (anticipatory occupant protection system)" section ( $\triangleright$  page 52).

# Belt height adjustment

You can adjust the seat belt height on the driver's seat and the front-passenger seat.





Adjust the height so that the upper part of the seat belt is routed across the center of your shoulder.

- ► To raise: slide the belt sash guide upwards. The belt sash guide engages in various positions.
- ► **To lower:** press and hold belt sash guide release (1).
- ▶ Slide the belt sash guide downwards.
- Release belt sash guide release ① and make sure that the belt sash guide has engaged.

# Using the rear center seat belt

If the left-hand rear seat backrest is folded down and back up again, the rear center seat belt may lock. The seat belt can then not be pulled out.

➤ To release the rear center seat belt: pull the seat belt out approximately 1 in (25 mm) at the belt outlet on the backrest and then release it again.

The seat belt is retracted and released.

# Releasing seat belts

- Press release button (4)(> page 56) and guide belt tongue (2) back towards belt sash guide (1).
- Make sure that the seat belt is fully rolled up. Otherwise, the seat belt or belt tongue will be trapped in the door or in the seat mechanism. This could damage the door, the door trim panel and the seat belt.

Damaged seat belts can no longer fulfill their protective function and must be replaced. Visit a qualified specialist workshop.

# Belt warning for the driver and front passenger

Regardless of whether the driver's and frontpassenger seat belts have already been fastened, the \*\* seat belt warning lamp lights up for six seconds each time the engine is started. It then goes out if the driver and the front passenger have already fastened their seat belts.

If the driver's seat belt is not fastened when the engine is started, an additional warning tone will sound. This warning tone stops after a maximum of six seconds or once the driver's seat belt is fastened.

If after six seconds the driver or front passenger have not fastened their seat belts and the doors are closed, the 🔼 seat belt warning lamp lights up:

- until the driver's or front passenger's seat belt is fastened
- if a vehicle speed of 15 mph (25 km/h) is exceeded, a warning tone also sounds with increasing intensity for a maximum of 60 seconds or until the driver or frontpassenger seat belt has been fastened.

If the driver/front passenger unfasten their seat belt while the vehicle is in motion, the seat belt warning lamp lights up and a warning tone sounds again.

The warning tone ceases even if the driver or front-passenger seat belt has still not been fastened after 60 seconds. The seat belt warning lamp stops flashing but remains illuminated.

After the vehicle comes to a standstill, the warning tone is reactivated and the seat belt warning lamp flashes again if the vehicle speed again exceeds 15 mph (25 km/h).



The seat belt warning lamp only goes out if:

• both the driver and the front passenger have fastened their seat helts

or

- the vehicle is stationary and a door is open.
- 1 For more information on the 🔼 seat belt warning lamp, see "Warning and indicator lamps in the instrument cluster. seat belts" (⊳ page 257).

### **Emergency Tensioning Devices, seat** belt force limiters

The seat belts for the front seats and rear outer seats are equipped with ETDs and seat belt force limiters.

The ETDs tighten the seat belts in an accident. pulling them close against the body.

The FTDs do not correct incorrect seat positions or incorrectly fastened seat belts. The ETDs do not pull vehicle occupants back towards the backrest.

When triggered, the seat belt force limiters help to reduce the peak force exerted by the seat belt on the vehicle occupant.

The seat belt force limiters for the front seats are synchronized with the front air bags. These take on a part of the deceleration force. They take on a part of the deceleration force, resulting in the force exerted on the occupant being distributed over a greater area.

The ETDs can only be activated when:

- the ignition is switched on
- the restraint systems are operational; see "SRS warning lamp" (> page 41).
- the belt tongue is engaged in the buckle on each of the lap-shoulder belts in the front
- the front-passenger seat is occupied and the belt tongue is engaged in the buckle on the front-passenger side

The ETDs on the outside seats in the rear compartment are triggered independently of the lock status of the seat belts.

The Emergency Tensioning Devices are triggered depending on the type and severity of an accident, if:

- in certain situations where the vehicle rolls over and the system determines that it can provide additional protection
- in the event of a head-on or rear-end collision, the vehicle decelerates or accelerates rapidly in a longitudinal direction during the initial stages of the impact
- in the event of a side impact, the vehicle decelerates or accelerates rapidly in a lateral direction on the side opposite the impact

If the ETDs are deployed, you will hear a bang, and a small amount of powder may also be released. Only in rare cases will the bang affect your hearing. The powder that is released generally does not constitute a health hazard. The SRS warning lamp lights up.

### ★ WARNING

Pyrotechnic ETDs that were activated must be replaced.

For your safety, when disposing of the pyrotechnic ETDs always follow our safety instructions. These are available at any authorized Mercedes-Benz Center.

If the front-passenger seat is not occupied, do not engage the seat belt tongue in the buckle on the frontpassenger seat. Otherwise, the Emergency Tensioning Device could be triggered in the event of an accident.

### Children in the vehicle

### Child restraint systems

### Important safety notes

We recommend that all infants and children be properly secured in an infant or child



restraint system at all times while the vehicle is in motion.

The use of seat belts and infant and child restraint systems is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Infants and small children must be seated in an appropriate infant or child restraint system recommended for the size and weight of the child. The infant or child restraint system must be properly secured in accordance with the manufacturer's instructions. All infant or child restraint systems must comply with the U.S. Federal Motor Vehicle Safety Standards 213 and 225 and Canadian Motor Vehicle Safety Standards 213 and 210.2.

Confirmation that the child restraint system corresponds to the standards can be found on an instruction label on the child restraint system. This confirmation can also be found in the installation instructions that are included with the child restraint system.

Always read and follow the manufacturer's instructions when using an infant or child restraint system or booster seat.

Observe all warning signs in the vehicle interior and on the infant or child restraint.

# **№ WARNING**

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating position. Thus, we strongly recommend that children be placed in the rear seats whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriate infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

The infant or child restraint must be properly secured with the vehicle's seat belt, the seat belt and top tether strap, or lower anchors and top tether strap, fully in accordance with the child seat manufacturer's instructions.

Occupants, especially children, should always sit as upright as possible, wear the seat belt

properly and use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

Children can be killed or seriously injured by an inflating air bag. Note the following important information when circumstances require you to place a child in the front passenger seat:

- Your vehicle is equipped with air bag technology designed to deactivate the front passenger front air bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the front passenger seat.
- For children larger than the typical 12-month-old child, the front passenger front air bag may or may not be activated. Always make sure the \*\* Image: Indicator lamp is illuminated, indicating that the front passenger front air bag is deactivated.
- A child in a rear-facing child restraint on the front passenger seat will be seriously injured or even killed if the front passenger front air bag inflates in a collision which could occur under some circumstances, even with the air bag technology installed in your vehicle. The only means to completely eliminate this risk is to never place a child in a rear-facing child restraint in the front seat. We therefore strongly recommend that you always place a child in a rear-facing child restraint in a backseat.
- If you must install a rear-facing child restraint on the front passenger seat because circumstances require you to do so, make sure the head of indicator lamp is illuminated, indicating that the front passenger front air bag is deactivated. Should the head of indicator lamp not illuminate or go out while the restraint is installed, please check installation. Periodically check the head of indicator lamp while driving to make sure the head of indicator lamp indicator lamp is illuminated. If the



PASS OFF Indicator lamp goes out or remains out, do not transport a child on the front passenger seat until the system has been repaired.

A child in a rear-facing child restraint on the front passenger seat will be seriously injured or even killed if the front passenger front air bag inflates.

• If you have to place a child in a forwardfacing child restraint on the front passenger seat, move the seat as far back as possible, use the proper child restraint recommended for the age, size and weight of the child, and secure child restraint with the vehicle's seat belt according to the child seat manufacturer's instructions.

# **↑** WARNING

Infants and small children should never share a seat belt with another occupant. In the event of an accident, they could be crushed between the occupant and seat belt.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.

Children that are too large for a child restraint must travel in seats using normal seat belts. Position the shoulder belt across the chest and shoulder, not the face or neck. A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lbs (18 kg) until they reach a height where a lap/ shoulder belt fits properly without a booster seat.

When the child restraint is not in use, remove it from the vehicle or secure it with the seat belt to prevent the child restraint from becoming a projectile in the event of an accident.

If an infant or child is traveling in the vehicle:

Secure the infant or child with an appropriate infant or child restraint

- recommended for the child's age and weight.
- Make sure that the infant or child is properly secured at all times while the vehicle is in motion.

### **↑** WARNING

When leaving the vehicle, always remove the SmartKey from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. The children could:

- injure themselves on parts of the vehicle
- be seriously or fatally injured through excessive exposure to extreme heat or cold
- injure themselves or cause an accident with vehicle equipment that can be operated even if the SmartKev is removed from the ignition lock or removed from the vehicle, such as seat adjustment, steering wheel adjustment, or the memory function

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic. Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and the child could be burned on these parts.



### **↑** WARNING

Do not carry heavy or hard objects in the passenger compartment or trunk unless they are firmly secured in place.

Unsecured or improperly positioned cargo increases a child's risk of injury in the event of

- · strong braking maneuvers
- · sudden changes of direction
- · an accident



### Special seat belt retractor

All seat belts except the driver's seat belt are equipped with a special seat belt retractor. When activated, the special seat belt retractor ensures that the seat belt will not slacken once the child restraint system has been secured.

Installing a child restraint system:

- ► Always comply with the manufacturer's installation instructions.
- ▶ Pull the seat belt smoothly from the seat belt retractor.
- Engage the seat belt tongue in the belt buckle.

Activating the special seat belt retractor:

- ▶ Pull the seat belt out fully and let the seat belt retractor retract it again. While the seat belt is retracting, you should hear a ratcheting sound. The special seat belt retractor is activated.
- Push down on the child restraint system to take up any slack.

Removing a child restraint system/ deactivating the special seat belt retractor:

- ► Always comply with the manufacturer's installation instructions.
- Press the seat belt release button and guide the belt tongue to the belt outlet. The special seat belt retractor is deactivated.

# **↑** WARNING

Never release the seat belt buckle while the vehicle is in motion, since the special seat belt retractor will be deactivated.

# LATCH-type (ISOFIX) child seat anchors in the rear

# **↑** WARNING

Children that are too large for a child restraint must travel in seats using normal seat belts. Position shoulder belt across the chest and shoulder, not face or neck. A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lb (18 kg) until they reach a height where a lap/shoulder belt fits properly without a booster.

Install the child restraint system in accordance with the manufacturer's instructions.

Attach the child restraint system to both securing rings.


An incorrectly installed child restraint system could come loose during an accident and seriously or even fatally injure the child.

Child restraint systems or child seat securing rings that are malfunctioning or damaged as the result of a collision must be replaced.

LATCH-type (ISOFIX) is a standardized securing system for specially designed child restraint systems on the rear seats. Securing rings for two LATCH-type (ISOFIX) child restraint systems are installed on the left and right of the rear seats.

Secure non-LATCH-type (ISOFIX) child restraint systems using the vehicle's seat belt system. When installing child restraint systems, you must observe the manufacturer's installation instructions.

When installing the child restraint system, make sure that the seat belt for the middle seat does not get trapped. The seat belt could otherwise be damaged.



Installation instructions ① indicate the installation location of securing rings ②.



► Install the LATCH-type (ISOFIX) child restraint system. Comply with the manufacturer's instructions when installing the LATCH-type (ISOFIX) child restraint system.


### **Top Tether**


### **↑** WARNING

Always lock the rear seat backrests in their upright position when the rear seats are occupied by passengers. Lock the rear seat backrests in their upright position before installing the Top Tether straps or when the cargo compartment is not in use. Make sure that rear seat backrests are secured properly by pushing and pulling on the seat backrests. If the seat backrest is not locked properly, the seat backrest could fold forward. The child restraint system is no longer supported properly or held in position and can no longer fulfill its function. This could cause serious or even fatal injuries.

Top Tether provides an additional connection between a child restraint system, secured with a LATCH-type (ISOFIX) child seat mount, and the rear seat. This helps reduce the risk of injury even further.

The Top Tether anchorages are located on the rear side of the rear seat backrests.





- ▶ Move head restraint (1) upwards.
- ► Install the LATCH-type (ISOFIX) child restraint system with Top Tether. Comply with the manufacturer's installation instructions when doing so.
- ► Route Top Tether belt ⑤ under head restraint ⑥ between the two head restraint bars.
- ► Guide Top Tether belt ⑤ downwards between cargo compartment cover ② and rear seat backrest.
- ▶ Hook Top Tether hook ④ of Top Tether belt
   ⑤ into Top Tether anchorage ③.
   Make sure that:
  - Top Tether hook 4 is hooked into Top Tether anchorage 3 as shown.
  - Top Tether belt (5) is not twisted.
  - Top Tether belt ⑤ is routed between the rear seat backrest and cargo compartment cover ② if cargo compartment cover ② is installed.
  - Top Tether belt ⑤ is routed between the rear seat backrest and the cargo net if the cargo net is installed.
- ► Tension Top Tether belt ⑤. Comply with the manufacturer's installation instructions when doing so.
- ▶ Move head restraint ① back down again slightly if necessary (▷ page 99). Make sure that you do not interfere with the correct routing of Top Tether belt ⑤.



# Child-proof locks

### Important safety notes

### **↑** WARNING

When leaving the vehicle, always remove the SmartKev from the ignition lock. Always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. The children could:

- injure themselves on parts of the vehicle
- · be seriously or fatally injured through excessive exposure to extreme heat or cold
- injure themselves or cause an accident with vehicle equipment that can be operated even if the SmartKey is removed from the ignition lock or removed from the vehicle, such as seat adjustment, steering wheel adjustment, or the memory function

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic. Do not expose the child restraint system to

direct sunlight. The child restraint system's metal parts, for example, could become very hot, and the child could be burned on these parts.

# Child-proof locks for the rear doors



### **↑** WARNING

Children could open a rear door from inside the vehicle. This could result in serious injuries or an accident. Therefore, when children ride in the rear always secure the rear doors with the child-proof locks.

You secure each door individually with the child-proof locks on the rear doors. A door secured with a child-proof lock cannot be opened from inside the vehicle. When the

vehicle is unlocked, the door can be opened from the outside.



- ► To activate: press the child-proof lock lever up in the direction of arrow (1).
- ▶ Make sure that the child-proof locks are working properly.
- ► To deactivate: press the child-proof lock lever down in the direction of arrow (2).

### Override feature for the rear side windows



### **↑** WARNING

When children ride on the vehicle's rear seats, activate the override switch. Otherwise, the children could be injured, e.g. by trapping themselves in the rear side window.



▶ To activate/deactivate: press button ②. If indicator lamp (1) is lit, operation of the rear side windows is disabled. Operation is only possible using the switches in the driver's door. If indicator lamp (1) is off,



operation is possible using the switches in the rear compartment.

# **Driving safety systems**

# Overview of driving safety systems

In this section, you will find information about the following driving safety systems:

- ABS (Anti-lock Braking System)
- BAS (Brake Assist System)
- BAS PLUS (**B**rake **A**ssist **S**ystem Plus)
- ESP® (Electronic Stability Program)
- EBD (**E**lectronic **B**rake force **D**istribution)
- PRE-SAFE® Brake

# Important safety notes

If you fail to adapt your driving style or become distracted, the driving safety systems can neither reduce the risk of accident nor override the laws of physics. Driving safety systems are merely aids designed to assist driving. You are responsible for the distance to the vehicle in front, for vehicle speed and for braking in good time. Always adapt your driving style to suit the prevailing road and weather conditions and maintain a safe distance from the vehicle in front. Drive carefully.

1 The driving safety systems described only work as effectively as possible when there is adequate contact between the tires and the road surface. Please pay special attention to the notes on tires, recommended minimum tire tread depths, etc. (⊳ page 328).

In wintry driving conditions, always use winter tires (M+S tires) and if necessary, snow chains. Only in this way will the driving safety systems described in this section work as effectively as possible.

## ABS (Anti-lock Braking System)

### Important safety notes

1 Observe the "Important safety notes" section (⊳ page 64).



### **↑** WARNING

If ABS is faulty, the wheels could lock when braking. The steerability and braking characteristics may be severely impaired. Additionally, further driving safety systems are deactivated. There is an increased danger of skidding and accidents.

Drive on carefully. Have ABS checked immediately at a qualified specialist workshop.

When ABS is malfunctioning, other systems, including driving safety systems, will also become inoperative. Observe the information on the ABS warning lamp (> page 259) and display messages which may be shown in the instrument cluster (⊳ page 232).

ABS regulates brake pressure in such a way that the wheels do not lock when you brake. This allows you to continue steering the vehicle when braking.

ABS works from a speed of about 5 mph (8 km/h) upwards, regardless of road-surface conditions. ABS works on slippery surfaces, even if you only brake gently.

The yellow ABS warning lamp in the instrument cluster lights up when the ignition is switched on. It goes out when the engine is running.

# **Braking**

- ▶ If ABS intervenes: continue to depress the brake pedal vigorously until the braking situation is over.
- ► To make a full brake application: depress the brake pedal with full force.

If ABS intervenes when braking, you will feel a pulsing in the brake pedal.

The pulsating brake pedal can be an indication of hazardous road conditions, and



functions as a reminder to take extra care while driving.

### **BAS (Brake Assist System)**

1 Observe the "Important safety notes" section (⊳ page 64).

### **↑** WARNING

If BAS is malfunctioning, the braking distance in an emergency braking situation is increased. There is a risk of an accident.

In an emergency braking situation, depress the brake pedal with full force. ABS prevents the wheels from locking.

BAS operates in emergency braking situations. If you depress the brake pedal quickly, BAS automatically boosts the braking force, thus shortening the stopping distance.

► Keep the brake pedal depressed firmly until the emergency braking situation is over. ABS prevents the wheels from locking.

The brakes will function as usual once you release the brake pedal. BAS is deactivated.

# **BAS PLUS (Brake Assist System** PLUS)

 Observe the "Important safety notes" section (⊳ page 64).

BAS PLUS is only available in vehicles equipped with DISTRONIC PLUS.

For BAS PLUS to assist you when driving, the radar sensor system must be:

- activated (> page 229)
- operational

With the help of the radar sensor system, BAS PLUS can detect obstacles that are in the path of your vehicle for an extended period of time.

If the radar sensor system is malfunctioning, BAS PLUS will not be available. The brake system is still available with complete brake boosting effect and BAS.

BAS PLUS provides braking assistance in hazardous situations at speeds greater than 4 mph (7 km/h).

At speeds of up to approximately 40 mph (70 km/h), BAS PLUS can also detect stationary objects. Examples of stationary objects are stopped or parked vehicles.

To prevent a front-end collision, BAS PLUS calculates the brake force necessary if:

- · you approach an obstacle, and
- BAS PLUS has detected a risk of collision.

At a speed less than 20 mph (30 km/h): if you depress the brake pedal, BAS PLUS is activated. Braking is performed as late as possible.

# At a speed greater than 20 mph

(30 km/h): if you depress the brake pedal sharply, BAS PLUS automatically raises the brake pressure to a value adapted to the traffic situation.

► Keep the brake pedal depressed until the emergency braking situation is over. ABS prevents the wheels from locking.

BAS PLUS is deactivated and the brakes function as usual, if:

- you release the brake pedal.
- there is no longer any danger of a rear-end collision.
- no obstacle is detected in front of your vehicle.



### **↑** WARNING

BAS PLUS cannot always clearly identify objects and complex traffic situations. BAS PLUS cannot intervene in these cases. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

In particular, the detection of obstacles can be impaired if there is:

- dirt on the sensors or anything else covering the sensors
- · snow or heavy rain
- interference by other radar sources



- there are strong radar reflections, for example in parking garages
- · a narrow vehicle traveling in front, e.g. a motorbike
- a vehicle traveling in front on a different line relative to the center of your vehicle

# ★ WARNING

BAS PLUS does not react:

- to people or animals
- · to oncoming vehicles
- · to crossing traffic
- · when cornering

As a result, BAS PLUS may not intervene in all critical situations. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

Following damage to the front end of the vehicle, have the configuration and operation of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

# ESP® (Electronic Stability Program)

### General notes

1 Observe the "Important safety notes" section (⊳ page 64).

ESP® monitors driving stability and traction, i.e. power transmission between the tires and the road surface.

If ESP® detects that the vehicle is deviating from the direction desired by the driver, one or more wheels are braked to stabilize the vehicle. The engine output is also modified to keep the vehicle on the desired course within physical limits. ESP® assists the driver when pulling away on wet or slippery roads. ESP® can also stabilize the vehicle during braking.

# ETS/4ETS (Electronic Traction System)

Observe the "Important safety notes" section (⊳ page 64).

ETS/4ETS traction control is part of ESP®.

Traction control brakes the drive wheels individually if they spin. This enables you to pull away and accelerate on slippery surfaces. for example if the road surface is slippery on one side. In addition, more drive torque is transferred to the wheel or wheels with traction.

Traction control remains active, even if you deactivate ESP®.

# Important safety notes

Observe the "Important safety notes" section (⊳ page 64).

# **↑** WARNING

If ESP® is malfunctioning, ESP® is unable to stabilize the vehicle. Additionally, further driving safety systems are deactivated. This increases the risk of skidding and an accident. Drive on carefully. Have ESP® checked at a qualified specialist workshop.

When testing the electric parking brake on a braking dynamometer, switch off the ignition. Application of the brakes by ESP® may otherwise destroy the brake svstem.

Vehicles without 4MATIC: observe the notes on ESP®(⊳ page 322) when towing the vehicle with a raised rear axle

■ Vehicles with 4MATIC: function or performance tests may only be carried out on a 2-axle dynamometer. Before you operate the vehicle on such a dynamometer, please consult a qualified workshop. You could otherwise damage the drive train or the brake system.

ESP® is deactivated if the Ramp warning lamp in the instrument cluster lights up continuously when the engine is running.



If the warning lamp and the warning lamp are lit continuously, ESP® is not available due to a malfunction.

Observe the information on warning lamps (> page 261) and display messages which may be shown in the instrument cluster (> page 232).

① Only use wheels with the recommended tire sizes. Only then will ESP® function properly.

### Characteristics of ESP

### General information

ESP® is activated automatically when the engine is started.

If ESP® intervenes, the SSP® warning lamp flashes in the instrument cluster.

If ESP® intervenes:

- ► Do not deactivate ESP® under any circumstances.
- ▶ Only depress the accelerator pedal as far as necessary when pulling away.
- ► Adapt your driving style to suit the prevailing road and weather conditions.

# Vehicles with the ECO start/stop function

The ECO start/stop function switches the engine off automatically when the vehicle stops moving. The engine starts automatically when the driver wants to pull away again. ESP® remains in its previously selected status. **Example:** if ESP® was deactivated before the engine was switched off, ESP® remains deactivated when the engine is switched on again.

# Deactivating/activating ESP®

### Important safety notes

You can select between the following states of ESP:

- ESP® is activated.
- ESP® is deactivated.

# **↑** WARNING

If you deactivate ESP®, ESP® no longer stabilizes the vehicle. There is an increased risk of skidding and an accident.

Only deactivate ESP® in the situations described in the following.

It may be best to deactivate ESP® in the following situations:

- when using snow chains
- in deep snow
- · on sand or gravel
- 1 Activate ESP® as soon as the situations described above no longer apply. ESP® will otherwise not be able to stabilize the vehicle if the vehicle starts to skid or a wheel starts to spin.

# Deactivating/activating ESP®



- ► To switch off: press button ①.

  The ☐ ESP® OFF warning lamp in the instrument cluster lights up.
- ► To switch on: press button ①.

  The ☐ SSP® OFF warning lamp in the instrument cluster goes out.

### Characteristics when ESP® is deactivated

If ESP® is deactivated and one or more wheels start to spin, the ESP® warning lamp in the instrument cluster flashes. In such situations, ESP® will not stabilize the vehicle.



If you deactivate ESP®:

- ESP® no longer improves driving stability.
- the engine's torque is no longer limited and the drive wheels are able to spin. The spinning of the wheels results in a cutting action, which provides better grip.
- · traction control is still activated.
- ESP® still provides support when you brake.

# Deactivating/activating ESP®

### Important safety notes

You can select between the following statuses of ESP:

- ESP® is activated.
- SPORT handling mode is activated.
- ESP<sup>®</sup> is deactivated.

# **↑** WARNING

When SPORT handling mode is activated, there is a greater risk of skidding and accidents.

Only activate SPORT handling mode in the situations described in the following.

# **↑** WARNING

If you deactivate ESP®, ESP® no longer stabilizes the vehicle. There is an increased risk of skidding and an accident.

Only deactivate ESP® in the situations described in the following.

In the following situations, it may be better to activate SPORT handling mode or deactivate ESP®:

- when using snow chains
- in deep snow
- on sand or gravel
- on designated roads when the vehicle's own oversteering and understeering characteristics are desired

Driving in SPORT handling mode or without ESP® requires an extremely qualified and experienced driver.

Activate ESP® as soon as the situations described above no longer apply. ESP® will otherwise not be able to stabilize the vehicle if the vehicle starts to skid or a wheel starts to spin.

### Deactivating/activating ESP®

► To activate SPORT handling mode: briefly press button (1).

The SPORT SPORT handling mode warning lamp in the instrument cluster lights up. The SPORT handling mode message appears in the multifunction display.

► To deactivate SPORT handling mode: briefly press button (1).

The SPORT SPORT handling mode warning lamp in the instrument cluster goes out.

- ► To deactivate ESP®: press button ① until the ☐ ESP® OFF warning lamp lights up in the instrument cluster.

  The ☐ OFF message appears in the multifunction display.
- ► To activate ESP®: briefly press button ①.

  The □ ESP® OFF warning lamp in the instrument cluster goes out. The □ ESP® ON message appears in the multifunction display.

# Characteristics of activated SPORT handling mode

If SPORT handling mode is activated and one or more wheels start to spin, the ESP® warning lamp in the instrument cluster flashes. ESP® only stabilizes the vehicle to a limited degree.

When SPORT handling mode is activated:

- ESP® only improves driving stability to a limited degree.
- traction control is still activated.
- the engine's torque is restricted to a limited degree and the drive wheels can spin in a



controlled manner. The spinning of the wheels results in a cutting action, which provides better grip.

• ESP® still provides support when you brake.

# Characteristics when ESP® is deactivated

If FSP® is deactivated and one or more wheels start to spin, the ESP® warning lamp in the instrument cluster does not flash. In such situations, ESP® will not stabilize the vehicle. If you deactivate ESP®:

- ESP® no longer improves driving stability.
- the engine's torque is no longer limited and the drive wheels are able to spin without restriction. The spinning of the wheels results in a cutting action, which provides better grip.
- · traction control is still activated.
- PRE-SAFE® Brake is no longer available; nor is it activated if you brake with assistance from FSP®.
- ESP® still provides support when you brake.

### ESP® trailer stabilization

# **↑** WARNING

If road and weather conditions are poor. trailer stabilization will not be able to prevent the vehicle/trailer combination from swerving. Trailers with a high center of gravity can tip over before ESP® can detect this. There is a risk of an accident.

Always adapt your driving style to the prevailing road and weather conditions.

If your vehicle with trailer (vehicle/trailer combination) begins to lurch, you can only stabilize the vehicle/trailer combination by depressing the brake firmly.

In this situation, ESP® assists you and can detect if the vehicle/trailer combination begins to lurch. ESP® slows the vehicle down by braking and limiting the engine output until the vehicle/trailer combination has stabilized.

Trailer stabilization is active above speeds of about 40 mph (65 km/h).

Trailer stabilization does not work if ESP® is deactivated because of a malfunction.

# EBD (electronic brake force distribution)

 Observe the "Important safety notes". section (⊳ page 64).



### **↑** WARNING

If EBD has malfunctioned, the rear wheels can still lock, e.g. under full braking. This increases the risk of skidding and an accident.

You should therefore adapt your driving style to the different handling characteristics. Have the brake system checked at a qualified specialist workshop.

Observe information regarding indicator and warning lamps (⊳ page 259) as well as display messages (⊳ page 233).

EBD monitors and controls the brake pressure on the rear wheels to improve driving stability while braking.

# PRE-SAFE® Brake

1 Observe the "Important safety notes" section (⊳ page 64).

PRE-SAFE® Brake is only available in vehicles with DISTRONIC PLUS.

If PRE-SAFE® Brake is to aid you, the radar sensor system must be:

- activated (> page 229)
- operational

With the help of the radar sensor system, PRE-SAFE® Brake can detect obstacles that are in front of your vehicle for an extended period of time.

PRE-SAFE® Brake can help you to minimize the risk of a collision with a vehicle ahead or



reduce the effects of such a collision. If PRE-SAFE® Brake has detected a risk of collision. you will be warned visually and acoustically as well as by automatic braking. PRE-SAFE® Brake cannot prevent a collision without your intervention.

Starting at a speed of around 4 mph (7 km/h), this function warns you if you very quickly approach a vehicle in front. An intermittent warning tone will then sound and the A distance warning lamp will light up in the instrument cluster.

▶ Brake immediately in order to increase the distance from the vehicle in front.

or

► Take evasive action provided it is safe to do

From a speed of approximately 4 mph (7 km/h), if the driver and front passenger have fastened their seat belts, PRE-SAFE® Brake can brake the vehicle automatically at speeds up to approximately 124 mph (200 km/h).

Due to the nature of the system, particularly complicated driving conditions may cause unnecessary warnings or the unnecessary intervention of PRE-SAFE® Brake.

You can prevent the intervention of the PRE-SAFE® Brake at any time by:

- depressing the accelerator pedal further
- activating kickdown
- releasing the brake pedal

The braking action of PRE-SAFE® Brake is ended automatically if:

- you maneuver to avoid the obstacle.
- there is no longer any danger of a rear-end collision.
- there is no longer an obstacle detected in front of your vehicle.

At speeds of up to approximately 40 mph (70 km/h), PRE-SAFE® Brake can also detect stationary objects. Examples of stationary objects are stopped or parked vehicles.

If you approach an obstacle and PRE-SAFE® Brake detects a risk of a collision, the system will alert you both visually and acoustically. If you do not brake or take evasive action, the system will warn you by automatically braking the vehicle gently. If there is an increased risk of collision, preventative passenger protection measures (PRE-SAFE®) are activated (⊳ page 52). If the risk of collision with the vehicle in front remains and you do not brake, take evasive action or accelerate significantly, automatic braking may be performed up to a level of emergency braking. Automatic emergency braking is not performed until immediately prior to an accident that can no longer be avoided.



# **↑** WARNING

PRE-SAFE® Brake will initially brake your vehicle by a partial application of the brakes if a danger of collision is detected. There may be a collision unless you also brake. Automatic emergency braking cannot prevent a collision. There is a risk of an accident. Always apply the brakes yourself and try to take evasive action.



### ★ WARNING

PRE-SAFE® Brake cannot always clearly identify objects and complex traffic conditions.

In these cases, PRE-SAFE® Brake may:

- give an unnecessary warning and then brake the vehicle
- not give a warning or intervene

There is a risk of an accident.

Always pay particular attention to the traffic situation and be ready to brake, especially if PRE-SAFE® Brake warns you. Terminate the intervention in a non-critical driving situation.

In particular, the detection of obstacles can be impaired if:

- dirt on the sensors or anything else covering the sensors
- snow or heavy rain



- interference by other radar sources
- there are strong radar reflections, for example in parking garages
- a narrow vehicle traveling in front, e.g. a motorbike
- a vehicle traveling in front on a different line relative to the center of your vehicle

### **↑** WARNING

PRE-SAFE® Brake does not react:

- to people or animals
- · to oncoming vehicles
- to crossing traffic
- · when cornering

As a result, PRE-SAFE® Brake may neither give warnings nor intervene in all critical situations. There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.

In order to maintain an appropriate distance from the vehicle in front and thus prevent a collision, you must apply the brakes yourself.

► To activate/deactivate: activate or deactivate PRE-SAFE® Brake in the onboard computer (> page 225).

When PRE-SAFE® Brake is activated, the □!

□!

symbol appears in the multifunction display as long as the HOLD function is deactivated (> page 179).

On vehicles with Parking Guidance, the symbol is displayed when position **P** is engaged or you are driving faster than 22 mph (35 km/h).

Following damage to the front end of the vehicle, have the configuration and operation of the radar sensors checked at a qualified specialist workshop. This also applies to collisions at low speeds where there is no visible damage to the front of the vehicle.

### Theft deterrent locking system

#### **Immobilizer**

The immobilizer prevents your vehicle from being started without the correct SmartKey. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. The engine can be started by anyone with a valid SmartKey that is left inside the vehicle.

- ► To activate with the SmartKey: remove the SmartKey from the ignition lock.
- ► To activate with KEYLESS-GO: switch the ignition off and open the driver's door.
- ▶ To deactivate: switch on the ignition.
- 1 The immobilizer is always deactivated when you start the engine.

In the event that the engine cannot be started when the starter battery is fully charged, the immobilizer may be faulty. Contact an authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes (in the USA) or 1-800-387-0100 (in Canada).

# ATA (anti-theft alarm system)

A visual and audible alarm is triggered if the alarm system is armed and you open:

- a door
- the vehicle with the mechanical key
- · the tailgate
- the hood

The alarm is not switched off, even if you close the open door that triggered it, for example.



- 1 If the alarm stays on for more than 30 seconds, the mbrace emergency call system (USA only) or the Tele Aid system (Canada only) initiates a call to the Customer Assistance Center automatically. The Tele Aid system will initiate the call provided that:
  - you have subscribed to the Tele Aid service.
  - the Tele Aid service has been activated properly.
  - the required mobile phone, power supply and GPS are available.



- ➤ To arm: lock the vehicle with the SmartKey or KEYLESS-GO. Indicator lamp ① flashes. The alarm system is armed after approximately 15 seconds.
- ► To disarm: unlock the vehicle with the SmartKey or KEYLESS-GO.
- ➤ To stop the alarm using the SmartKey: insert the SmartKey into the ignition lock. The alarm is switched off.

or

► Press the or button on the SmartKey.

The alarm is switched off.

➤ To stop the alarm using KEYLESS-GO: grasp the outside door handle. The SmartKey must be outside the vehicle. The alarm is switched off.

or

Press the Start/Stop button on the dashboard. The SmartKey must be inside the vehicle.

The alarm is switched off.



Useful information	74
SmartKey	74
Doors	79
Cargo compartment	82
Side windows	86
Sliding sunroof	89

# **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (⊳ page 27).

# **SmartKey**

### Important safety notes

#### ★ WARNING

If children are left unsupervised in the vehicle, they could:

- · open the doors, thus endangering other people or road users.
- · get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- · shifting the automatic transmission out of park position P
- · Start the engine.

There is a risk of an accident and injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.



#### **↑** WARNING

If persons, particularly children are subjected to prolonged exposure to extreme heat or cold, there is a risk of injury, possibly even fatal. Never leave children unattended in the vehicle.



### **↑** WARNING

If you attach heavy or large objects to the SmartKev, the SmartKev could be unintentionally turned in the ignition lock. This could cause the engine to be switched off. There is a risk of an accident.

Do not attach any heavy or large objects to the SmartKey. Remove any bulky keyrings before inserting the SmartKey into the ignition lock.


- Keep the SmartKey away from strong magnetic fields. Otherwise, the remote control function could be affected.
  - Strong magnetic fields can occur in the vicinity of powerful electrical installations.
- Do not keep the KEYLESS-GO key:
  - with electronic devices, e.g. a mobile phone or another SmartKey
  - with metallic objects, e.g. coins or metal foil
- inside metallic objects e.g. a metal case This can affect the functionality of the SmartKey.

#### **SmartKey functions**

The SmartKey centrally locks/unlocks:

- the doors
- · the tailgate
- the fuel filler flap





- 1) To lock the vehicle
- ② To open/close the tailgate
- 3 To unlock the vehicle

The turn signals flash once when unlocking and three times when locking.

When it is dark, the surround lighting also comes on if it is activated in the on-board computer (> page 227).

You can also set an audible signal to confirm that the vehicle has been locked. The audible signal can be activated and deactivated using the on-board computer (> page 228).

► To unlock centrally: press the button.

If you do not open the vehicle within approximately 40 seconds of unlocking:

- the vehicle is locked again.
- the theft deterrent locking system is armed again.
- ▶ To lock centrally: press the 🕡 button.

#### **KEYLESS-GO**

#### **General notes**

Bear in mind that the engine can be started by any of the vehicle occupants if there is a KEYLESS-GO key in the vehicle.

# Locking/unlocking centrally


You can start, lock or unlock the vehicle using KEYLESS-GO. To do this, you only need carry the SmartKey with you. You can combine the

functions of KEYLESS-GO with those of a conventional SmartKey. Unlock the vehicle by using KEYLESS-GO, for instance, and lock it using the button on the SmartKey.

When locking or unlocking with KEYLESS-GO, the distance between the SmartKey and the corresponding door handle must not be greater than 3 ft (1 m).

KEYLESS-GO checks whether a valid SmartKey is in the vehicle by periodically establishing a radio connection between the vehicle and the SmartKey. This happens:

- when the external door handles are touched
- · when starting the engine
- while the vehicle is in motion



- ► To unlock the vehicle: touch the inner surface of the door handle.
- ► To lock the vehicle: touch sensor surface (1).
- ► Convenience closing feature: touch recessed sensor surface ② for an extended period.

Further information on the convenience closing feature (⊳ page 88).

If you pull on the handle of the tailgate, only the cargo compartment of the vehicle is unlocked.

# Changing the settings of the locking system

You can change the settings of the locking system. This means that only the driver's door



and the fuel filler flap are unlocked when the vehicle is unlocked. This is useful if you frequently travel on your own.

- ▶ To change the setting: press and hold down the 🕡 and 🔒 buttons simultaneously for approximately six seconds until the battery check lamp (⊳ page 77) flashes twice.
- 1 If the setting of the locking system is changed within the signal range of the vehicle, pressing the 🕡 or 🕠 button:
  - · locks or
  - unlocks the vehicle

The SmartKev now functions as follows:

- ▶ To unlock the driver's door: press the button once.
- ► To unlock centrally: press the button twice.
- ▶ To lock centrally: press the 🔒 button.

The KEYLESS-GO function is changed as follows:

- ▶ To unlock the driver's door: touch the inner surface of the door handle on the driver's door.
- ▶ To unlock centrally: touch the inner surface of the door handle on the frontpassenger door or the rear door.
- ▶ To lock centrally: touch the outer sensor surface on one of the door handles (⊳ page 75).
- ▶ To restore the factory settings: press and hold down the and buttons simultaneously for approximately six seconds until the battery check lamp flashes twice.

# Mechanical key

#### General notes

If the vehicle can no longer be locked or unlocked with the SmartKey or the KEYLESS-GO key, use the mechanical key.

If you use the mechanical key to unlock and open the driver's door, the anti-theft alarm system will be triggered (⊳ page 71).

- ▶ To end the alarm: insert the SmartKey into the ignition lock.
- **1** With KEYLESS-GO: remove the Start / Stop button from the ignition lock beforehand.

If you unlock the vehicle using the mechanical key, the fuel filler flap will not be unlocked automatically.

# Removing the mechanical key



▶ Push release catch (1) in the direction of the arrow and at the same time remove mechanical key (2) from the SmartKey.

# SmartKey battery

# Important safety notes

Mercedes-Benz recommends that you have the batteries replaced at a qualified specialist workshop.



#### **↑** WARNING

Batteries contain toxic and corrosive substances. If batteries are swallowed, it can result in severe health problems. There is a risk of fatal injury.

Keep batteries out of the reach of children. If a battery is swallowed, seek medical attention immediately.



#### Checking the battery



- ▶ Press the or button. The battery is working properly if battery check lamp lights up briefly. If battery check lamp does not light up briefly during the test, the battery is discharged.
- 1 If the SmartKey battery is checked within the signal reception range of the vehicle, pressing the or button:
  - locks or
  - · unlocks the vehicle
- ► Change the battery (> page 77).
- 1 You can get a battery at a qualified specialist workshop.


# Replacing the battery

You require a CR 2025 3 V cell battery.

► Take the mechanical key out of the SmartKey (> page 76).



- ▶ Press mechanical key ② into the SmartKey opening in the direction of the arrow until battery compartment cover ① opens. Do not hold battery compartment cover ① closed while doing so.
- ▶ Remove battery compartment cover ①.



- ► Repeatedly tap the SmartKey against your palm until battery (3) falls out.
- ► Insert the new battery with the positive terminal facing upwards. Use a lint-free cloth to do so.
- ► Make sure that the surface of the battery is free from lint, grease and all other forms of contamination.
- ► Insert the front tabs of battery compartment cover ① into the housing first and then press to close it.
- ► Insert mechanical key ② into the SmartKey.
- ► Check the function of all SmartKey buttons on the vehicle.



Problem	s with	the	Smart	Key
---------	--------	-----	-------	-----

Problem	Possible causes/consequences and ▶ Solutions
You cannot lock or unlock the vehicle using the SmartKey.	The SmartKey battery is discharged or nearly discharged.  ▶ Try again to lock/unlock the vehicle using the remote control function of the SmartKey. Point the tip of the SmartKey at the driver's door handle from close range and press the  or button.  If this does not work:  ▶ Check the SmartKey battery (▷ page 77) and replace it if necessary (▷ page 77).  ▶ Lock (▷ page 81) or unlock (▷ page 81) the vehicle using the mechanical key.
	The SmartKey is faulty.  ► Lock (> page 81) or unlock (> page 81) the vehicle using the mechanical key.  ► Have the SmartKey checked at a qualified specialist workshop.
You can no longer lock or unlock the vehicle using KEYLESS-GO.	<ul> <li>KEYLESS-GO is in standby mode because the vehicle has not been unlocked for a long time.</li> <li>▶ Pull the door handle and then turn the SmartKey to position 2 in the ignition lock.</li> </ul>
	There is interference from a powerful source of radio waves.  ▶ Lock/unlock the vehicle using the remote control function of the SmartKey. Point the tip of the SmartKey at the driver's door handle from close range and press the
	<ul> <li>There is a malfunction with KEYLESS-GO.</li> <li>▶ Lock/unlock the vehicle using the remote control function of the SmartKey. Point the tip of the SmartKey at the driver's door handle from close range and press the or or button.</li> <li>▶ Have KEYLESS-GO checked at a qualified specialist workshop.</li> <li>If this does not work:</li> <li>▶ Check the SmartKey battery (▷ page 77) and replace it if necessary (▷ page 77).</li> <li>▶ Lock (▷ page 81) or unlock (▷ page 81) the vehicle using the mechanical key.</li> </ul>
You have lost a SmartKey.	<ul> <li>► Have the SmartKey deactivated at a qualified specialist workshop.</li> <li>► Report the loss immediately to the vehicle insurers.</li> <li>► If necessary, have the locks changed as well.</li> </ul>



	Problem	Possible causes/consequences and ▶ Solutions
	You have lost the mechanical key.	<ul> <li>Report the loss immediately to the vehicle insurers.</li> <li>If necessary, have the locks changed as well.</li> </ul>
	The engine cannot be started using the SmartKey.	The on-board voltage is too low.  ► Switch off non-essential consumers, e.g. seat heating or interior lighting, and try to start the engine again.  If this does not work:  ► Check the starter battery and charge it if necessary (> page 314).  or  ► Jump-start the vehicle (> page 318).  or  ► Consult a qualified specialist workshop.
	The engine cannot be started using KEYLESS-GO. The SmartKey is in the vehicle.	A door is open. Therefore, the SmartKey cannot be detected as easily.  ▶ Close the door and try to start the vehicle again.
		There is interference from a powerful source of radio waves.  Start your vehicle with the SmartKey in the ignition lock.

#### **Doors**

# Important safety notes



#### **↑** WARNING

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- · get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shifting the automatic transmission out of park position P
- · Start the engine.

There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.



#### **↑** WARNING

If persons, particularly children are subjected to prolonged exposure to extreme heat or cold, there is a risk of injury, possibly even fatal. Never leave children unattended in the vehicle.

# Unlocking and opening doors from the inside

You can open a door from inside the vehicle even if it has been locked. You can only open the rear doors from inside the vehicle if they are not secured by the child-proof locks (⊳ page 63).

Only open the door when the traffic situation permits.



If the vehicle has been locked with the SmartKey or with KEYLESS-GO, opening a door from the inside will trigger the anti-theft alarm system. Switch off the alarm (> page 71).



➤ To unlock a front door: pull door handle ②.

Locking knob ① pops up.

The door is unlocked and can be opened.

- ► To open a front door: pull door handle ②.
- ► To unlock a rear door: pull up locking knob ①.

The door is unlocked and can be opened.

► To open a rear door: pull door handle ②.

# Centrally locking and unlocking the vehicle from the inside

You can centrally lock or unlock the vehicle from the inside.

You cannot unlock the vehicle centrally from the inside if the vehicle has been locked with the SmartKey or KEYLESS-GO.



- ▶ To unlock: press button ①.
- ➤ To lock: press button ②.

  If the front-passenger door is closed, the vehicle locks.

Meanwhile, the fuel filler flap will not be locked or unlocked.

Only open the door when the traffic situation permits.

If the vehicle was previously locked with the SmartKey or with KEYLESS-GO, opening the vehicle from the inside will activate the antitheft alarm system. Switch off the alarm ( $\triangleright$  page 71).

If the vehicle has been locked using the locking button for the central locking, or has been locked automatically, and a door is opened from the inside:

- the vehicle will be fully unlocked if it had previously been fully unlocked
- only the door which has been opened form the inside is unlocked if only the driver's door had been previously unlocked

If the vehicle has been locked centrally with the SmartKey or with KEYLESS-GO, it is not unlocked when the release button for the central locking is used.


# **Automatic locking feature**

The vehicle is locked automatically when the ignition is switched on and the vehicle's wheels are turning at a speed in excess of 9 mph (15 km/h).



You could therefore be locked out if:

- the vehicle is being pushed.
- the vehicle is being towed.
- the vehicle is on a roller dynamometer.



- ► To deactivate: press and hold button ①
  for about five seconds until a tone sounds.
- ► To activate: press and hold button ② for about five seconds until a tone sounds.
- 1 If you press one of the two buttons and do not hear a tone, the relevant setting has already been selected.

You can also switch the automatic locking function on and off using the on-board computer (> page 228).

# Unlocking the driver's door (mechanical key)

If the vehicle can no longer be unlocked with the SmartKey, use the mechanical key.

If you use the mechanical key to unlock and open the driver's door, the anti-theft alarm system will be triggered (▷ page 71).

- ► Take the mechanical key out of the SmartKey (> page 76).
- ► Insert the mechanical key into the lock of the driver's door as far as it will go.



- ► Turn the mechanical key counter-clockwise to position 1.
  - The door is unlocked.
- Turn the mechanical key back and remove it.
- ► Insert the mechanical key into the SmartKey.

# Locking the vehicle (mechanical key)

If the vehicle can no longer be locked with the SmartKey, use the mechanical key.

- ▶ Open the driver's door.
- ► Close the front-passenger door, the rear doors and the tailgate.
- ▶ Press the locking button (> page 80).
- ► Check whether the locking knobs on the front-passenger door and the rear doors are still visible. Press down the locking knobs manually, if necessary (> page 79).
- ► Close the driver's door.
- ► Take the mechanical key out of the SmartKey (> page 76).
- ► Insert the mechanical key into the lock of the driver's door as far as it will go.





- ► Turn the mechanical key clockwise as far as it will go to position 1.
- ► Turn the mechanical key back and remove it.
- Make sure that the doors and the tailgate are locked.
- ► Insert the mechanical key into the SmartKey.
- 1 If you lock the vehicle as described above, the fuel filler flap is not locked. The antitheft alarm system is not armed.

### Cargo compartment

# Important safety notes

# **⚠ WARNING**

If persons, particularly children are subjected to prolonged exposure to extreme heat or cold, there is a risk of injury, possibly even fatal. Never leave children unattended in the vehicle.

# **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. If the tailgate is open when the engine is running, particularly if the vehicle is moving, exhaust fumes could enter the passenger compartment. There is a risk of poisoning. Turn off the engine before opening the tailgate. Never drive with the tailgate open.

I The tailgate swings upwards and to the rear when opened. Therefore, make sure

that there is sufficient clearance above and behind the tailgate.

1 Tailgate opening dimensions(▷ page 373).

You should preferably place luggage or loads in the cargo compartment. Observe the loading guidelines (> page 270).

Do not leave the SmartKey in the cargo compartment. You could otherwise lock yourself out.

# Vehicles without the EASY-PACK tailgate: the tailgate can be:

- · opened and closed manually from outside
- unlocked from inside with the mechanical key

# For vehicles with the EASY-PACK tailgate you can:

- open and close the tailgate manually from outside
- open and close the tailgate automatically from outside
- open and close the tailgate automatically from inside
- limit the opening angle of the tailgate
- unlock the tailgate from inside with the mechanical key

# Opening/closing from outside

# **Opening**

▶ Press the button on the SmartKey.





- ▶ Pull handle ①.
- ► Raise the tailgate.

Vehicles with the EASY-PACK tailgate: if you pull handle (1) and keep it in this position, you can open the tailgate manually. If you release the handle, the tailgate opens automatically.

#### Closing



- ▶ Pull the tailgate down using recess (1).
- ▶ Push the tailgate closed from outside the vehicle.
- ▶ If necessary, lock the vehicle with the button on the SmartKey (⊳ page 74) or with KEYLESS-GO (⊳ page 75).
- 1 If a KEYLESS-GO key is detected in the cargo compartment, the tailgate will not lock.

## Opening/closing automatically from outside

# Important safety notes



# **↑** WARNING

Parts of the body could become trapped during automatic closing of the tailgate. Moreover, people, e.g. children, may be standing in the closing area or may enter the closing area during the closing process. There is a risk of injury.

Make sure that nobody is in the vicinity of the closing area during the closing process.

Use one of the following options to stop the closing process:

- press the \( \) button on the SmartKey.
- press the remote operating switch on the driver's door.
- press the closing or locking button on the tailgate.
- pull the handle on the tailgate.



#### **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. If the tailgate is open when the engine is running, particularly if the vehicle is moving, exhaust fumes could enter the passenger compartment. There is a risk of poisoning. Turn off the engine before opening the tailgate. Never drive with the tailgate open.

- I The tailgate swings upwards and to the rear when opened. Therefore, make sure that there is sufficient clearance above and behind the tailgate.
- 1 Tailgate opening dimensions (⊳ page 373).

# Opening

You can open the tailgate automatically with the SmartKey or the handle in the tailgate. Open or close the tailgate fully using the automatic door function if you have stopped the tailgate in an intermediate position.

▶ Press and hold the 💢 button on the SmartKey until the tailgate opens.

or

- ▶ If the tailgate is unlocked, pull the handle and let it go again immediately.
- 1 You can also close the tailgate manually if it is fully opened.
- If you have opened the tailgate automatically, you should wait a moment before closing the tailgate manually.



#### Closing



#### **↑** WARNING

Parts of the body could become trapped during automatic closing of the tailgate. Moreover, people, e.g. children, may be standing in the closing area or may enter the closing area during the closing process. There is a risk of injury.

Make sure that nobody is in the vicinity of the closing area during the closing process.

Use one of the following options to stop the closing process:

- press the [3] button on the SmartKey.
- press the remote operating switch on the driver's door.
- press the closing or locking button on the tailgate.
- pull the handle on the tailgate.

You can close the tailgate automatically using the SmartKey, the closing button<sup>2</sup> or the locking button<sup>3</sup>.



Closing and locking button (example: vehicle with EASY-PACK tailgate and KEYLESS-GO)

▶ To close: press closing button (1) on the tailgate.

or

- ▶ Press and hold the 💢 button on the SmartKey until the tailgate closes.
- ▶ To close and lock simultaneously: Press locking button (2) on the tailgate.

- 1 The tailgate can only be opened and closed with the SmartKey if it is not in the ignition lock.
  - If the tailgate touches an object while closing, the closing procedure is interrupted and the tailgate reopens.
- 1 If you leave a KEYLESS-GO key in the cargo compartment, the tailgate will not lock.

The tailgate is not closed unless a KEYLESS-GO key is detected.

### Opening/closing automatically from inside



#### **↑** WARNING

Parts of the body could become trapped during automatic closing of the tailgate. Moreover, people, e.g. children, may be standing in the closing area or may enter the closing area during the closing process. There is a risk of injury.

Make sure that nobody is in the vicinity of the closing area during the closing process.

Use one of the following options to stop the closing process:

- press the \( \sum \) button on the SmartKey.
- press the remote operating switch on the driver's door.
- press the closing or locking button on the tailgate.
- pull the handle on the tailgate.



#### **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. If the tailgate is open when the engine is running, particularly if the vehicle is moving, exhaust fumes could enter the passenger compartment. There is a risk of poisoning. Turn off the engine before opening the

tailgate. Never drive with the tailgate open.

- <sup>2</sup> For vehicles with the EASY-PACK tailgate only.
- <sup>3</sup> For vehicles with the EASY-PACK tailgate and KEYLESS-GO only.



- The tailgate swings upwards and to the rear when opened. Therefore, make sure that there is sufficient clearance above and behind the tailgate.
- i Tailgate opening dimensions (> page 373).

You can open and close the tailgate from the driver's seat when the vehicle is stationary and unlocked.



- ► **To open:** pull remote operating switch ① for the tailgate until the tailgate opens.
- ► To close: turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Press remote operating switch for tailgate ① until the tailgate is closed. You hear a tone during the closing procedure.

# Limiting the opening angle of the tailgate

# Important safety notes

You can limit the opening angle of the tailgate. This is possible in the top half of its opening range, up to approximately 8 in (20 cm) before the stop.

This could be useful, for example, if there is insufficient space above the tailgate.

Make sure there is sufficient clearance to open the tailgate fully when setting the opening angle. The tailgate could otherwise be damaged. Ideally, set the opening angle outside.

#### **Activating**

- ► To open the tailgate: pull the handle on the tailgate.
- ➤ To stop the opening procedure at the desired position: press the closing button (> page 83) in the tailgate or pull the handle on the outside of the tailgate again.
- ➤ To store the position: press and hold the closing button in the tailgate until you hear a short tone.
  - The opening angle limiter is activated. The tailgate will now stop in the stored position when opening.
- 1 To open the tailgate fully, pull the handle on the outside of the tailgate again after it has stopped automatically. This does not delete the stored position.

#### Deactivating

Press and hold the closing button (▷ page 83) in the tailgate until you hear two short tones.

# Tailgate emergency release

# Important safety notes


■ The tailgate swings upwards and to the rear when opened. Therefore, make sure that there is sufficient clearance above and behind the tailgate.

If the tailgate can no longer be opened from outside the vehicle, use the emergency release on the inside of the tailgate.

1 Tailgate opening dimensions(▷ page 373).



#### **Opening**



- ▶ Take the mechanical key out of the SmartKey (⊳ page 76).
- ▶ Insert mechanical key ② into the opening in paneling (1).
- ► Turn mechanical key (2)90° clockwise.
- ▶ Push mechanical key (2) in the direction of the arrow and open the tailgate.

#### Side windows

### Important safety notes

#### **↑** WARNING

While opening the side windows, body parts could become trapped between the side window and the door frame as the side window moves. There is a risk of injury. Make sure that nobody touches the side window during the opening procedure. If somebody becomes trapped, release the switch or pull the switch to close the side

# **MARNING**

window again.

While opening the side windows, body parts in the closing area could become trapped. There is a risk of injury.

Make sure that no body parts are in close proximity during the closing procedure. If somebody becomes trapped, release the switch or press the switch down to open the side window again.

### **↑** WARNING

If children operate the side windows they could become trapped, particularly if they are left unsupervised. There is a risk of injury.

Activate the override feature for the rear side windows. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

#### **↑** WARNING

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shifting the automatic transmission out of park position P
- · Start the engine.

There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

# Side window reversing feature

The side windows are equipped with an automatic reversing feature. If a solid object blocks or restricts a side window during the closing process, the side window opens again automatically. However, the automatic reversing feature is only an aid and does not relieve you of the responsibility of paying attention when closing a side window.



#### **↑** WARNING


The reversing feature does not react:

- to soft, light and thin objects, e.g. small fingers
- over the last 4 mm of the closing movement
- · during resetting
- when closing the side window again manually immediately after automatic reversing

This means that the reversing feature cannot prevent someone being trapped in these situations. There is a risk of injury.

Make sure that no body parts are in close proximity during the closing procedure. If someone becomes trapped, press the switch to open the side window again.

### Opening and closing the side windows



- Front left
- (2) Front right
- (3) Rear right
- (4) Rear left

The switches for all side windows are located on the driver's door. There is also a switch on each door for the corresponding side window.

The switches on the driver's door take precedence.

1 The side windows cannot be operated from the rear when the override feature for the side windows is activated (▷ page 63).

- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ **To open:** press the corresponding switch.
- ▶ **To close:** pull the corresponding switch.
- 1 If you press the switch beyond the point of resistance, an automatic opening/ closing process is started in the corresponding direction. You can stop automatic operation by operating the switch again.
- 1 You can continue to operate the side windows after you switch off the engine or remove the SmartKey. This function is available for up to five minutes or until the driver's or front-passenger door is opened.

# Convenience opening

You can ventilate the vehicle before you start driving. To do this, the SmartKey is used to carry out the following functions simultaneously:

- · unlock the vehicle
- open the side windows
- open the panorama roof with power tilt/ sliding panel and the roller sunblinds
- 1 The convenience opening feature can only be operated using the SmartKey. The SmartKey must be close to the driver's door handle.
- ▶ Point the tip of the SmartKey at the driver's door handle.
- ▶ Press and hold the 🔐 button until the side windows and the panorama roof with power tilt/sliding panel are in the desired position.

If the roller sunblinds of the panorama roof with power tilt/sliding panel are closed, the roller sunblinds are opened first.



- ▶ Press and hold the button again until the panorama roof with power tilt/sliding panel is in the desired position.
- ► To interrupt convenience opening: release the button.

### Convenience closing feature

#### General notes

When you lock the vehicle, you can simultaneously:

- · close the side windows
- close the panorama roof with power tilt/ sliding panel

On vehicles with a panorama roof with power tilt/sliding panel, you can then close the roller sunblinds.

# **↑** WARNING

When the convenience closing feature is operating, parts of the body could become trapped in the closing area of the side window and the sliding sunroof. There is a risk of injury.

Observe the complete closing procedure when the convenience closing feature is operating. Make sure that no body parts are in close proximity during the closing procedure.

Proceed as follows if someone is trapped: With the SmartKey:

- release the 🕞 button.
- press and hold the button until the side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel open again.

# Using KEYLESS-GO:

- release the sensor surface on the door handle.
- pull the door handle immediately and hold it.

The side windows and the sliding sunroof or the panorama roof with power tilt/sliding panel open.

### **Using the SmartKey**


- 1 The SmartKey must be close to the driver's door handle.
- Point the tip of the SmartKey at the driver's door handle.
- Press and hold the button until the side windows and the panorama roof with power tilt/sliding panel are fully closed.
- Make sure that all the side windows and the panorama roof with power tilt/sliding panel are closed.

On vehicles with a panorama roof with power tilt/sliding panel:

- ▶ Press and hold the button again until the roller sunblinds of the panorama roof with power tilt/sliding panel close.
- ► To interrupt convenience closing: release the button.

#### Using KEYLESS-GO

The KEYLESS-GO key must be outside the vehicle. All the doors must be closed.



► Touch recessed sensor surface ① on the door handle until the side windows and the



panorama roof with power tilt/sliding panel are fully closed.

- Make sure you only touch recessed sensor surface (1).
- ► Make sure that all the side windows and the panorama roof with power tilt/sliding panel are closed.

On vehicles with a panorama roof with power tilt/sliding panel:

- ► Touch recessed sensor surface (1) on the door handle again until the roller sunblinds of the panorama roof with power tilt/ sliding panel close.
- ▶ To interrupt convenience closing: release recessed sensor surface (1) on the door handle.

### Resetting the side windows

You must reset each side window if a side window can no longer be closed fully.

- Close all the doors.
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Pull the corresponding switch on the door control panel until the side window is completely closed (⊳ page 87).
- ▶ Hold the switch for an additional second.

If the side window opens again slightly:

- ▶ Immediately pull the corresponding switch on the door control panel until the side window is completely closed (⊳ page 87).
- ▶ Hold the switch for an additional second.
- ▶ If the corresponding side window remains closed after the button has been released, the side window has been reset correctly. If this is not the case, repeat the steps above again.

#### Problems with the side windows

Problem: a side window cannot be closed because it is blocked by objects, e.g. leaves in the window guide.

- ▶ Remove the objects.
- Close the side window.

Problem: a side window cannot be closed and you cannot see the cause.



#### **↑** WARNING

If you close a side window again immediately after it has been blocked or reset, the side window closes with increased or maximum. force. The reversing feature is then not active. Parts of the body could be trapped in the closing area in the process. This poses an increased risk of injury or even fatal injury.

Make sure that no parts of the body are in the closing area. To stop the closing process, release the switch or push the switch again to reopen the side window.

If a side window is obstructed during closing and reopens again slightly:

▶ Immediately after the window blocks, pull the corresponding switch again until the side window has closed.

The side window is closed with increased force.

If a side window is obstructed again during closing and reopens again slightly:

► Immediately after the window blocks, pull the corresponding switch again until the side window has closed.

The side window is closed without the antientrapment feature.

# Sliding sunroof

# Important safety notes

In the following section, the term "sliding sunroof" refers to the panorama roof with power tilt/sliding panel.



### **↑** WARNING

While opening and closing the sliding sunroof, body parts in close proximity could become trapped. There is a risk of injury.

Make sure that no body parts are in close proximity during the opening and closing procedures.

If somebody becomes trapped:

- release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The opening or closing procedure will be stopped.

#### **↑** WARNING

If children operate the sliding sunroof they could become trapped, particularly if they are left unsupervised. There is a risk of injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

I Only open the sliding sunroof if it is free of snow and ice. Otherwise, malfunctions may occur.

Do not allow anything to protrude from the sliding sunroof. Otherwise, the seals could be damaged.

- I The weather can change abruptly. It could start to rain or snow. Make sure that the sliding sunroof is closed when you leave the vehicle. The vehicle electronics can be damaged if water enters the vehicle interior
- Resonance noises can occur in addition to the usual airflow noises when the sliding sunroof is open. They are caused by minor pressure fluctuations in the vehicle interior. Change the position of the sliding sunroof or open a side window slightly to reduce or eliminate these noises.

# Sliding sunroof reversing feature

The sliding sunroof is equipped with an automatic reversing feature. If a solid object blocks or restricts the sliding sunroof during the closing process, the sliding sunroof opens again automatically. However, the automatic reversing feature is only an aid and does not relieve you of the responsibility of paying attention when closing the sliding sunroof.



#### **↑** WARNING

The reversing feature does not react:

- to soft, light and thin objects, e.g. small fingers
- over the last 4 mm of the closing movement
- · during resetting
- · when closing the sliding sunroof again manually immediately after automatic reversing

This means that the reversing feature cannot prevent someone being trapped in these situations. There is a risk of injury.

Make sure that no body parts are in close proximity during the closing procedure.


If somebody becomes trapped:

- · release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The closing process is stopped.



# Operating the sliding sunroof



Overhead control panel

- (1) To raise
- ② To open
- ③ To close/lower

The sliding sunroof can only be operated when the roller sunblinds are open.

- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Press or pull the switch in the corresponding direction.
- 1 If you press the switch beyond the point of resistance, an automatic opening/ closing process is started in the corresponding direction. You can stop automatic operation by operating the switch again.

The automatic raising feature is available only when the sliding sunroof is closed.

# Operating the roller sunblinds for the sliding sunroof

#### General notes

The roller sunblinds shield the vehicle interior from sunlight. The two roller sunblinds can only be opened and closed together when the sliding sunroof is closed.

#### ★ WARNING

When opening or closing the roller sunblind, parts of the body could be trapped between

the roller sunblind and the frame or sliding sunroof. There is a risk of injury.

When opening or closing make sure that no parts of the body are in the sweep of the roller sunblind.

If somebody becomes trapped:

- release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The opening or closing procedure will be stopped.

### Roller sunblind reversing feature

The roller sunblinds are equipped with an automatic reversing feature. If an object blocks or restricts the roller sunblind during the closing process, the roller sunblind opens again automatically. However, the automatic reversing feature is only an aid and does not relieve you of the responsibility of paying attention when closing the roller sunblinds.



### **↑** WARNING

The reversing feature does not react:

- to soft, light and thin objects, e.g. small fingers
- · when closing the roller sunblind again manually immediately after automatic reversing

This means that the reversing feature cannot prevent someone being trapped in these situations. There is a risk of injury.


When closing make sure that no parts of the body are in the sweep of the roller sunblind. If somebody becomes trapped:

- · release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The closing process is stopped.



#### Opening and closing



Overhead control panel

- 1) To open
- 2 To open
- ③ To close
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Press or pull the switch in the corresponding direction.
- 1 If you press the switch beyond the point of resistance, an automatic opening/ closing process is started in the corresponding direction. You can stop automatic operation by operating the switch again.

#### Resetting the sliding sunroof and the roller sunblinds

Reset the sliding sunroof and the roller sunblinds if the sliding sunroof or the roller sunblinds do not move smoothly.

- ▶ Turn the SmartKey to position 1 or 2 in the ignition lock.
- ▶ Press the button to the point of resistance in the direction of arrow (2) until the sliding sunroof is open approximately 4 in (10 cm).
- ▶ Pull the switch repeatedly to the point of resistance in the direction of arrow (3) until the sliding sunroof is fully closed.
- ► Keep the switch pulled for an additional second.

- ▶ Press the button to the point of resistance in the direction of arrow (2) until the roller sunblinds are open approximately 4 in (10 cm).
- ▶ Pull the switch repeatedly to the point of resistance in the direction of arrow (3) until the roller sunblinds are fully closed.
- ► Keep the switch pulled for an additional second.
- ▶ Make sure that the sliding sunroof and the roller sunblinds can be fully opened and closed again (⊳ page 91).
- ▶ If this is not the case, repeat the steps above again.
- If the sliding sunroof and the roller sunblinds cannot be fully opened or closed after resetting, contact a qualified specialist workshop.

#### Problems with the sliding sunroof

Problem: the sunroof cannot be closed and you cannot see the cause.

#### **↑** WARNING

If you close the sliding sunroof again immediately after it has been blocked or reset, the sliding sunroof closes with increased or maximum force. The reversing feature is then not active. Parts of the body could be trapped in the closing area in the process. This poses an increased risk of injury or even fatal injury.

Make sure that no parts of the body are in the closing area.

If somebody becomes trapped:

- release the switch immediately, or
- during automatic operation, push the switch briefly in any direction

The closing process is stopped.



If the sliding sunroof is obstructed during closing and reopens again slightly:

► Immediately after the sliding sunroof blocks, pull the switch in the overhead control panel down to the point of resistance and hold it until the sliding sunroof is closed. The sliding sunroof is closed with increased

force.

If the sliding sunroof is obstructed again during closing and then reopens slightly:

- ▶ Immediately after the sliding sunroof blocks, pull the switch in the overhead control panel down to the point of resistance and hold it until the sliding sunroof is closed.
  - The sliding sunroof is closed without the anti-entrapment feature.
- If the sliding sunroof still cannot be opened or closed as a result of a malfunction, contact a qualified specialist workshop.





Useful information	. 9	
Correct driver's seat position		
Seats	. 9	
Steering wheel	10	
Mirrors	10	
Memory function	10	

# **Useful information**

- i) This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- ① Read the information on qualified specialist workshops: (▷ page 27).

# Correct driver's seat position



- ► Observe the safety guidelines on seat adjustment (> page 97).
- ► Make sure that seat ③ is adjusted properly.

Electrical seat adjustment (> page 98) When adjusting the seat, make sure that:

- you are as far away from the driver's air bag
- you are sitting in a normal upright position.
- you can fasten the seat belt properly.

as possible.

- you have moved the backrest to an almost vertical position.
- you have set the seat cushion angle so that your thighs are gently supported.
- you can depress the pedals properly.
- ► Check whether the head restraint is adjusted properly.
  - When doing so, make sure that you have adjusted the head restraint so that the back of your head is supported at eye level by the center of the head restraint.
- ➤ Observe the safety guidelines on steering wheel adjustment (> page 102).
- ► Make sure that steering wheel ① is adjusted properly.

Adjusting the steering wheel manually (> page 102)

Adjusting the steering wheel electrically (> page 102)

When adjusting the steering wheel, make sure that:

- you can hold the steering wheel with your arms slightly bent.
- you can move your legs freely.
- you can see all the displays in the instrument cluster clearly.
- Observe the safety guidelines for seat belts (▷ page 54).
- ► Check whether you have fastened the seat belt ② properly (> page 56).

The seat belt should:

- fit snugly across your body
- be routed across the middle of your shoulder
- be routed in your pelvic area across the hip joints
- ▶ Before starting off, adjust the rear-view mirror and the exterior mirrors in such a way that you have a good view of road and traffic conditions (▷ page 103).
- ► Vehicles with a memory function: save the seat, steering wheel and exterior mirror



settings with the memory function (⊳ page 106).

#### **Seats**

#### Important safety notes



#### **↑** WARNING

The seats can still be adjusted when there is no key in the ignition lock. For this reason, children should never be left unsupervised in the vehicle. They could otherwise become trapped when adjusting the seat.

#### **↑** WARNING

Make sure that the back of your head is supported at eye level by the central area of the head restraint. If your head is not supported correctly by the head restraint, you could suffer a severe neck injury in the event of an accident. Never drive if the head restraints are not engaged and set correctly.

#### **↑** WARNING

In order to avoid possible loss of vehicle control, all seat, head restraint, steering wheel and rear view mirror adjustments, as well as fastening of seat belts, must be done before setting the vehicle in motion.



#### **↑** WARNING

Do not adjust the driver's seat while driving. Adjusting the seat while driving could cause the driver to lose control of the vehicle.

Never travel in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the seat belt would apply force at the abdomen or neck. This could cause serious or fatal injuries. The seat backrest and seat belts provide the best restraint when the wearer is in a position that is as upright as possible and seat belts are properly positioned on the body.

#### **↑** WARNING

Your seat belt must be adjusted so that you can correctly fasten your seat belt.

Observe the following points:

- adjust the seat backrest until your arms are slightly angled when holding the steering wheel.
- adjust the seat to a comfortable seating position that still allows you to reach the accelerator/brake pedal safely. The position should be as far back as possible with the driver still able to operate the controls properly.
- · adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level.
- never place hands under the seat or near any moving parts while a seat is being adjusted.

Failure to do so could result in an accident and/or serious personal injury.



#### **↑** WARNING

According to accident statistics, children are safer when properly restrained on the rear seats than on the front-passenger seat. Thus, we strongly recommend that children be placed in the rear seat whenever possible. Regardless of seating position, children 12 vears old and under must be seated and properly secured in an appropriately sized child restraint system or booster seat recommended for the size and weight of the child. For additional information, see the "Children in the vehicle" section.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.



### **↑** WARNING

For your protection, drive only with properly positioned head restraints.



Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.

Do not drive the vehicle without the seat head restraints. Head restraints are intended to help reduce injuries during an accident.

- To avoid damage to the seats and the seat heating, observe the following information:
  - keep liquids from spilling on the seats. If liquid is spilled on the seats, dry them as soon as possible.
  - if the seat covers are damp or wet, do not switch on the seat heating. The seat heating should also not be used to dry the seats.
  - clean the seat covers as recommended;
     see the "Interior care" section.
  - do not transport heavy loads on the seats. Do not place sharp objects on the seat cushions, e.g. knives, nails or tools. The seats should only be occupied by passengers, if possible.
  - when the seat heating is in operation, do not cover the seats with insulating materials, e.g. blankets, coats, bags, seat covers, child seats or booster seats.
- Make sure that there are no objects in the footwell or behind the seats when resetting the seats. There is a risk that the seats and/or the objects could be damaged.
- The rear-compartment head restraints can be removed (> page 100).
  For more information, contact a qualified

For more information, contact a qualified specialist workshop.

- 1 Further related subjects:
  - Cargo compartment enlargement (folding the rear bench seat forwards) (⊳ page 272)

# Adjusting the seats


Vehicles without Memory function: the seats can be adjusted within three minutes of a front door being opened.

The time period starts over again if, within these three minutes, you:


- · open or close a front door
- insert the SmartKey into the ignition lock or remove it from the ignition lock
- · switch the ignition on or off

If the SmartKey is in position **2** in the ignition lock, the seats can be adjusted at any time.

Depending on the equipment, the seat adjustment buttons are either located on the side of the seat or on the door control panel.



- (1) Seat cushion angle
- Seat height
- ③ Seat fore-and-aft adjustment
- (4) Backrest angle



- Seat cushion angle
- Seat height



- (3) Seat fore-and-aft adjustment
- (4) Backrest angle
- (5) Head restraint height<sup>4</sup>
- 1 You can store the seat settings using the memory function (⊳ page 106).

### Adjusting the head restraints

# Adjusting the head restraints manually

### Adjusting the head restraint height<sup>5</sup>



- ▶ To raise: pull the head restraint up to the desired position.
- ▶ To lower: press release catch (1) in the direction of the arrow and push the head restraint down to the desired position.

# Adjusting the angle of the head restraints



▶ Push or pull the lower edge of the head restraint in the direction of the arrow.

- <sup>4</sup> For vehicles with memory function only.
- 5 For vehicles without memory function only.

# Adjusting the head restraints electrically

▶ To adjust the head restraint height: slide the switch for head restraint adjustment (⊳ page 98) up or down in the direction of the arrow.

#### Rear seat head restraints

### **↑** WARNING

For safety reasons, always drive with the rear head restraints in the upright position when the rear seats are occupied.

Keep the area around head restraints clear of articles (e.g. clothing) to not obstruct the folding operation of the head restraints.

#### **↑** WARNING

For your protection, drive only with properly positioned head restraints.


Adjust the head restraint in such a way that it is as close to the head as possible and the center of the head restraint supports the back of the head at eve level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.

With a rear seat occupied, make sure to move the respective head restraint up from the lowest non-use position and have the occupant adjust the head restraint properly.

Do not drive the vehicle without the seat head restraints installed when the rear seats are occupied. Head restraints are intended to help reduce injuries during an accident.



# Adjusting the rear seat head restraint height



Once the head restraint is fully lowered, press release catch (1).

- ▶ To raise: pull the head restraint up to the desired position.
- ▶ To lower: press release catch (1) and push the head restraint down until it is in the desired position.

# Adjusting the rear seat head restraint angle

Adjust the head restraints so that they are as close as possible to your head.

You can only adjust the two outer head restraints




▶ Pull or push the top of the head restraint until it is in the desired position.

#### Installing/removing the rear seat head restraints

### **↑** WARNING

Occupants should only travel sitting on seats which have the head restraints installed. This reduces the risk of injury to occupants in the event of an accident.



- ▶ To remove: pull the head restraint up to the stop.
- ▶ Press release catch (1) and pull the head restraint out of the guides.
- ▶ To re-install: insert the head restraint so that the notches on the bar are on the left when viewed in the direction of travel.
- ▶ Push the head restraint down until you hear it engage in position.

# Adjusting the lumbar support

You can adjust the contour of the front seats so as to provide optimum support for your back.






▶ Move adjustment lever (1) in the direction of the arrow until the desired backrest contour is achieved.

### Adjusting the 4-way lumbar support

You can adjust the contour of the front seat backrests individually to provide optimum support for your back.



- 1 To raise the backrest contour
- (2) To soften the backrest contour
- (3) To lower the backrest contour
- (4) To harden the backrest contour

# Switching the seat heating on/off

# Activating/deactivating

#### **↑** WARNING

Repeatedly setting the seat heating to level 3 may result in excessive seat temperatures. The health of passengers that have limited temperature sensitivity or a limited ability to react to excessively high temperatures may be affected or they may even suffer burn-like injuries. Therefore, do not use seat heating level 3 repeatedly.

The three red indicator lamps in the button indicate the heating level you have selected.

1 If the battery voltage is too low, the seat heating may switch off.



Driver's and front-passenger seat

The system automatically switches down from level 3 to level 2 after approximately eight minutes.

The system automatically switches down from level 2 to level 1 after approximately ten minutes.

The system automatically switches off approximately 20 minutes after it is set to level 1.

- ► Make sure that the SmartKey is in position 1 or 2 in the ignition lock.
- ▶ To switch on: press button (1) repeatedly until the desired heating level is set.
- ▶ To switch off: press button (1) repeatedly until all the indicator lamps go out.

# Problems with the seat heating

The seat heating has switched off prematurely or cannot be switched on. The vehicle's electrical system voltage is too low because too many electrical consumers are switched on.

► Switch off electrical consumers that you do not need, such as the rear window defroster or interior lighting.



# Steering wheel


### Important safety notes

#### **↑** WARNING

Do not adjust the steering wheel while driving. Adjusting the steering wheel while driving, or driving without the steering wheel adjustment feature locked could cause the driver to lose control of the vehicle.

The electrical steering wheel adjustment feature can be operated at any time. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

## Adjusting the steering wheel manually



- 1 Release lever
- (2) To adjust the steering wheel height
- (3) To adjust the steering wheel position (fore-and-aft adjustment)
- ▶ Push release lever (1) down completely. The steering column is unlocked.
- ▶ Adjust the steering wheel to the desired position.
- ▶ Push release lever (1) up completely. The steering column is locked.
- ▶ Check if the steering column is locked. When doing so, try to push the steering wheel up or down or try to move it in the fore-and-aft direction.

# Adjusting the steering wheel electrically



- (1) To adjust the steering wheel height
- (2) To adjust the steering wheel position (fore-and-aft adjustment)
- further related subjects:
  - EASY-ENTRY/EXIT feature (⊳ page 102)
  - Storing settings (> page 106)

### **EASY-ENTRY/EXIT feature**

# Important safety notes

### **↑** WARNING

Make sure that nobody can become trapped when you activate the EASY-ENTRY/EXIT feature.

If there is a risk of someone becoming trapped, stop the adjustment procedure. To halt the procedure:

- press the steering column adjustment button.
- press one of the memory function position buttons.

The steering column stops moving immediately.

Do not keep the memory function position button pressed as this will start the memory function and set the steering wheel and seat in motion.

Do not leave children unattended in the vehicle. They could open the driver's door and



thereby unintentionally activate the EASY-ENTRY/EXIT feature and become trapped.

### **↑** WARNING

Let the system complete the adjustment procedure before setting the vehicle in motion. All steering wheel adjustment must be completed before setting the vehicle in motion. Driving off with the steering wheel still adjusting could cause the driver to lose control of the vehicle.

The EASY-ENTRY/EXIT feature makes getting in and out of your vehicle easier.

You can activate and deactivate the FASY-ENTRY/EXIT feature in the on-board computer (⊳ page 229).

# Position of the steering wheel when the EASY-ENTRY/EXIT feature is active

The steering wheel swings upwards when you:

- remove the SmartKey from the ignition lock
- open the driver's door and KEYLESS-GO is in position 1
- open the driver's door and the SmartKey is in position 0 or 1 in the ignition lock
- 1 The steering wheel only moves upwards if it has not already reached the upper end stop.

# Position of the steering wheel for driving

The steering wheel is moved to the last selected position when:

- the driver's door is closed.
- you insert the SmartKey into the ignition lock.

• you press the Start/Stop button once on vehicles with KEYLESS-GO.

When you close the driver's door with the ignition switched on, the steering wheel is also automatically moved to the previously set position.

The last position of the steering wheel is stored when you switch off the ignition or when you store the setting with the memory function (⊳ page 106).

# Crash-responsive EASY-EXIT feature

If the crash-responsive EASY-EXIT feature is triggered in an accident, the steering column will move upwards when the driver's door is opened. This occurs irrespective of the position of the SmartKey in the ignition lock. This makes it easier to exit the vehicle and rescue the occupants.

The crash-responsive EASY-EXIT feature is only operational if the EASY-EXIT/ENTRY feature is activated in the on-board computer.

#### **Mirrors**

#### Rear-view mirror



► Anti-glare mode: flick anti-glare lever (1) forwards or back.

### **Exterior mirrors**

#### Adjusting the exterior mirrors



#### **↑** WARNING

The exterior mirrors reduce the size of the image. Objects are actually closer than they appear. You could misjudge the distance from vehicles driving behind and cause an



accident, e.g. when changing lane. For this reason, make sure of the actual distance from the vehicle driving behind by glancing over your shoulder.

The convex exterior mirrors provide a larger field of vision.

The exterior mirrors are automatically heated after starting the vehicle if the rear window defroster is switched on and the outside temperature is low. Mirror heating lasts up to 10 minutes.

 You can also heat up the exterior mirrors manually by switching on the rear window defroster.



- Make sure that the SmartKey is in position1 or 2 in the ignition lock.
- ► Press button ① for the left-hand exterior mirror or button ② for the right-hand exterior mirror.

The indicator lamp in the corresponding button lights up in red.

- The indicator lamp goes out again after some time. You can adjust the selected mirror using adjustment button ③ as long as the indicator lamp is lit.
- ▶ Press adjustment button ③ up, down, or to the left or right until you have adjusted the exterior mirror to the correct position. You should have a good overview of traffic conditions.

# Folding the exterior mirrors in or out electrically

This function is only available in vehicles for Canada.



- ► Make sure that the SmartKey is in position 1 or 2 in the ignition lock.
- ► Briefly press button ①.

  Both exterior mirrors fold in or out.
- Make sure that the exterior mirrors are always folded out fully while driving. They could otherwise vibrate.
- 1 If you are driving faster than 9 mph (15 km/h), you can no longer fold in the exterior mirrors.

# Setting the exterior mirrors

This function is only available in vehicles for Canada.

If the battery has been disconnected or completely discharged, the exterior mirrors must be reset. The exterior mirrors will otherwise not fold in when you select the "Fold in mirrors when locking" function in the on-board computer ( $\triangleright$  page 230).

- ► Make sure that the SmartKey is in position 1 in the ignition lock.
- ▶ Briefly press button ①.

# Folding the exterior mirrors in or out automatically

This function is only available in vehicles for Canada.



If the "Fold in mirrors when locking" function is activated in the on-board computer (⊳ page 230):

- the exterior mirrors fold in automatically as soon as you lock the vehicle from the outside.
- the exterior mirrors fold out again automatically as soon as you unlock the vehicle and then open the driver's or frontpassenger door.
- 1 If the exterior mirrors have been folded in manually, they do not fold out.

# Exterior mirror out of position

If an exterior mirror has been pushed out of position, proceed as follows:

- ▶ Vehicles without electrically folding exterior mirrors: move the exterior mirror into the correct position manually.
- ▶ Vehicles with electrically folding exterior mirrors6: until you hear a click and then the mirrors engage in position. (⊳ page 104)

The mirror housing is engaged again and you can adjust the exterior mirrors as usual (⊳ page 103).

# Automatic anti-glare mirrors

# **↑** WARNING

If incident light from headlamps is prevented from striking the sensor in the rear-view mirror, for instance, by luggage piled too high in the vehicle, the mirror's automatic antiglare function will not operate.

Incident light could then blind you. This may distract you from the traffic conditions and, as a result, you may cause an accident.

The rear-view mirror and the exterior mirror on the driver's side automatically go into antiglare mode if the following conditions are met simultaneously:

- · the ignition is switched on and
- incident light from headlamps strikes the sensor in the rear-view mirror.

The mirrors do not go into anti-glare mode if reverse gear is engaged or if the interior lighting is switched on.

### Parking position for the exterior mirror on the front-passenger side

### Setting and storing the parking position

### Using reverse gear

You can position the front-passenger side exterior mirror in such a way that you can see the rear wheel on that side as soon as you engage reverse gear. You can store this position.



- ▶ Make sure that the vehicle is stationary and that the SmartKey is in position 2 in the ignition lock.
- ▶ Press button ② for the exterior mirror on the front-passenger side.



- ► Engage reverse gear. The exterior mirror on the front-passenger side moves to the preset parking position.
- ▶ Use adjustment button (3) to adjust the exterior mirror to a position that allows you to see the rear wheel and the curb. The parking position is stored.
- 1 If you shift the transmission to another position, the exterior mirror on the frontpassenger side returns to the driving position.

#### Using the memory button

You can position the front-passenger side exterior mirror in such a way that you can see the rear wheel on that side as soon as you engage reverse gear. This setting can be stored using memory button M (4).

- ► Make sure that the SmartKey is in position 2 in the ignition lock.
- ▶ With the exterior mirror on the frontpassenger side activated, use adjustment button (3) to adjust the exterior mirror. In the exterior mirror, the rear wheel and the curb should be visible.
- ▶ Press memory button **M** (4) and one of the arrows on adjustment button (3) within three seconds.
  - The parking position is stored if the exterior mirror does not move.
- ▶ If the mirror moves out of position, repeat the steps.

# Calling up a stored parking position setting

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► Adjust the exterior mirror on the frontpassenger side using button (2).
- ► Engage reverse gear. The exterior mirror on the front-passenger side moves to the stored parking position.

The exterior mirror on the front-passenger side moves back to its original position:

- as soon as you exceed a speed of 9 mph (15 km/h)
- if you press button (1) for the exterior mirror on the driver's side

# **Memory function**

### Storing settings



#### ↑ WARNING

Only use the memory function on the driver's side when the vehicle is stationary. You could otherwise be distracted from the traffic conditions by the seat moving of its own accord, and as a result cause an accident.

With the memory function, you can store up to three different settings, e.g. for three different people.

The following settings are stored as a single memory preset:

- position of the seat, backrest and head restraint
- driver's side: steering wheel position
- driver's side: position of the exterior mirrors on the driver's and front-passenger sides





- ► Adjust the seat (> page 98).
- ▶ On the driver's side, adjust the steering wheel (▷ page 102) and the exterior mirrors (▷ page 103).
- Briefly press the M memory button and then press storage position button 1, 2 or 3 within three seconds.

The settings are stored in the selected preset position. A tone sounds when the settings have been completed.

## Calling up a stored setting

- If you want to move the seat from the fully reclined position to a stored seat position, first raise the backrest. The seat could otherwise be damaged.
- ▶ Press and hold the relevant storage position button 1, 2 or 3 until the seat, steering wheel and exterior mirrors are in the stored position.
- 1 The setting procedure is interrupted as soon as you release the storage position button.





Useful information	110
Exterior lighting	110
Interior lighting	115
Replacing bulbs	110
Windshield wipers	120

# **Useful information**

- i) This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- 1 Read the information on qualified specialist workshops: (▷ page 27).

# **Exterior lighting**

#### **General notes**

For reasons of safety, Mercedes-Benz recommends that you drive with the lights switched on even during the daytime. In some countries, operation of the headlamps varies due to legal requirements and self-imposed obligations.

# Notes on driving abroad

# Conversion to symmetrical low beam

Switch the headlamps to symmetrical low beam in countries in which traffic drives on the opposite side of the road from the country where the vehicle is registered. This prevents glare to oncoming traffic. When using symmetrical lights, the edge of the road is not lit as widely and as far ahead as normal.

Have the headlamps converted at a qualified specialist workshop as close to the border as possible before driving in these countries.

# Conversion to asymmetrical low beam after returning

Have the headlamps converted back to asymmetrical low-beam headlamps at a qualified specialist workshop as soon as possible after crossing the border again.

# Setting the exterior lighting


#### **Setting options**

Exterior lighting can be set using:

- · the light switch
- the combination switch (⊳ page 112)
- the on-board computer (⊳ page 227)

### Light switch

#### Operation



- 1 -P Left-hand standing lamps
- **2 P**∈→ Right-hand standing lamps
- Parking lamps, license plate and instrument cluster lighting
- 4 Automatic headlamp mode, controlled by the light sensor
- 5 Dow-beam/high-beam headlamps
- ⑥ ◎ Rear fog lamp
- (7) Fog lamp (only vehicles with front fog lamps)

If you hear a warning tone when you leave the vehicle, the lights may still be switched on.

► Turn the light switch to AUTO.

The exterior lighting (except the parking/ standing lamps) switches off automatically if you:

- remove the SmartKey from the ignition lock
- open the driver's door with the SmartKey in position **0**.



#### Automatic headlamp mode

#### **↑** WARNING

When the light switch is set to AUTO, the lowbeam headlamps may not be switched on automatically if there is fog, snow or other causes of poor visibility due to the weather conditions such as spray. There is a risk of an accident.

In such situations, turn the light switch to ■D.

The automatic headlamp feature is only an aid. The driver is responsible for the vehicle's lighting at all times.

**AUTO** is the favored light switch setting. The light setting is automatically selected according to the brightness of the ambient light (exception: poor visibility due to weather conditions such as fog, snow or spray):

- SmartKey in position 1 in the ignition lock: the parking lamps are switched on or off automatically depending on the brightness of the ambient light.
- With the engine running: if you have activated the daytime running lamps function via the on-board computer, the daytime running lamps or the low-beam headlamps and parking lamps are switched on or off automatically depending on the brightness of the ambient light.
- ► To switch on automatic headlamp mode: turn the light switch to AUTO.

#### Only for Canada:

The daytime running lamps improve the visibility of your vehicle during the day. The daytime running lamps function is required by law in Canada. It cannot therefore be deactivated.

When the engine is running and the vehicle is stationary: if you move the selector lever from a drive position to P, the daytime running lamps/low-beam headlamps go out after three minutes.

When the engine is running, the vehicle is stationary and in high ambient light: if you turn the light switch to [305], you turn on the daytime running lamps and parking lamps. If the engine is running and you turn the light switch to , the manual settings take precedence over the daytime running lamps.

#### **USA only:**

The daytime running lamps improve the visibility of your vehicle during the day. To do this, the daytime running lamps function must be switched on using the on-board computer (⊳ page 227).

If the engine is running and you turn the light switch to ⋽0€ or 🗊 , the manual settings take precedence over the daytime running lamps.

### Low-beam headlamps



#### **↑** WARNING

When the light switch is set to AUTO, the lowbeam headlamps may not be switched on automatically if there is fog, snow or other causes of poor visibility due to the weather conditions such as spray. There is a risk of an accident.

In such situations, turn the light switch to ■D.

Even if the light sensor does not detect that it is dark, the parking lamps and low-beam headlamps switch on when the ignition is switched on and the light switch is set to the position. This is a particularly useful function in the event of rain and fog.

- ► To switch on the low-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊. The green D indicator lamp in the instrument cluster lights up.

# Front fog lamps

In conditions where visibility is poor due to fog, snow or rain, the fog lamps improve visibility as well as making it easier for other road users to see you. They can be operated together with the parking lamps or together



with the parking lamps and low-beam headlamps.

- ➤ To switch on the front fog lamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊 or AUTO.
- ► Press the 10 button.

  The green 10 indicator lamp in the instrument cluster lights up.
- ► To switch off the front fog lamps: press the 🚯 button.

The green indicator lamp in the instrument cluster goes out.

Only vehicles with front fog lamps have the fog lamps function.

#### Rear fog lamp

The rear fog lamp improves visibility of your vehicle for the traffic behind in the event of thick fog. Please take note of the country-specific regulations for the use of rear fog lamps.

- ► To switch on the rear fog lamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊 or 🗚 Or .
- ► Press the ① button.

  The yellow ① indicator lamp in the instrument cluster lights up.

The yellow 1 indicator lamp in the instrument cluster goes out.

# Parking lamps

If the battery has been excessively discharged, the parking lamps or standing lamps are automatically switched off to enable the next engine start. Always park your vehicle safely and sufficiently lit according to legal standards. Avoid the continuous use of the Dace parking lamps for several hours. If possible, switch on the Peright or the Peright standing lamp.

► **To switch on:** turn the light switch to \(\frac{1}{200\pi}\).

Depending on the equipment level, the green indicator lamp or the scale illumination in the instrument cluster light up.


#### Standing lamps

Switching on the standing lamps ensures the corresponding side of the vehicle is illuminated.

- ➤ To switch on the standing lamps: the SmartKey is not in the ignition lock or it is in position 0.
- ► Turn the light switch to ←►€ (left-hand side of the vehicle) or ►€← (right-hand side of the vehicle).

#### Combination switch

#### Turn signal



- ① High-beam headlamps
- ② Turn signal, right
- 3 High-beam flasher
- 4 Turn signal, left
- ➤ To indicate briefly: press the combination switch briefly to the pressure point in the direction of arrow ② or ④.

The corresponding turn signal flashes three times.

► To indicate: press the combination switch beyond the pressure point in the direction of arrow (2) or (4).



#### High-beam headlamps

- ► To switch on the high-beam headlamps: turn the SmartKey in the ignition lock to position 2 or start the engine.
- ► Turn the light switch to 🗊 or **AUTO**.
- ▶ Press the combination switch beyond the pressure point in the direction of arrow (1).

In the **AUTO** position, the high-beam headlamps are only switched on when it is dark and the engine is running.

The <code>ID</code> indicator lamp in the instrument cluster lights up when the high-beam headlamps are switched on.

► To switch off the high-beam headlamps: move the combination switch back to its normal position.

The indicator lamp in the instrument cluster goes out.

### High-beam flasher

- ➤ To switch on: turn the SmartKey in the ignition lock to position 1 or 2 or start the engine.
- ▶ Pull the combination switch in the direction of arrow (3).

# Hazard warning lamps



The hazard warning lamps automatically switch on if:

- an air bag is deployed.
- the vehicle is slowed down rapidly from a speed of over 45 mph (70 km/h) and comes to a halt.
- ► To switch on the hazard warning lamps: press button (1).

All turn signals flash. If you now switch on a turn signal using the combination switch, only the turn signal lamp on the corresponding side of the vehicle will flash.

► To switch off the hazard warning lamps: press button (1).

If the vehicle returns to a speed of over 6 mph (10 km/h) after a full application of the brakes, the hazard warning lamps are deactivated automatically.

1 The hazard warning lamps still operate if the ignition is switched off.

# Headlamp cleaning system

The headlamps are cleaned automatically if the "Wipe with washer fluid" function is operated five times while the lights are on and the engine is running (> page 120). When you switch off the ignition, the automatic headlamp cleaning system is reset and counting is resumed from 0.

# **Active light function**





The active light function is a system that moves the headlamps according to the steering movements of the front wheels. In this way, relevant areas remain illuminated while driving. This allows you to recognize pedestrians, cyclists and animals.

Active: when the lights are switched on.

### **Cornering light function**



The cornering light function improves the illumination of the road over a wide angle in the direction you are turning, enabling better visibility in tight bends, for example. The cornering light function can only be activated when the low-beam headlamps are switched on.

#### Active:

- if you are driving at speeds below 25mph (40 km/h) and switch on the turn signal or turn the steering wheel.
- if you are driving at speeds between 25 mph (40 km/h) and 45 mph (70 km/h) and turn the steering wheel.

Not active: if you are driving at speeds above 25 mph (40 km/h) or switch off the turn signals or turn the steering wheel to the straight-ahead position.

The cornering light function may remain lit for a short time, but is automatically switched off after no more than three minutes.

# **Adaptive Highbeam Assist**



#### **↑** WARNING

Adaptive Highbeam Assist does not recognize road users:

- · who have no lights, e.g. pedestrians
- who have poor lighting, e.g. cyclists
- whose lighting is blocked, e.g. by a barrier

In very rare cases, Adaptive Highbeam Assist may fail too recognize other road users that have lights, or may recognize them too late. In this or similar situations, the automatic high-beam headlamps will not be deactivated or activated regardless. There is a risk of an accident.

Always carefully observe the traffic conditions and switch off the high-beam headlamps in good time.

You can use this function to set the headlamps to change between low beam and high beam automatically. The system recognizes vehicles with their lights on, either approaching from the opposite direction or traveling in front of your vehicle, and consequently switches the headlamps from high beam to low beam.

The system automatically adapts the lowbeam headlamp range depending on the distance to the other vehicle. Once the system no longer detects any other vehicles, it reactivates the high-beam headlamps.

The system's optical sensor is located behind the windshield near the overhead control panel.







- ► To activate: activate the Adaptive Highbeam Assist function using the onboard computer (> page 227).
- ► Turn the light switch to **AUTO**.
- Press the combination switch beyond the pressure point in the direction of arrow ① (▷ page 112).

If it is dark and the light sensor activates the low-beam headlamps, the indicator lamp in the instrument cluster lights up.

If you are driving at speeds above approximately 28 mph (45 km/h):

The headlamp range is set automatically depending on the distance between the vehicle and other road users.

If you are driving at speeds above approximately 35 mph (55 km/h) and no other road users have been detected:

The high-beam headlamps are switched on automatically. The D indicator lamp in the instrument cluster also lights up.

If you are driving at speeds below approximately 30 mph (45 km/h) or other road users have been detected or the roads are adequately lit:

The high-beam headlamps are switched off automatically. The Dindicator lamp in the instrument cluster goes out. The D

indicator lamp in the instrument cluster stays on.

➤ To deactivate: move the combination switch back to its normal position.

The □ indicator lamp in the instrument cluster goes out.

# Headlamps fogged up on the inside

The headlamps may fog up on the inside if there is high atmospheric humidity.

► Switch on the lights and drive off.


The level of moisture diminishes,
depending on the length of the journey and
the weather conditions (humidity and
temperature).

If the level of moisture does not diminish:

► Have the headlamps checked at a qualified specialist workshop.

# Interior lighting

# Overview of interior lighting




Front overhead control panel

- ① Switches the rear interior lighting on/off
- 2 Switches the automatic interior lighting control on/off
- ③ Switches the right-hand front reading lamp on/off



- (4) Switches the front interior lighting on/off
- lamp on/off



Rear-compartment overhead control panel

- lamp on/off
- ② 番 Switches the left-hand reading lamp on/off

## Interior lighting control

#### General notes

In order to prevent the vehicle's battery from discharging, the interior lighting functions are automatically deactivated after some time unless the SmartKey is in position 2 in the ignition lock.

# Automatic interior lighting control

▶ To activate/deactivate: press the 👼 button.

When the automatic interior lighting control is activated, the button is flush with the overhead control panel.

The interior lighting automatically switches on if you:

- unlock the vehicle
- open a door
- remove the SmartKey from the ignition lock.

The interior light is activated for a short while when the SmartKey is removed from the

ignition lock. You can activate this delayed switch-off using the on-board computer (⊳ page 228).

# Manual interior lighting control

- ▶ To switch the front interior lighting on/ off: press the 🔀 button.
- ► To switch the interior lighting on/off: press the [25] button.
- ► To switch the reading lamps on/off: press the Yam button.

### Crash-responsive emergency lighting

The interior lighting is activated automatically if the vehicle is involved in an accident.

► To switch off the crash-responsive emergency lighting: press the hazard warning lamp button.

or

▶ Lock and then unlock the vehicle using the SmartKey.

## Replacing bulbs

## Important safety notes

#### Xenon bulbs



#### **↑** DANGER

Xenon bulbs carry a high voltage. You can get an electric shock if you remove the cover of the Xenon bulb and touch the electrical contacts. There is a risk of fatal injury.

Never touch the parts or the electrical contacts of the Xenon bulb. Always have work on the Xenon bulbs carried out at a qualified specialist workshop.

If your vehicle is equipped with Xenon bulbs, you can recognize this by the following: the cone of light from the Xenon bulbs moves from the top to the bottom and back again when you start the engine. For this to be



observed, the lights must be switched on before starting the engine.

Bulbs and lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.

#### Other bulbs



#### **↑** WARNING

Bulbs, lamps and connectors can get very hot when operating. If you change a bulb, you could burn yourself on these components. There is a risk of injury.

Allow these components to cool down before changing a bulb.

There are bulbs other than the Xenon bulbs that you cannot replace. Replace only the bulbs listed (▷ page 117). Have the bulbs that you cannot replace yourself changed at a qualified specialist workshop.

If you require assistance changing bulbs, consult a qualified specialist workshop.

Do not touch the glass tube of new bulbs with your bare hands. Even minor contamination can burn into the glass surface and reduce the service life of the bulbs. Always use a lintfree cloth or only touch the base of the bulb when installing.


Only use bulbs of the correct type.

If the new bulb still does not light up, consult a qualified specialist workshop.

Bulbs and lamps are an important aspect of vehicle safety. You must therefore make sure that these function correctly at all times. Have the headlamp setting checked regularly.

# Overview: changing bulbs/bulb types

You can change the following bulbs. The bulb type can be found in the legend.




Halogen headlamps

- ① Low-beam headlamp: H7 55 W
- (2) High-beam headlamp/parking lamp/ standing lamp: H15 55 W/15 W
- (3) Turn signal lamp: PWY 24 W



Vehicles with Bi-Xenon headlamps (1) Cornering lamp: H7 55 W



(1) Backup lamp: W 16 W



### Changing the front bulbs

## Low-beam headlamps (halogen headlamps)

# **↑** WARNING


These bulbs are pressurized.

They can explode when being changed if:

- · they are still hot
- they hit an object when being removed
- they are dropped

There is a risk of injury.

You should wear eye protection and clean gloves when you are changing a bulb. If necessary, have bulbs changed at a qualified specialist workshop.



- Switch off the lights.
- ▶ Open the hood.
- ► Turn housing cover (1) counter-clockwise and pull it out.
- ► At the bulb holder, push the bulb upwards, disconnect it and pull it out of bulb holder (2).
- ▶ Insert the new bulb into bulb holder ②, push it down and secure it in place.
- ► Attach housing cover (1) and turn it clockwise until it engages.

# High-beam headlamps, standing/ parking lamps (halogen headlamps)




These bulbs are pressurized.

They can explode when being changed if:

- · they are still hot
- they hit an object when being removed
- they are dropped

There is a risk of injury.

You should wear eye protection and clean gloves when you are changing a bulb. If necessary, have bulbs changed at a qualified specialist workshop.



- ► Switch off the lights.
- ▶ Open the hood.
- ► Turn housing cover (1) counter-clockwise and pull it out.
- ► Turn bulb counter-clockwise and pull it out.
- ▶ Insert the new bulb into bulb holder ② and turn it clockwise.
- ▶ Align housing cover (1) and turn it clockwise until it engages.

# Cornering light function (Bi-Xenon headlamps)

#### **↑** WARNING

These bulbs are pressurized.

They can explode when being changed if:


- they are still hot
- they hit an object when being removed
- · they are dropped

There is a risk of injury.

You should wear eye protection and clean gloves when you are changing a bulb. If




necessary, have bulbs changed at a qualified specialist workshop.




- ► Switch off the lights.
- ▶ Open the hood.
- ► Turn housing cover ① counter-clockwise and pull it out.
- ▶ Push the lever of holder ② upwards until holder ② is released.
- ▶ Pull out bulb holder ②.
- ► Take the bulb out of bulb holder ②.
- ► Insert the new bulb into bulb holder ②.
- ▶ Insert holder ② from above and press it until it engages.
- ► Align housing cover ① and turn it clockwise until it engages.

# Turn signal



- ► Switch off the lights.
- ▶ Open the hood.
- ► Turn housing cover ① counter-clockwise and pull it out.

- ► Grip the back of lever extension ② and pull it out in a straight line.
- ▶ Take the bulb out of lever extension ②.
- ► Insert the new bulb into lever extension ②.




► Re-insert lever extension ② downwards (swelling) with guide rail (3).

#### Changing the rear bulbs


# Opening and closing the side trim panels

You must open the side trim panel in the cargo compartment before you can change the bulbs in the tail lamps.



Left-hand side trim panel






Right-hand side trim panel


- ▶ To open: turn release knob ① 90° in the direction of the arrow and remove side trim panel ②.
- ► To close: insert side trim panel ② and turn release knob ① 90° in the opposite direction to the arrow.

#### Tail lamp

- ► Switch off the lights.
- ▶ Open the cargo compartment.
- ▶ Open the side trim panel (> page 119).



- ▶ Pull out connector ①.
- ► Turn fender nut ② 90° counter-clockwise and pull out the bulb holder.




- ► Backup lamp ①: remove the bulb from bulb holder.
- ▶ Insert the new bulb into the bulb holder.
- ▶ Re-install bulb holder.
- ► Turn fender nut 90° clockwise.
- ▶ Insert the connector.
- ► Close the side trim panel (> page 119).

#### Windshield wipers

# Switching the windshield wipers on/

- I Do not operate the windshield wipers when the windshield is dry, as this could damage the wiper blades. Moreover, dust that has collected on the windshield can scratch the glass if wiping takes place when the windshield is dry.
- If the windshield wipers leave smears on the windshield after the vehicle has been washed in an automatic car wash, wax or other residues may be the reason for this. Clean the windshield using washer fluid after washing the vehicle in an automatic car wash.






#### Combination switch

- 1 0 Windshield wiper off
- 2 ••• Intermittent wipe, low<sup>7</sup>
- 3 Intermittent wipe, high<sup>8</sup>
- 4 Continuous wipe, slow
- 5 Continuous wipe, fast
- Single wipe/ To wipe the windshield using washer fluid
- ► Switch on the ignition.
- ► Turn the combination switch to the corresponding position.
- Vehicles with a rain sensor: if the windshield becomes dirty in dry weather conditions, the windshield wipers may be activated inadvertently. This could then damage the windshield wiper blades or scratch the windshield.

For this reason, you should always switch off the windshield wipers in dry weather.

If the wiper blades are worn, the windshield will no longer be wiped properly. This could prevent you from observing the traffic conditions. Replace the wiper blades twice a year, ideally in spring and fall.

# Switching the rear window wiper on/off



#### Combination switch

- ① Switch
- 2 To wipe with washer fluid
- 3 I To switch on intermittent wiping
- 4 0 To switch off intermittent wiping
- 5 To wipe with washer fluid
- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ► Turn switch ① on the combination switch to the corresponding position. When the rear window wiper is switched on,

the icon appears in the instrument cluster.

# Replacing the wiper blades

# Important safety notes



If the windshield wipers begin to move while you are changing the wiper blades, you could be trapped by the wiper arm. There is a risk of injury.

Always switch off the windshield wipers and ignition before changing the wiper blades.

Never open the hood/tailgate if a wiper arm has been folded away from the windshield/rear window.

- <sup>7</sup> Rain sensor set to low sensitivity.
- <sup>8</sup> Rain sensor set to high sensitivity.



Never fold a windshield wiper arm without a wiper blade back onto the windshield/rear window.

Hold the windshield wiper arm firmly when you change the wiper blade. If you release the wiper arm without a wiper blade and it falls onto the windshield/rear window, the windshield/rear window may be damaged by the force of the impact.

Mercedes-Benz recommends that you have the wiper blades changed at a qualified specialist workshop.

To avoid damaging the wiper blades, make sure that you touch only the wiper arm of the wiper.

#### Changing the windshield wiper blades

# Moving the wiper blades to a vertical position

■ Before changing the wiper blades, always set the wiper arms to a vertical position using the combination switch. There is otherwise a risk of damaging the hood.

#### **Vehicles without KEYLESS-GO**


- ► Turn the SmartKey to position 1 or 2 in the ignition lock.
- ➤ Set the windshield wipers to position —.
- ► When the wiper arms have reached a vertical position, turn the SmartKey to position **0** and remove it from the ignition lock.

#### Vehicles with KEYLESS-GO

- ▶ Switch off the engine.
- ▶ Remove your foot from the brake pedal.
- ► Set the windshield wipers to position \_\_\_\_.
- ► Press the Start/Stop button repeatedly until the windshield wipers start.
- When the wiper arms have reached a vertical position, press the Start/Stop button.

#### Removing the wiper blades

- ► Fold the wiper arm away from the windshield until it engages.
- Set the wiper blade at right angles to the wiper arm.



Remove the wiper blade from the retaining pin on the wiper arm in the direction of the arrow.

#### Installing the wiper blades

- ▶ Push the new wiper blade onto the retaining pin on the wiper arm in the opposite direction to the arrow.
  - Make sure that the wiper blade slides fully onto the retaining pin on the wiper arm.
- ► Turn the wiper blade parallel to the wiper arm.
- ► Fold the wiper arm back onto the windshield.

# Replacing the rear window wiper blade

#### Removing the wiper blades





- ► Remove the SmartKey from the ignition lock.
- ► Fold wiper arm ① away from the rear window until it engages.
- ▶ Position wiper blade ② at a right angle to wiper arm ①.
- ► Hold wiper arm ① and press wiper blade ② in the direction of the arrow until it releases.
- ► Remove wiper blade ②.

### Installing the wiper blade

- ▶ Place new wiper blade ② onto wiper arm ①.
- ► Hold wiper arm ① and press wiper blade ② in the opposite direction to the arrow until it engages.
- ► Make sure that wiper blade ② is seated correctly.
- ▶ Position wiper blade ② parallel to wiper arm (1).
- ► Fold wiper arm ① back onto the rear window.



Problems with the windshield wipers			
Problem	Possible causes/consequences and ▶ Solutions		
The windshield wipers are jammed.	Leaves or snow, for example, may be obstructing the windshield wiper movement. The wiper motor has been deactivated.  ▶ For safety reasons, you should remove the SmartKey from the ignition lock.  or  ▶ Switch off the engine using the Start/Stop button and open the driver's door.  ▶ Remove the cause of the obstruction.  ▶ Switch the windshield wipers back on.		
The windshield wipers fail completely.	The windshield wiper drive is malfunctioning.  ➤ Select another wiper speed on the combination switch.  ➤ Have the windshield wipers checked at a qualified specialist workshop.		
The spray nozzles are misaligned.	The windshield washer fluid from the spray nozzles no longer hits the center of the windshield. The spray nozzles are misaligned.  ▶ Have the spray nozzles adjusted at a qualified specialist workshop.		



Useful information	12
Overview of climate control systems	12
Operating the climate control sys-	
tems	13
Setting the air vents	13

# **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops: (▷ page 27).

#### **Overview of climate control systems**

## Important safety notes

Observe the settings recommended on the following pages. The windows could otherwise fog up.

To prevent the windows from fogging up:

- · switch off climate control only briefly
- switch on air-recirculation mode only briefly
- switch on the cooling with air dehumidification function
- switch on the defrost windshield function briefly, if required

Climate control regulates the temperature and the humidity in the vehicle interior and filters undesirable substances out of the air.


Climate control can only be operated when the engine is running. Optimum operation is only achieved with the side windows and roof closed.

The residual heat function can only be activated or deactivated with the ignition switched off (> page 136).

i Ventilate the vehicle for a brief period during warm weather, e.g. using the convenience opening feature (▷ page 87). This will speed up the cooling process and the desired vehicle interior temperature will be reached more quickly.


- 1 The integrated filter can filter out most particles of dust, and completely filters out pollen. A clogged filter reduces the amount of air supplied to the vehicle interior. For this reason, you should always observe the interval for replacing the filter, which is specified in the Maintenance Booklet. As it depends on environmental conditions, e.g. heavy air pollution, the interval may be shorter than stated in the Maintenance Booklet.
- i) It is possible that the dehumidification function of the climate control system may be activated automatically an hour after the SmartKey has been removed. The vehicle is ventilated for 30 minutes.

# Control panel for dual-zone automatic climate control



#### Canada only

- ① To set the temperature, left (▷ page 133)
- ② To defrost the windshield (▷ page 134)
- ③ To switch the ZONE function on/off (> page 134)
- (4) To switch cooling with air dehumidification on/off (> page 131)
- ⑤ To switch the rear window defroster on/off (> page 135)
- ⑥ To set the temperature, right (> page 133)
- ⑦ To activate/deactivate air-recirculation mode (▷ page 136)
- (8) To set the air distribution (> page 133)
- To increase the airflow (▷ page 134)
- ① To reduce the airflow (▷ page 134)
- ① To switch climate control on/off (▷ page 131)
- ② To set climate control to automatic (⊳ page 132)



#### USA only

- ① To set the temperature, left (▷ page 133)
- (2) To defrost the windshield (⊳ page 134)
- ③ To switch maximum cooling on/off (> page 135)
- (4) To switch cooling with air dehumidification on/off (> page 131)
- ⑤ To switch the rear window defroster on/off (▷ page 135)
- ⑥ To set the temperature, right (▷ page 133)
- ⑦ To activate/deactivate air-recirculation mode (▷ page 136)
- To set the air distribution (⊳ page 133)
- To increase the airflow (▷ page 134)
- To reduce the airflow (⊳ page 134)
- ① To switch climate control on/off (▷ page 131)
- ② To set climate control to automatic (> page 132)

# Notes on using dual-zone automatic climate control

#### Automatic climate control

The following contains notes and recommendations on optimum use of dual-zone automatic climate control.

- Activate climate control using the Auto and A/C buttons. The indicator lamps in the AUTO and A/C buttons light up.
- Set the temperature to 72 °F (22 °C).

- Only use the "windshield defrosting" function briefly until the windshield is clear again.
- Only use air-recirculation mode briefly, e.g.
  if there are unpleasant outside odors or
  when in a tunnel. The windows could
  otherwise fog up, since no fresh air is drawn
  into the vehicle in air-recirculation mode.
- Use the ZONE function to adopt the temperature settings on the driver's side for the front-passenger side as well. The indicator lamp in the DONE button goes out.



# ECO start/stop function

During automatic engine switch-off, the ECO start/stop function only operates at a reduced capacity. If you require the full climate control output, you can switch off the ECO start/stop function by pressing the ECO button (> page 146).



# Control panel for 3-zone automatic climate control





P68.10-4246-31

Canada only

#### Front control panel

- ① To set the temperature, left (> page 133)
- ② To defrost the windshield (▷ page 134)
- (3) To switch the residual heat function on/off (> page 136)
- (4) To switch cooling with air dehumidification on/off (> page 131)
- (5) To switch the rear window defroster on/off (> page 135)
- 6 To set the temperature, right (> page 133)
- ⑦ To switch the ZONE function on/off (▷ page 134)
- To switch climate control on/off (▷ page 131)
- (9) To set the air distribution (▷ page 133)
- (ii) To increase the airflow (▷ page 134)
- 1) To reduce the airflow (> page 134)
- ② To adjust airflow (▷ page 132)
- ③ To activate / deactivate air-recirculation mode (▷ page 136)
- (4) To set climate control to automatic (⊳ page 132)

#### Rear control panel

- (5) To increase the airflow (⊳ page 134)
- To reduce the airflow (▷ page 134)
- (7) Display
- (®) To reduce the temperature (▷ page 133)
- To increase the temperature (▷ page 133)



# Notes on using 3-zone automatic climate control

#### Automatic climate control

The following contains instructions and recommendations to enable you to get the most out of your automatic climate control.

- Activate climate control using the AUTO and A/C buttons. The indicator lamps in the AUTO and A/C buttons light up.
- Set the temperature to 72 °F (22 °C).
- Only use the "windshield defrosting" function briefly until the windshield is clear again.
- Only use air-recirculation mode briefly, e.g.
  if there are unpleasant outside odors or
  when in a tunnel. The windows could
  otherwise fog up, since no fresh air is drawn
  into the vehicle in air-recirculation mode.
- Use the ZONE function to adopt the temperature settings on the driver's side for the front-passenger side and the rear compartment as well. The indicator lamp in the ZONE button goes out.
- Use the residual heat function if you want to heat or ventilate the vehicle interior when the ignition is switched off. The residual heat function can only be activated or deactivated with the ignition switched off.

# ECO start/stop function

During automatic engine switch-off, the ECO start/stop function only operates at a reduced capacity. If you require the full climate control output, you can switch off the ECO start/stop function by pressing the ECO button (▷ page 146).

# Operating the climate control systems

#### Switching climate control on/off

#### Points to observe before use

When the climate control is switched off, the air supply and air circulation are also switched off. Only use this setting for a brief period. The windows could otherwise fog up. Only switch off climate control briefly to prevent the windows from fogging up.

**1** Switch on climate control primarily using the **AUTO** button (▷ page 132).

### Activating/deactivating

- ► Turn the SmartKey to position 2 in the ignition lock (> page 141).
- ► To activate: press the AUTO button.

  The indicator lamp in the AUTO button lights up. Airflow and air distribution are set to automatic mode.

or

- Press the OFF button. The indicator lamp in the OFF button goes out. The previously selected settings are restored.
- ► To deactivate: press the OFF button.

  The indicator lamp in the OFF button lights up.

# Activating/deactivating cooling with air dehumidification

#### Points to observe before use

If you switch off the cooling function, the vehicle will not be cooled when weather conditions are warm. The windows can fog up more quickly. Only deactivate the cooling with air dehumidification function for a short time to prevent the windows from fogging up. The cooling with air dehumidification function is only available when the engine is running. The air inside the vehicle is cooled and



dehumidified according to the temperature selected.

Condensation may drip from the underside of the vehicle when it is in cooling mode. This is normal and not a sign that there is a malfunction.

# Activating/deactivating

- ► To activate: press the A/C button.

  The indicator lamp in the A/C button lights up.
- When the "Cooling with air dehumidification" function is activated, one of the indicator lamps on the auxiliary heating button will light up on vehicles with auxiliary heating.
- ► To deactivate: press the A/C button.

  The indicator lamp in the A/C button goes out. The "Cooling with air dehumidification" function has a delayed switch-off feature.

# Problems with the "Cooling with air dehumidification" function

When you press the <code>\_A/c</code> button, the indicator lamp in the button flashes three times or remains off. You can no longer switch on the cooling with air dehumidification function.

► Visit a qualified specialist workshop.

# Setting the climate control to automatic

In automatic mode, the set temperature is maintained automatically at a constant level. The system automatically regulates the temperature of the dispensed air, the airflow and the air distribution.

The automatic mode functions optimally when the "Cooling with air dehumidification" function is activated. If necessary, cooling with air dehumidification can be deactivated.

If you switch off the cooling function, the vehicle will not be cooled when weather

conditions are warm. The windows can fog up more quickly. Only deactivate the cooling with air dehumidification function for a short time to prevent the windows from fogging up.

- ► Turn the SmartKey to position **2** in the ignition lock (> page 141).
- ► Set the desired temperature.
- ► To activate: press the AUTO button.

  The indicator lamp in the AUTO button lights up. Automatic air distribution and airflow are activated.

3-zone automatic climate control: when automatic mode is activated, you can adjust airflow (▷ page 132).

▶ To select manually: press the button.

or

▶ Press the ∰ or ᠍ button.

The indicator lamp in the Auto button goes out. Automatic air distribution and airflow are deactivated.

# Adjusting airflow

This function is only available with 3-zone automatic climate control.

In automatic mode you can select the following airflow settings:

FOCUS high airflow that is set slightly cooler

MEDIUM medium airflow, standard setting DIFFUSE low airflow that is set slightly warmer and with less draft

- ► Turn the SmartKey to position **2** in the ignition lock (> page 141).
- ▶ Press the **AUTO** button.
- ► Press the AIR button repeatedly until the required airflow setting appears in the display.



# Setting the temperature


#### Dual-zone automatic climate control

Different temperatures can be set for the driver's and front-passenger sides.

- ► Turn the SmartKey to position **2** in the ignition lock (> page 141).
- ► To increase/reduce: turn control ① or ⑥ clockwise or counter-clockwise (▷ page 127).

Only change the temperature setting in small increments. Start at 72 °F (22 °C).

### 3-zone automatic climate control9



Automatic climate control zones

You can select different temperature settings for the driver's and front-passenger sides as well as for the rear compartment.

- ► Turn the SmartKey to position 2 in the ignition lock (> page 141).
- ► To increase/reduce the temperature in the front: turn control ① or ⑥ clockwise or counter-clockwise (▷ page 130).

  Only change the temperature setting in small increments. Start at 72 °F (22 °C).
- ► To increase/reduce the temperature in the rear compartment using the front control panel: press the ZONE button.

  The indicator lamp in the ZONE button goes out.
- 9 Canada only.
- <sup>10</sup> Only for USA.
- 11 Canada only.

- Turn control ① clockwise or counterclockwise (▷ page 130).
  Only change the temperature setting in small increments. Start at 72 °F (22 °C).
- ➤ To increase/reduce the temperature in the rear compartment using the rear control panel: press the ▲ or ▼ button on the rear control panel.

  Only change the temperature setting in small increments. Start at 72 °F (22 °C).
- 1 If you leave the vehicle parked for longer than 30 minutes, the temperature setting for the rear compartment then switches back to 72 °F (22 °C).

# Setting the air distribution

#### Air distribution settings

Dual-zone climate control: the air distribution can be set individually for the driver's and front-passenger sides.

- Directs air through the defroster vents
- Directs air through the center and side air vents
- Directs air through the footwell air
- Directs the airflow through the center and side air vents as well as the footwell air vents<sup>10</sup>
- Directs the airflow to the entire vehicle interior 11
- Directs air through the defroster, center and side air vents<sup>11</sup>
- Directs air through the defroster and footwell vents
- Regardless of the air distribution setting, airflow is always directed through the side air vents. The side air vents can only be closed when the controls on the side air vents are turned downwards.



# **Adjusting**

- ► Turn the SmartKey to position 2 in the ignition lock (> page 141).
- Press the jibutton repeatedly until the desired symbol appears in the display. The indicator lamp in the Auto button goes out. Automatic control is deactivated and the air distribution is controlled according to the selected setting.

# Setting the airflow

- ► Turn the SmartKey to position 2 in the ignition lock (> page 141).
- 1 You can use 3-zone automatic climate control to set the airflow in the rear compartment separately.

If the battery is not sufficiently charged, blower output may be reduced. As soon as the battery is sufficiently charged, full blower output will be available.

# Switching the ZONE function on/off

This function is only available in vehicles for Canada.

► To activate: press the ZONE button.

The indicator lamp in the ZONE button lights up.

Dual-zone automatic climate control: the temperature setting for the driver's side is not adopted for the front-passenger side.

3-zone automatic climate control: the temperature setting for the driver's side is not adopted for the front-passenger side and the rear compartment.

When the buttons for temperature, airflow or air distribution are activated, the temperature setting for the driver's side is not adopted for the other climate control zones.

► To deactivate: press the ZONE button.

The indicator lamp in the ZONE button goes out.

Dual-zone automatic climate control: the temperature setting for the driver's side is adopted for the front-passenger side.

3-zone automatic climate control: the temperature setting for the driver's side is adopted for the front-passenger side and the rear compartment.

### Defrosting the windshield

You can use this function to defrost the windshield or to defrost the inside of the windshield and the side windows.

- 1 You should only select the "windshield defrosting" function until the windshield is clear again.
- ► Turn the SmartKey to position 2 in the ignition lock (> page 141).
- ► To activate: press the button.

  The indicator lamp in the button lights up.

The climate control system switches to the following functions:

- · high airflow
- high temperature
- air distribution to the windshield and front side windows
- · air-recirculation mode off

If the battery is not sufficiently charged, blower output may be reduced. As soon as the battery is sufficiently charged, full blower output will be available.

► To deactivate: press the www button.

The indicator lamp in the www button goes out. The previously selected settings are restored. Air-recirculation mode remains deactivated.

or



Press the AUTO button.

The indicator lamp in the WAX button goes out. Airflow and air distribution are set to automatic mode.

or

► Turn temperature control ① or ⑥ clockwise or counter-clockwise (▷ page 127), (▷ page 130).

or

▶ Press the 🛞 or 😵 button.

#### MAX COOL maximum cooling

The MAX COOL function is only available in vehicles for the USA.

MAX COOL is only operational when the engine is running.

When you activate MAX COOL, climate control switches to the following functions:

- · maximum cooling
- · maximum airflow
- · air-recirculation mode on
- ► **To activate:** press the total button.

  The indicator lamp in the button lights up.
- ► To activate: press the \[ \] button again. The indicator lamp goes out. The previously selected settings are restored.

# **Defrosting the windows**

# Windows fogged up on the inside

- ► Activate the <a>A/c</a> cooling with air dehumidification function.
- ► Activate automatic mode **AUTO**.
- ► Adjust the side air vents so that the warmed air is directed to the side windows.
- ▶ If the windows continue to fog up, activate the "windshield defrosting" function (> page 134).
- 1 You should only select this setting until the windshield is clear again.

### Windows fogged up on the outside

- ► Activate the windshield wipers.
- Press the justified button repeatedly until the justified symbol appears in the display.
- ► Adjust the side air vents so that no air is directed to the side windows.

#### Rear window defroster

### Activating/deactivating

The rear window defroster has a high current draw. You should therefore switch it off as soon as the rear window is clear. Otherwise, the rear window defroster switches off automatically after several minutes.

If the battery voltage is too low, the rear window defroster may switch off.

- ► Turn the SmartKey to position **2** in the ignition lock (> page 141).
- ► Press the button.

  The indicator lamp in the button lights up or goes out.



#### Problems with the rear window defroster

Problem	Possible causes/consequences and ▶ Solutions
The rear window defroster has deactivated prematurely or cannot be activated.	The battery has not been sufficiently charged.  ▶ Switch off any consumers that are not required, e.g. reading lamps, interior lighting or the seat heating.  When the battery is sufficiently charged, the rear window defroster can be activated again.

#### Activating/deactivating airrecirculation mode

If you switch on air-recirculation mode, the windows can fog up more quickly, in particular at low temperatures. Only use air-recirculation mode briefly to prevent the windows from fogging up.

You can deactivate the flow of fresh air if unpleasant odors are entering the vehicle from outside. The air already inside the vehicle will then be recirculated.

The operation of air-recirculation mode is the same for all control panels.

- ► Turn the SmartKey to position 2 in the ignition lock (> page 141).
- ▶ To activate: press the 🔊 button.

  The indicator lamp in the 🗐 button lights up.
- 1 In the event of high pollution levels 12 or at high outside temperatures, air-recirculation mode is automatically activated. When air-recirculation mode is activated automatically, the indicator lamp in the 50 button is not lit.

Outside air is added after about 30 minutes.

▶ To deactivate: press the ♠️ button.

The indicator lamp in the ♠️ button goes out.


- i Air-recirculation mode deactivates automatically:
  - after approximately five minutes at outside temperatures below approximately 41 °F (5 °C)
  - after approximately five minutes if cooling with air dehumidification is deactivated
  - after approximately 30 minutes at outside temperatures above approximately 41 °F(5 °C) if the "Cooling with air dehumidification" function is activated

# Activating/deactivating the residual heat function

The residual heat function is only available in vehicles for Canada with 3-zone automatic climate control.

It is possible to make use of the residual heat of the engine to continue heating the vehicle for approximately 30 minutes after the engine has been switched off. The heating time depends on the temperature that has been set.

- 1 The blower will run at a low speed regardless of the airflow setting.
- 1 If you activate the residual heat function at high temperatures, only the ventilation will be activated. The blower runs at medium speed.





- ► Turn the SmartKey to position **0** in the ignition lock (> page 141) or remove it.
- ► To activate: press the REST button.

  The indicator lamp in the REST button lights up.
- 1 If the residual heat function is activated, the windows may fog up on the inside.
- ► To deactivate: press the REST button.

  The indicator lamp in the REST button goes out.
- Residual heat is deactivated automatically:
  - after approximately 30 minutes
  - when the ignition is switched on
  - if the battery voltage drops
  - when the auxiliary heating is activated

# Setting the air vents

#### Important safety notes

# **↑** WARNING

Very hot or very cold air can flow from the air vents. This could result in burns or frostbite in the immediate vicinity of the air vents. There is a risk of injury.

Make sure that all vehicle occupants always maintain a sufficient distance to the air outlets. If necessary, redirect the airflow to another area of the vehicle interior.

In order to ensure the direct flow of fresh air through the air vents into the vehicle interior, please observe the following notes:

- keep the air inlet between the windshield and the hood free of blockages, such as ice, snow or leaves.
- never cover the air vents or air intake grilles in the vehicle interior.
- For virtually draft-free ventilation, adjust the sliders of the air vents to the center position.

#### Setting the center air vents



- ➤ To open the center air vent: turn the adjuster in one of center air vents ① counter-clockwise.
- ➤ To close the center air vent: turn the adjuster in one of center air vents ① clockwise until it engages.

# Setting the side air vents



- 1) Side window defroster vent
- Side air vent
- ► To open a side air vent: turn the adjuster in side air vent ② counter-clockwise.
- ► To close a side air vent: turn the adjuster in side air vent ② clockwise until it engages.

# Setting the glove box air vent


When automatic climate control is activated, the glove box can be ventilated, for instance



to cool its contents. The level of airflow depends on the airflow and air distribution settings.

! Close the air vent when heating the vehicle.

At high outside temperatures, open the air vent and activate the "cooling with air dehumidification" function. Otherwise, temperature-sensitive items stored in the glove box could be damaged.



- (1) Air vent thumbwheel
- ② Air vent
- ► To open/close: turn thumbwheel ① clockwise or counter-clockwise.

# Setting the rear-compartment air vents



- ① Rear-compartment air vent thumbwheel
- ② Rear-compartment air vent, right

- 3 Rear control panel, only with 3-zone automatic climate control<sup>13</sup>
- 4 Rear-compartment air vent, left
- ► To open/close: turn thumbwheel ① up or down.



Useful information	140
Notes on breaking-in a new vehicle	
Driving	140
Automatic transmission	148
Refueling	154
Parking	160
Driving tips	162
Driving systems	169
Towing a trailer	208

# **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (⊳ page 27).

- If possible, do not depress the accelerator pedal past the point of resistance (kickdown).
- Only select shift ranges 3. 2 or 1 when driving slowly, e.g. in mountainous terrain.

After 1,000 miles (1,500 km), you can increase the engine speed gradually and accelerate the vehicle to full speed.

- 1 You should also observe these notes on breaking in if the engine or parts of the drive train on your vehicle have been replaced.
- Always observe the respective speed limits.

### Notes on breaking-in a new vehicle

## Important safety notes

New and replaced brake pads and discs only reach their optimum braking effect after several hundred kilometers of driving. Compensate for this by applying greater force to the brake pedal.

### The first 1,000miles (1,500 km)

The more you look after the engine when it is new, the more satisfied you will be with its performance in the future.

- You should therefore drive at varying vehicle and engine speeds for the first 1,000 miles (1,500 km).
- Ideally, for the first 1,000 miles (1,500 km), drive in program E.
- Avoid heavy loads, e.g. driving at full throttle, during this period.
- Change gear in good time, before the tachometer needle is 3/3 of the way to the red area of the tachometer.
- Do not manually shift to a lower gear to brake the vehicle.

# **Driving**

#### Important safety notes

# **↑** WARNING

Objects in the driver's footwell can restrict the pedal travel or obstruct a depressed pedal. The operating and road safety of the vehicle is jeopardized. There is a risk of an accident. Make sure that all objects in the vehicle are stowed correctly, and that they cannot enter the driver's footwell. Install the floormats securely and as specified in order to ensure sufficient clearance for the pedals. Do not use loose floormats.

#### **↑** WARNING

Unsuitable footwear can hinder correct usage of the pedals, e.g.:

- · shoes with thick soles
- · shoes with high heels
- slippers

There is a risk of an accident.

Wear suitable footwear to ensure correct usage of the pedals.



#### **↑** WARNING

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect.



for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.

#### **↑** WARNING

If the parking brake has not been fully released when driving, the parking brake can:

- · overheat and cause a fire
- lose its hold function.

There is a risk of fire and an accident. Release the parking brake fully before driving off.


Warm up the engine quickly. Do not use the engine's full performance until it has reached operating temperature.

Only shift the automatic transmission to the desired drive position when the vehicle is stationary.

Where possible, avoid spinning the drive wheels when pulling away on slippery roads. You could otherwise damage the drive train.

# **Key positions**

# **SmartKey**



- o To remove the SmartKey (shift the transmission to position **P**)
- 1 Power supply for some consumers, such as the windshield wipers

- 2 Ignition (power supply for all consumers) and drive position
- 3 To start the engine

The steering is locked when you remove the SmartKey from the ignition lock.

1 The SmartKey can be turned in the ignition lock even if it is not the correct SmartKey for the vehicle. The ignition is not switched on. The engine cannot be started.

#### **KEYLESS-GO**

#### General notes

- Do not keep the KEYLESS-GO key:
  - with electronic devices, e.g. a mobile phone or another SmartKev
- with metallic objects, e.g. coins or metal foil
- inside metallic objects, e.g. a metal case This can impair the functionality of the KEYLESS-GO key.

Vehicles with KEYLESS-GO are equipped with a SmartKey featuring an integrated KEYLESS-GO function and a detachable Start/Stop button.

The Start/Stop button must be inserted in the ignition lock and the SmartKey must be in the vehicle.

Pressing the Start/Stop button several times in succession corresponds to the different key positions in the ignition lock. This is only the case if you are not depressing the brake pedal.

If you depress the brake pedal and press the Start/Stop button, the engine starts immediately.

The Start/Stop button can be removed from the ignition lock. Then, you can insert the SmartKey into the ignition lock.

1 You do not have to remove the Start/Stop button from the ignition lock when you leave the vehicle. You should, however, always take the SmartKey with you when leaving the vehicle. The vehicle can be



started with the Start/Stop button if the SmartKey is in the vehicle. Electrically powered equipment can be operated.



- (1) Start/Stop button
- ② Ignition lock
- ▶ Insert Start/Stop button (1) into ignition lock (2).
- 1 When you insert Start/Stop button (1) into ignition lock (2), the system needs approximately 2 seconds recognition time. You can then use Start/Stop button (1).



Start/Stop button

- ③ USA only
- (4) Canada only
- ▶ Position 0: if Start/Stop button (1) has not vet been pressed, this corresponds to the key being removed from the ignition.
- ▶ Position 1: press Start/Stop button (1). You can now activate the windshield wipers, for example.

- 1 If you then open the driver's door when in this position, the power supply is deactivated
- ▶ Position 2: (ignition): press Start/Stop button (1) twice.
- 1 The power supply is switched off again if:
  - the driver's door is opened and
  - you press Start/Stop button (1) once when in this position

As soon as the ignition is switched on, all the indicator lamps in the instrument cluster light up. If an indicator lamp does not go out after starting the engine or lights up while driving, see (⊳ page 259).

### Starting the engine

#### Important safety notes

#### **↑** WARNING

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shift the automatic transmission out of parking position P.
- starting the engine.

There is a risk of an accident and injury. When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the

vehicle. Always keep the SmartKey out of reach of children.

#### **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There



is a risk of fatal injury. Therefore never leave the engine running in enclosed spaces without sufficient ventilation

#### **↑** WARNING

Flammable materials introduced through environmental influence or by animals can ignite if in contact with the exhaust system or parts of the engine that heat up. There is a risk of fire.

Carry out regular checks to make sure that there are no flammable foreign materials in the engine compartment or in the exhaust system.

Do not depress the accelerator pedal when starting the engine.

### **General notes**

1 Vehicles with a gasoline engine: the catalytic converter is preheated for up to 30 seconds after a cold start. The sound of the engine may change during this time.

#### Automatic transmission

- ▶ Shift the transmission to position **P**. The transmission position display in the multifunction display shows P.
- 1 You can also start the engine when the transmission is in position N.

# Starting procedure with the SmartKey

- 1 To start the engine using the SmartKey instead of KEYLESS-GO, pull the Start/ Stop button out of the ignition lock.
- ▶ To start a gasoline engine: turn the SmartKey to position 3 in the ignition lock

- (▷ page 141) and release it as soon as the engine is running.
- ▶ To start a diesel engine: turn the SmartKey to position 2 in the ignition lock (⊳ page 141).

The more preglow indicator lamp in the instrument cluster lights up.

- ▶ When the 700 preglow indicator lamp goes out, turn the SmartKey to position 3(⊳ page 141) and release it as soon as the engine is running.
- 1 You can start the engine without preglow if the engine is warm.

### Using KEYLESS-GO to start the engine

You can start the engine if a valid SmartKev with the integrated KEYLESS-GO function is in the vehicle. Always take the SmartKey with you when leaving the vehicle, even if you only leave it for a short time. Pay attention to the important safety notes.

- 1 The Start/Stop button can be used to start the vehicle without inserting the SmartKey into the ignition lock. The Start/ Stop button must be inserted in the ignition lock and the SmartKey must be in the vehicle.
- ▶ Depress the brake pedal and keep it depressed.
- ▶ Press the Start/Stop button once (⊳ page 141). The engine starts.

# **Pulling away**

#### Automatic transmission

# **↑** WARNING

If the engine speed is above the idling speed and you engage transmission position **D** or R, the vehicle could pull away suddenly. There is a risk of an accident.



When engaging transmission position  ${\bf D}$  or  ${\bf R}$ , always firmly depress the brake pedal and do not simultaneously accelerate.

- ilt is only possible to shift the transmission from position P to the desired position if you depress the brake pedal. Only then is the parking lock released. If you do not depress the brake pedal, you can move the DIRECT SELECT lever but the parking lock remains engaged.
- ▶ Depress the brake pedal and keep it depressed.
- ▶ Shift the transmission to position **D** or **R**.
- ► Release the parking brake (> page 161).
- ► Release the brake pedal.
- ► Carefully depress the accelerator pedal.
- If a warning tone sounds and the Release Park. Brake message appears in the multifunction display, the parking brake is still applied. Release the parking brake.
- 1 The vehicle locks centrally once you have pulled away. The locking knobs in the doors drop down.

You can open the doors from the inside at any time.

You can also deactivate the automatic locking feature (> page 228).

Upshifts take place at higher engine speeds after a cold start. This helps the catalytic converter to reach its operating temperature more quickly.

#### Hill start assist

Hill start assist helps you when pulling away forwards or in reverse on an uphill gradient. It holds the vehicle for a short time after you have removed your foot from the brake pedal. This gives you enough time to move your foot from the brake pedal to the accelerator pedal and to depress it before the vehicle begins to roll.

# **MARNING**

After a short time, hill start assist will no longer brake your vehicle and it could roll away. There is a risk of an accident and injury.

Therefore, quickly move your foot from the brake pedal to the accelerator pedal. Never leave the vehicle when it is held by hill start assist.

- ► Take your foot off the brake pedal. The vehicle is then held for about a second.
- ▶ Pull away.

Hill start assist will not function if:

- you are pulling away on a level road or on a downhill gradient.
- the transmission is in position N.
- the parking brake is applied.
- ESP® is malfunctioning.

#### ECO start/stop function

# Important safety notes

# $\triangle$

#### **↑** WARNING

If the engine is switched off automatically and you exit the vehicle, the engine is restarted automatically. The vehicle may begin moving. There is a risk of accident and injury.

If you wish to exit the vehicle, always turn off the ignition and secure the vehicle against rolling away.

#### General notes

If the **ECO** symbol is shown in green in the multifunction display, the ECO start/stop function switches the engine off automatically if the vehicle stops moving. The engine starts automatically when the driver wants to pull away again. The ECO start/stop function thereby helps you to reduce the fuel consumption and emissions of your vehicle.



Every time you switch on the engine using the SmartKey or the Start/Stop button, the ECO start/stop function is activated.

If the ECO start/stop function has been manually deactivated (▷ page 146) or a malfunction has caused the system to be deactivated, the ECO symbol is not displayed.

## Automatic engine switch-off

#### General notes

The ECO start/stop function is operational and the **ECO** symbol is displayed in green in the multifunction display, if:

- the indicator lamp in the ECO button is lit green.
- the outside temperature is within the comfort range.
- the engine is at normal operating temperature.
- the set temperature for the vehicle interior has been reached
- the battery is sufficiently charged.
- the system detects that the windshield is not fogged up when the air-conditioning system is switched on.
- the hood is closed.
- the driver's door is closed and the driver's seat belt is fastened.

If not all conditions for automatic engine switch-off are fulfilled, the **ECO** symbol is shown in yellow.

- All of the vehicle's systems remain active when the engine has been stopped automatically.
- 1 The engine can be switched off automatically a maximum of four times (first stop and three subsequent stops) in succession. The ECO symbol is shown in yellow in the multifunction display after the engine has been started automatically for the fourth time. When the ECO symbol is shown in green in the multifunction display,

automatic engine switch-off is again possible.

#### Vehicles with automatic transmission

If the vehicle is braked to a standstill in  ${\bf D}$  or  ${\bf N}$ , the ECO start/stop function switches off the engine automatically.

1 The HOLD function can be activated if the engine has been switched off automatically. It is then not necessary to continue applying the brakes during the automatic stop phase. When you depress the accelerator pedal, the engine starts automatically and the braking effect of the HOLD function is deactivated.

### Automatic engine start

#### General notes

The engine starts automatically if:

- you switch off the ECO start/stop function by pressing the ECO button.
- you engage reverse gear R.
- the vehicle starts to roll.
- the brake system requires this.
- the temperature in the vehicle interior deviates from the set range.
- the system detects moisture on the windshield when the air-conditioning system is switched on.
- the condition of charge of the battery is too low.
- the driver's seat belt is removed or the driver's door is opened.

#### Vehicles with automatic transmission

The engine is started automatically if you:

- release the brake pedal when HOLD is not activated and the transmission is in position D or N.
- depress the accelerator pedal.
- move the transmission out of position P.
- **1** Shifting the transmission to position **P** does not start the engine.



1 If you shift the transmission from **R** to **D**, the ECO start/stop function is available again once the ECO symbol reappears in green in the multifunction display.

# Deactivating/activating the ECO start/ stop function



#### ECO button

- ➤ To switch off: press button ①.
  Indicator lamp ② on button ① and the

  ECO symbol in the multifunction display go out.
- ► To switch on: press button ①.
  Indicator lamp ② lights up.
  If all conditions for automatic engine switch-off (> page 145) are fulfilled, the ECO symbol is shown in green in the multifunction display.
  - If not all conditions for automatic engine switch-off (▷ page 145) are fulfilled, the **ECO** symbol is shown in yellow in the multifunction display. If this is the case, the ECO start/stop function is not available.
- i If indicator lamp ② is off, the ECO start/ stop function has been deactivated manually or as the result of a malfunction. The engine will then not be switched off automatically when the vehicle stops.



Problems with the engine		
Problem	Possible causes/consequences and ▶ Solutions	
The engine does not start. The starter motor can be heard.	<ul><li>There is a malfunction in the engine electronics.</li><li>There is a malfunction in the fuel supply.</li></ul>	
	► Turn the SmartKey back to position <b>0</b> in the ignition lock before attempting to start the engine again.	
	or	
	► Press the Start/Stop button repeatedly until all indicator lamps in the instrument cluster go out.	
	▶ Try to start the engine again (▷ page 142). Avoid excessively long and frequent attempts to start the engine as these will drain the battery.	
	If the engine does not start after several attempts:  ▶ Consult a qualified specialist workshop.	
The engine does not start. You cannot hear the starter motor.	The on-board voltage is too low because the battery is too weak or discharged.  ▶ Jump-start the vehicle (▷ page 318).  If the engine does not start despite attempts to jump-start it:  ▶ Consult a qualified specialist workshop.	
	<ul> <li>The starter motor was exposed to a thermal load that was too high.</li> <li>▶ Allow the starter motor to cool down for approximately two minutes.</li> <li>▶ Try to start the engine again.</li> <li>If the engine still does not start:</li> </ul>	

► Consult a qualified specialist workshop.



Problem	Possible causes/consequences and ▶ Solutions		
The engine is not running smoothly and is misfiring.	There is a malfunction in the engine electronics or in a mechanical component of the engine management system.  ▶ Only depress the accelerator pedal slightly.  ▶ Have the cause rectified immediately at a qualified specialist workshop.  Otherwise, non-combusted fuel may get into the catalytic converter and damage it.		
The coolant temperature gauge shows a value above 248 °F (120 °C).	<ul> <li>The coolant level is too low. The coolant is too hot and the engine is no longer being cooled sufficiently.</li> <li>▶ Stop as soon as possible and allow the engine and the coolant to cool down.</li> <li>▶ Check the coolant level (▷ page 302). Observe the warning notes as you do so and add coolant if necessary.</li> </ul>		

#### **Automatic transmission**

# Important safety notes

# **↑** WARNING

If the engine speed is above the idling speed and you engage transmission position  ${\bf D}$  or  ${\bf R}$ , the vehicle could pull away suddenly. There is a risk of an accident.

When engaging transmission position  ${\bf D}$  or  ${\bf R}$ , always firmly depress the brake pedal and do not simultaneously accelerate.

# **⚠ WARNING**


The automatic transmission switches to neutral position  ${\bf N}$  when you switch off the engine. The vehicle may roll away. There is a risk of an accident.

After switching off the engine, always switch to parking position **P**. Prevent the parked vehicle from rolling away by applying the parking brake.

#### **DIRECT SELECT lever**

### Overview of transmission positions

The DIRECT SELECT lever is on the right of the steering column.



- P Park position with parking lock
- R Reverse gear
- N Neutral
- **D** Drive
- The DIRECT SELECT lever always returns to its original position. The current transmission position P, R, N or D appears in the transmission position display (▷ page 149) in the multifunction display.



# Transmission position and drive program display



- (1) Transmission position display
- ② Drive program display
- 1 The arrows in the transmission position display show how and into which transmission positions you can change using the DIRECT SELECT lever.
- If the transmission position display in the multifunction display is not working, you should pull away carefully to check whether the desired transmission position is engaged. Ideally, you should select transmission position **D** and drive program **E** or **S**. Do not restrict the shift range.

The current transmission position and drive program appear in the multifunction display.

# **Engaging park position P**

- ► Push the DIRECT SELECT lever in the direction of arrow P
- **1** The automatic transmission shifts into park position **P** automatically:
  - if you open the driver's door while the vehicle is stationary in transmission position **D** or **R**
  - if you open the door while traveling at very low speeds in transmission position
     D or R
- If the engine speed is too high or the vehicle is moving, do not shift the automatic transmission directly from **D** to

**R**, from **R** to **D** or directly to **P**. The automatic transmission could otherwise be damaged.

### **Engaging park position P automatically**

Park position P is automatically engaged if:

- you switch off the engine using the SmartKey and remove the SmartKey
- you switch off the engine using the Start/ Stop button and open one of the front doors
- the HOLD (▷ page 179) or DISTRONIC PLUS (▷ page 171) function brake your vehicle until it is stationary and at least one of the following conditions is fulfilled:
  - there is a system malfunction.
- the vehicle is on a steep uphill or downhill gradient. The electric parking brake is then also applied.

## Engaging reverse gear R

- Only shift the automatic transmission to R when the vehicle is stationary.
- ► When the vehicle is stationary, depress the brake pedal.
- ▶ Push the DIRECT SELECT lever up past the first point of resistance.

# Shifting to neutral N

- ► When the vehicle is stationary, depress the brake pedal.
- ▶ Push the DIRECT SELECT lever up or down to the first point of resistance.

If the engine has been switched off, the automatic transmission automatically shifts to  ${\bf N}.$ 

### Remaining in neutral N

If the automatic transmission is to remain in neutral  ${\bf N}$ , e.g. for washing the vehicle in car washes with a towing device, please observe the following instructions:



# **↑** WARNING

If children are left unsupervised in the vehicle, they could:

- open the doors, thus endangering other people or road users.
- get out and disrupt traffic.
- operate the vehicle's equipment.

Additionally, children could set the vehicle in motion if, for example, they:

- release the parking brake.
- shift the automatic transmission out of parking position P.
- starting the engine.

There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children or animals unattended in the vehicle. Always keep the SmartKey out of reach of children.

#### Using the SmartKey:

- Make sure that the ignition is switched on.
- When the vehicle is stationary, depress the brake pedal and keep it depressed.
- Shift to neutral N.
- Release the brake pedal.
- if the electric parking brake is applied, release it.
- Switch off the ignition and leave the SmartKey in the ignition lock.

#### Using KEYLESS-GO:

- Make sure that the ignition is switched on.
- When the vehicle is stationary, depress the brake pedal and keep it depressed.
- Engage park position P.
- Release the brake pedal.
- Remove the Start/Stop button from the ignition lock.
- Insert the SmartKey into the ignition lock.
- Switch on the ignition.
- Depress the brake pedal and keep it depressed.

- Shift to neutral N.
- Release the brake pedal.
- if the electric parking brake is applied, release it.
- Switch off the ignition and leave the SmartKey in the ignition lock.

#### Engaging drive position D

- When the vehicle is stationary, depress the brake pedal.
- ▶ Push the DIRECT SELECT lever down past the first point of resistance.

# Transmission positions

# Р

## Park position

Do not shift the transmission into position **P**(▷ page 160) unless the vehicle is stationary. The parking lock should not be used as a brake when parking. Always apply the parking brake in addition to the parking lock in order to secure the vehicle.

If the vehicle electronics are malfunctioning, the transmission may be locked in position **P**. Have the vehicle electronics checked immediately at a qualified specialist workshop.

The automatic transmission shifts to **P** automatically if you:

- remove the SmartKey
- switch off the engine when in R or D and open one of the front doors



#### Reverse gear

Only shift the transmission to **R** when the vehicle is stationary.





#### Neutral

Do not shift the transmission to **N** while driving. The transmission could otherwise be damaged.

No power is transmitted from the engine to the drive wheels.

Releasing the brakes will allow you to move the vehicle freely, e.g. to push it or tow it.

If ESP® is deactivated or faulty: only shift the transmission to position **N** if the vehicle is in danger of skidding, e.g. on icy roads.

Rolling in neutral **N** can damage the drive train.



#### Drive

The automatic transmission changes gear automatically. All forward gears are available.

# Changing gear

The automatic transmission shifts to the individual gears automatically when it is in transmission position **D**. This automatic gearshifting behavior is determined by:

- a shift range restriction, if selected
- the selected drive program:
  - **E/S**(⊳ page 151)
- the position of the accelerator pedal
- the road speed

# **Driving tips**

#### Kickdown

Use kickdown for maximum acceleration.

- ► Depress the accelerator pedal beyond the pressure point.
- The automatic transmission shifts to a lower gear depending on the engine speed.
- ► Ease off the accelerator pedal once the desired speed is reached.

The automatic transmission shifts back up.

### Towing a trailer

- ► When traveling downhill, switch to a lower gear if the automatic transmission constantly switches between two gears.
- ► Engaging a lower gear and reducing the speed reduces the risk of the engine overheating.

# **Program selector button**

#### General notes

The program selector button allows you to choose between different driving characteristics.



Program selector button

<b>E</b> Economy	Comfortable, economical driving
<b>S</b> Sport	Sporty driving style



- for further information on the automatic drive program, see (> page 152).
- ► Press program selector button ①
  repeatedly until the letter for the desired
  gearshift program appears in the
  multifunction display.

## Steering wheel paddle shifters



- 1) Left-hand steering wheel paddle shifter
- 2 Right-hand steering wheel paddle shifter

In the automatic drive program, you can restrict or derestrict the shift range by using the steering wheel paddle shifters (> page 152).

1 You can only change gear with the steering wheel paddle shifters when the transmission is in position **D**.

# **Automatic drive program**

Drive program **E** is characterized by the following:

- optimal fuel consumption resulting from the automatic transmission shifting up sooner
- the vehicle pulling away more gently in forward and reverse gears, unless the accelerator pedal is depressed fully

- increased sensitivity. This improves driving stability on slippery road surfaces, for example
- the automatic transmission shifting up sooner. This results in the vehicle being driven at lower engine speeds and the wheels being less likely to spin

Drive program **S** is characterized by the following:

- sporty engine and automatic transmission settings
- the vehicle pulling away in first gear
- the automatic transmission shifting up later
- the fuel consumption possibly being higher as a result of the later automatic transmission shift points

#### Shift ranges

#### Introduction

When the automatic transmission is in position **D**, it is possible to restrict or derestrict the shift range (▷ page 152).

The shift range selected is shown in the multifunction display. The automatic transmission shifts only as far as the selected gear.

# Shift range:

- You can use the engine's braking effect
- You can use the braking effect of the engine on downhill gradients and for driving:
  - on steep mountain roads
  - in mountainous terrain
  - · in arduous conditions
- To use the braking effect of the engine on extremely steep downhill gradients and on long downhill stretches



### Restricting the shift range

- Pull the left-hand steering wheel paddle shifter
  - The automatic transmission shifts down one gear and restricts the shift range to the relevant gear.
- 1 If the engine exceeds the maximum engine speed when shifting down, the automatic transmission protects against engine damage by not shifting down.
- 1 If the maximum engine speed for the shift range is reached and you continue to accelerate, the automatic transmission shifts up, even if the shift range is restricted. This prevents the engine from overrevving.

### Extending the shift range

Pull the right-hand steering wheel paddle shifter.

The shift range is derestricted.

# Clearing the shift range restriction

Pull and hold the right-hand steering wheel paddle shifter until **D** is shown again in the multifunction display.

The automatic transmission shifts from the current shift range directly to **D**.

# Selecting the ideal shift range

▶ Pull the left-hand steering wheel paddle shifter and hold it in position.

The automatic transmission shifts to the gear which allows optimum acceleration and deceleration. To do this, the automatic transmission shifts down one or more gears.



B 11 11 11 1

Problems with the transmission		
Problem	Possible causes/consequences and ▶ Solutions	
The transmission has problems shifting gear.	The transmission is losing oil.  ▶ Have the transmission checked at a qualified specialist workshop immediately.	
The acceleration ability is deteriorating. The transmission no longer changes gear.	The transmission is in emergency mode.  It is only possible to shift into <b>second</b> gear and reverse gear.  ▶ Stop the vehicle.  ▶ Shift the transmission to position <b>P</b> .  ▶ Switch off the engine.  ▶ Wait at least ten seconds before restarting the engine.  ▶ Shift the transmission to position <b>D</b> or <b>R</b> .  If <b>D</b> is selected, the transmission shifts into <b>second</b> gear; if <b>R</b> is selected, the transmission shifts into reverse gear.	

workshop immediately.

#### Transfer case

This section is only valid for vehicles with 4wheel drive (4MATIC). Power is always transmitted to both axles.

- Performance tests may only be carried out on a 2-axle dynamometer. The brake system or transfer case could otherwise be damaged. Contact a qualified specialist workshop for a performance test.
- I To prevent ESP® from intervening, the ignition must be switched off (SmartKey in position 0 or 1) if:
  - the parking brake is being tested on a brake dynamometer.
  - the vehicle is being towed with only one axle raised (not permitted for vehicles with 4MATIC).

The brake system could otherwise be damaged.

■ Vehicles with 4MATIC must not be towed with either the front or the rear axle raised. as doing so will damage the transmission.

# Refueling

▶ Have the transmission checked at a qualified specialist

# Important safety notes



#### **↑** WARNING

Fuel is highly flammable. If you handle fuel incorrectly, there is a risk of fire and explosion.

You must avoid fire, open flames, creating sparks and smoking. Switch off the engine and, if applicable, the auxiliary heating before refueling.



#### / WARNING

Fuel is poisonous and hazardous to health. There is a risk of injury.

You must make sure that fuel does not come into contact with your skin, eyes or clothing and that it is not swallowed. Do not inhale fuel vapors. Keep fuel away from children.



If you or others come into contact with fuel, observe the following:

- Wash away fuel from skin immediately using soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical assistance without delay.
- If fuel is swallowed, seek medical assistance without delay. Do not induce vomiting.
- Immediately change out of clothing which has come into contact with fuel.

# **↑** WARNING

Electrostatic buildup can create sparks and ignite fuel vapors. There is a risk of fire and explosion.

Always touch the vehicle body before opening the fuel filler flap or touching the fuel pump nozzle. Any existing electrostatic buildup is thereby discharged.

#### **↑** WARNING

Vehicles with a diesel engine:

If you mix diesel fuel with gasoline, the flash point is lower than that of pure diesel fuel. When the engine is running, exhaust system components could overheat without being noticed. There is a risk of fire.

Never refuel with gasoline. Never mix gasoline with diesel fuel.

Do not use gasoline to refuel vehicles with a diesel engine. Do not use diesel to refuel vehicles with a gasoline engine. Do not switch on the ignition if you accidentally refuel with the wrong fuel. Otherwise, the fuel will enter the fuel system. Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. The repair costs are high. Notify a qualified specialist workshop and have the fuel tank and fuel lines drained completely.

- Overfilling the fuel tank could damage the fuel system.
- I Take care not to spill any fuel on painted surfaces. You could otherwise damage the paintwork.
- Use a filter when refueling from a fuel can.

  Otherwise, the fuel lines and/or injection system could be blocked by particles from the fuel can.

Do not get into the vehicle again during the refueling process. Otherwise, electrostatic charge could build up again.

If you overfill the fuel tank, fuel could spray out when the fuel pump nozzle is removed. For further information on fuel and fuel quality (> page 365).

## Refueling

# Opening/closing the fuel filler flap



- ① To open the fuel filler flap
- ② To insert the fuel filler cap
- ③ Tire pressure table
- 4 Fuel type to be used

The fuel filler flap is unlocked or locked automatically when you open or close the vehicle with the SmartKey or with KEYLESS-GO.

The position of the fuel filler cap is displayed

in the instrument cluster. The arrow
next to the filling pump indicates the side of
the vehicle.



#### To open

- ▶ Switch the engine off.
- ▶ Remove the SmartKey from the ignition lock.
- ▶ KEYLESS-GO: open the driver's door. This corresponds to key position 0: "key removed".
  - The driver's door can be closed again.
- ▶ Press the fuel filler flap in the direction of arrow ①.
  - The fuel filler flap opens slightly.
- ▶ Open the fuel filler flap fully.
- ► Turn the fuel filler flap counter-clockwise and remove it.
- ▶ Insert the fuel filler cap into the holder bracket on the inside of filler flap (2).
- Completely insert the filler neck of the fuel pump nozzle into the tank, hook in place and refuel.
- ➤ Only fill the tank until the pump nozzle switches off.
- 1 Do not add any more fuel after the pump stops filling for the first time. Otherwise, fuel may leak out.

#### To close

- Replace the cap on the filler neck and turn clockwise until it engages audibly.
- ► Close the fuel filler flap.
- 1 Close the fuel filler flap before locking the vehicle.
- open, the reserve fuel warning lamp flashes. A message appears in the multifunction display (▷ page 245). In addition, the Check Engine warning lamp may light up (▷ page 264). For further information on warning and

indicator lamps in the instrument cluster, see (▷ page 264).



Problems with fuel and the fuel tank		
Problem	Possible causes/consequences and ▶ Solutions	
Fuel is leaking from the vehicle.	The fuel line or the fuel tank is faulty.	
The engine does not start.	The fuel tank of a vehicle with a diesel engine has been run completely dry.  ▶ Refuel the vehicle with at least 5.3 US qt (5 liters) of diesel.  ▶ Turn the ignition on for approximately ten seconds (▷ page 141).  ▶ Start the engine continuously for up to ten seconds until it runs smoothly.  If the engine does not start:  ▶ Turn the ignition on again for approximately ten seconds (▷ page 141).  ▶ Start the engine again continuously for up to ten seconds until it runs smoothly.  If the engine does not start after three attempts:  ▶ Consult a qualified specialist workshop.	
The fuel filler flap cannot be opened.	The fuel filler flap is not unlocked.  or The SmartKey battery is discharged.  ▶ Unlock the vehicle (▷ page 74).  or  ▶ Unlock the vehicle using the mechanical key (▷ page 76).  The fuel filler flap is unlocked, but the opening mechanism is jammed.  ▶ Consult a qualified specialist workshop.	



# **DEF (BlueTEC vehicles only)**

#### Important notes on use

To function properly, BlueTEC exhaust gas aftertreatment must be operated with the reducing agent DEF. Adding DEF is one of the tasks performed during maintenance. Under normal operating conditions, a tank of DEF lasts until the next service due date.

When the supply of DEF is almost used up, the Check Additive See Operator's Manual message is shown in the multifunction display.

When the DEF supply drops to a minimum, the Remaining Starts: 16 message is shown in the multifunction display.

If the Remaining Starts: 16 message appears in the multifunction display, you can start the engine another 16 times. If DEF is not refilled, you will subsequently be **unable to start the engine**. Refill the DEF tank with around 1 gal (3.8 l) of DEF or have the DEF tank refilled at a qualified specialist workshop.

Use the special DEF refill bottle when adding DEF between maintenance intervals. Contact a qualified specialist workshop with any questions or, if necessary, contact Roadside Assistance (▷ page 24).

If the outside temperature is below 12 °F (-11 °C) it may be difficult to top up. If DEF is frozen and there is an active warning indicator, it may not be possible to add DEF. Park the vehicle in a warmer place, e.g. in a garage, until DEF has become fluid again. It will then be possible to add DEF again. Alternatively, have the DEF tank refilled at a qualified specialist workshop.

Further information about BlueTEC exhaust gas aftertreatment and DEF is available at any authorized Mercedes-Benz Center.

# Important safety notes on the refilling procedure

DEF is a water-soluble fluid for the exhaust gas aftertreatment of diesel engines. It is:

- · not poisonous
- · colorless and odorless
- not flammable

When you open the DEF container, small amounts of ammonia vapor may be released. Ammonia vapors have a pungent odor and are particularly irritating to the skin, to mucous membranes and to the eyes. You may experience a burning sensation in your eyes, nose and throat. Coughing and watering of the eyes are possible.

Do not inhale ammonia vapors. Fill the DEF tank only in well-ventilated areas.

DEF must not come into contact with your skin, eyes or clothing and must not be swallowed. Keep DEF away from children.

If you or other persons come into contact with DEF, observe the following:

- Rinse DEF from your skin immediately with soap and water.
- If DEF comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical assistance without delay.
- If DEF has been swallowed, rinse your mouth out immediately. Drink plenty of water. Seek medical assistance without delay.
- Change out of clothing contaminated with DEF immediately.
- I Only use DEF in accordance with ISO 22241. Do not mix any additives with DEF, and do not dilute DEF with water. This may destroy the BlueTEC exhaust gas aftertreatment system.
- Rinse surfaces that have come into contact with DEF immediately with water or remove DEF using a damp cloth and cold water. If the DEF has already crystallized, use a sponge and cold water to clean it. DEF



residues crystallize after time and contaminate the affected surfaces.

- DEF is not a fuel additive and must not be added to the fuel tank. If DEF is added to the fuel tank, this can lead to engine damage.
- Only screw on the DEF refill bottle handtight. It could otherwise be damaged.

The DEF filler neck is under the cargo compartment floor.

- ▶ Switch the ignition off.
- ▶ Open the tailgate.
- ► Lift up the cargo compartment floor (> page 312).



► Turn DEF cap ① counter-clockwise and remove it.



► Turn DEF filler cap ② counter-clockwise and open it. Filler cap ② is secured with a plastic strip.



- ► Unscrew the protective cap from DEF refill bottle ③.
- ► Set DEF refill bottle ③ as shown on the filler neck and screw it on hand-tight.
- ➤ Press DEF refill bottle ③ downward.

  The DEF tank is filled. This may take up to one minute.
- 1 To top up between service intervals, fill the DEF tank with approximately 1 gal (3.8 l) of DEF. 1 gal (3.8 l) DEF is equivalent to approximately 2 DEF refill bottles. Then have the DEF supply checked at a qualified specialist workshop and completely refilled if necessary.
- ▶ Release DEF refill bottle ③. When DEF refill bottle ③ is no longer pressed down, filling stops. DEF refill bottle ③ can be removed when it has been only partially emptied.
- ► Turn DEF refill bottle ③ counter-clockwise and remove it.
- ▶ Place DEF filler cap ② on the filler neck and turn it clockwise.





- ▶ Replace DEF cover (1) as shown and turn it clockwise as far as it will go.
- ► Fold the cargo compartment floor down.
- ► Close the tailgate.
- ▶ Drive faster than 10 mph (16 km/h). The Check Additive See Operator's Manual message goes out after approximately one minute.
- If the Check Additive See Operator's Manual message remains shown in the multifunction display, add an additional bottle of DFF.

For further information on DEF, see (⊳ page 369).

#### **Parking**

#### Important safety notes

# **↑** WARNING

If flammable materials such as leaves, grass or twigs are exposed to prolonged contact to parts of the exhaust system that heat up, they could ignite. There is a risk of fire.

Park the vehicle so that no flammable materials come into contact with parts of the vehicle which are hot. Take particular care not to park on dry grassland or harvested grain fields.

# **↑** WARNING

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect, for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.

### **↑** WARNING

If you leave children unsupervised in the vehicle, they could set it in motion by, for example:

- releasing the parking brake
- · shifting the automatic transmission out of the parking position P
- starting the engine.

They could also operate the vehicle's equipment. There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

Always secure the vehicle correctly against rolling away. Otherwise, the vehicle or its drivetrain could be damaged.

To ensure that the vehicle is secured against rolling away unintentionally:

- the parking brake must be applied.
- the transmission must be in position P and the SmartKey must be removed from the ignition lock.
- on uphill or downhill gradients, the front wheels must be turned towards the curb.

# Switching off the engine

# Important safety notes



#### **↑** WARNING

The automatic transmission switches to neutral position N when you switch off the engine. The vehicle may roll away. There is a risk of an accident.

After switching off the engine, always switch to parking position **P**. Prevent the parked vehicle from rolling away by applying the parking brake.



#### Vehicles with automatic transmission

- Apply the parking brake firmly.
- ▶ Shift the transmission to position **P**.

#### Using the SmartKey

- ► Turn the SmartKey to position **0** in the ignition lock and remove it. The immobilizer is activated.
- 1 The SmartKey can only be removed if the transmission is in position P.

#### Using KEYLESS-GO

- ▶ Press the Start/Stop button (▷ page 141). The engine stops and all the indicator lamps in the instrument cluster go out.
- When the driver's door is closed, this corresponds to key position 1. When the driver's door is open, this corresponds to key position 0: "key removed".
- 1 In the event of an emergency, the engine can be turned off while the vehicle is in motion by pressing and holding the Start/ Stop button for three seconds.

### Parking brake



#### **↑** WARNING

If you must brake the vehicle with the parking brake, the braking distance is considerably longer and the wheels could lock. There is an increased danger of skidding and accidents.

Only use the parking brake to brake the vehicle when the service brake is faulty. Do not apply the parking brake too firmly. If the wheels lock, release the parking brake until the wheels begin turning again.

# **↑** WARNING


If you leave children unsupervised in the vehicle, they could set it in motion by, for example:

- releasing the parking brake
- · shifting the automatic transmission out of the parking position P
- starting the engine.

They could also operate the vehicle's equipment. There is a risk of an accident and injury.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Never leave children unsupervised in the vehicle.

If you brake the vehicle with the parking brake, the brake lamps will not light up.



- ▶ To apply: depress parking brake ② firmly. When the engine is running, the BRAKE (USA only) or (Canada only) indicator lamp lights up in the instrument cluster.
- ► To release: depress the brake pedal and keep it depressed.
- ▶ Pull release handle ①. When the ignition is switched on or the engine is running, the BRAKE (USA only) or (Canada only) indicator lamp goes out in the instrument cluster.

# Parking the vehicle for a long period

If you leave the vehicle parked for longer than four weeks, the battery may be damaged by exhaustive discharging.



- ► Connecting a trickle charger.
- 1 You can obtain information about trickle chargers from a qualified specialist workshop.

If you leave the vehicle parked for longer than six weeks, the vehicle may suffer damage as a result of lack of use.

► Visit a qualified specialist workshop and seek advice.

# **Driving tips**

# General driving tips

#### Important safety notes



#### **↑** WARNING

If you switch off the ignition while driving, safety-relevant functions are only available with limitations, or not at all. This could affect. for example, the power steering and the brake boosting effect. You will require considerably more effort to steer and brake. There is a risk of an accident.

Do not switch off the ignition while driving.



#### **↑** WARNING

If you operate mobile communication equipment while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident.

Only operate this equipment when the vehicle is stationary.

Observe the legal requirements for the country in which you are driving. Some jurisdictions prohibit the driver from using a mobile phone while driving a vehicle.

If you make a call while driving, always use hands-free mode. Only operate the telephone when the traffic situation permits. If you are unsure, pull over to a safe location and stop before operating the telephone.

Bear in mind that at a speed of only 30 mph (approximately 50 km/h), the vehicle covers a distance of 44 feet (approximately 14 m) per second.

## Drive sensibly - save fuel

Observe the following tips to save fuel:

- ▶ The tires should always be inflated to the recommended tire pressure.
- Remove unnecessary loads.
- ▶ Remove roof racks when they are not needed.
- ▶ Warm up the engine at low engine speeds.
- Avoid frequent acceleration or braking.
- ► Have all maintenance work carried out as indicated by the service intervals in the Maintenance Booklet or by the service interval display.

Fuel consumption also increases when driving in cold weather, in stop-start traffic and in hilly terrain.

### Drinking and driving



#### **↑** WARNING

Drinking and driving and/or taking drugs and driving are very dangerous combinations. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgment.

The possibility of a serious or even fatal accident are greatly increased when you drink or take drugs and drive.

Do not drink or take drugs and drive or allow anyone to drive who has been drinking or taking drugs.

#### **Emission control**



#### **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There is a risk of fatal injury. Therefore never leave the engine running in enclosed spaces without sufficient ventilation.



Certain engine systems are designed to keep the level of poisonous components in exhaust fumes within legal limits.

These systems only work at peak efficiency if they are serviced exactly in accordance with the manufacturer's specifications. For this reason, all work on the engine must be carried out by qualified and authorized Mercedes-Benz technicians.

The engine settings must not be changed under any circumstances. Furthermore, all specific service work must be carried out at regular intervals and in accordance with the Mercedes-Benz service requirements. Details can be found in the Maintenance Booklet.

### **ECO** display

The ECO display gives you information on how economical your driving style is. The ECO display assists you in achieving the optimum driving style in terms of consumption, taking the actual and selected conditions into consideration. Your driving style can significantly influence the vehicle's consumption.



Example: ECO display

The ECO display consists of three bars:

- Acceleration
- Constant
- Coasting

The percent value is the average value of the three bars. The three bars and the mean value begin at the value of 50%. A higher percentage indicates a more economical driving style.

The ECO display does not indicate the actual fuel consumption and a fixed percentage

count in the ECO display does not indicate a fixed consumption figure.

Apart from driving style, consumption is dependent on many factors such as, e.g.:

- load
- tire pressure
- · cold start
- · choice of route
- · electrical consumers switched on

These factors are not taken into consideration by the ECO display.

The evaluation of your driving style is carried out using the following three categories:

- Acceleration (evaluation of all acceleration processes):
- The bar fills up: moderate acceleration, especially at higher speeds
- The bar empties: sporty acceleration
- Constant (assessment of driving behavior at all times):
  - The bar fills up: constant speed and avoidance of unnecessary acceleration and deceleration
- The bar empties: fluctuations in speed
- Coasting (assessment of all deceleration processes):
  - The bar fills up: anticipatory driving, keeping your distance and early release of the accelerator. The vehicle can coast without use of the brakes.
  - The bar empties: frequent braking
- An economical driving style specially requires driving at moderate engine speeds.

To achieve a higher value in the categories Acceleration and Constant:

- observe the gearshift recommendations.
- drive in drive program E.
- On long journeys at a constant speed, e.g. on the highway, only the bar for Constant will change.



1 The ECO display summaries the driving characteristics from the start of the journey to its completion. For this reason, the bars change dynamically at the beginning of the journey. On longer journeys, there are fewer changes. For more dynamic changes, carry out a manual reset.

Further information on the ECO display (⊳ page 220).

#### **Brakes**

### Important safety notes



#### **↑** WARNING

If you shift down on a slippery road surface in an attempt to increase the engine's braking effect, the drive wheels could lose their grip. There is an increased danger of skidding and accidents.

Do not shift down for additional engine braking on a slippery road surface.

# Downhill gradients

I On long and steep gradients, you must reduce the load on the brakes by shifting early to a lower gear. This allows you to take advantage of the engine braking effect and helps avoid overheating and excessive wear of the brakes.

When you take advantage of the engine braking effect, a drive wheel may not turn for some time, e.g. on a slippery road surface. This could cause damage to the drive train. This type of damage is not covered by the Mercedes-Benz warranty.

# Heavy and light loads



#### **↑** WARNING

If you rest your foot on the brake pedal while driving, the braking system can overheat. This increases the stopping distance and can even cause the braking system to fail. There is a risk of an accident.

Never use the brake pedal as a footrest. Never depress the brake pedal and the accelerator pedal at the same time.

Depressing the brake pedal constantly results in excessive and premature wear to the brake pads.

If the brakes have been subjected to a heavy load, do not stop the vehicle immediately. Drive on for a short while. This allows the airflow to cool the brakes more quickly.

#### Wet roads

If you have driven for a long time in heavy rain without braking, there may be a delayed reaction from the brakes when braking for the first time. This may also occur after the vehicle has been washed.

You have to depress the brake pedal more firmly. Maintain a greater distance from the vehicle in front.

After driving on a wet road or having the vehicle washed, brake firmly while paying attention to the traffic conditions. This will warm up the brake discs, thereby drying them more quickly and protecting them against corrosion.

#### Limited braking performance on salttreated roads

If you drive on salted roads, a layer of salt residue may form on the brake discs and brake pads. This can result in a significantly longer braking distance.

- Brake occasionally to remove any possible salt residue. Make sure that you do not endanger other road users when doing so.
- Carefully depress the brake pedal and the beginning and end of a journey.
- Maintain a greater distance to the vehicle ahead.



#### Servicing the brakes

If the red brake warning lamp lights up in the instrument cluster and you hear a warning tone while the engine is running. the brake fluid level may be too low. Observe additional warning messages in the multifunction display.

The brake fluid level may be too low due to brake pad wear or leaking brake lines.

Have the brake system checked immediately. This work should be carried out at a qualified specialist workshop.

All checks and maintenance work on the brake system must be carried out at a qualified specialist workshop. Consult a qualified specialist workshop to arrange this. Have brake pads installed and brake fluid replaced at a qualified specialist workshop.

- Vehicles with 4MATIC: function or performance tests may only be carried out on a 2-axle dynamometer. If you are planning to have the vehicle tested on such a dynamometer, contact an authorized Mercedes-Benz Center to obtain further information first. Otherwise, you could damage the drive train or the brake system.
- As the ESP<sup>®</sup> system operates automatically, the engine and the ignition must be switched off (SmartKey in position **0** or **1** in the ignition lock) when:
  - testing the parking brake on a brake dynamometer.
  - you intend to have the vehicle towed with the front or rear axle raised (not permitted for vehicles with 4MATIC).

Braking maneuvers triggered automatically by ESP® may seriously damage the brake system.

If the brake system has only been subject to moderate loads, you should test the functionality of your brakes at regular intervals. To do so, press firmly on the brake pedal when driving at a high speed. This improves the grip of the brake pads.

You can find a description of Brake Assist (BAS) on ( $\triangleright$  page 65).

Mercedes-Benz recommends that you only have brake pads/linings installed on your vehicle which have been approved for Mercedes-Benz vehicles or which correspond to an equivalent quality standard. Brake pads/linings which have not been approved for Mercedes-Benz vehicles or which are not of an equivalent quality could affect your vehicle's operating safety.

Mercedes-Benz recommends that you only use brake fluid that has been specially approved for your vehicle by Mercedes-Benz, or which corresponds to an equivalent quality standard. Brake fluid which has not been approved for Mercedes-Benz vehicles or which is not of an equivalent quality could affect your vehicle's operating safety.

### Parking brake

#### **↑** WARNING

If you must brake the vehicle with the parking brake, the braking distance is considerably longer and the wheels could lock. There is an increased danger of skidding and accidents.

Only use the parking brake to brake the vehicle when the service brake is faulty. Do not apply the parking brake too firmly. If the wheels lock, release the parking brake until the wheels begin turning again.

If you brake the vehicle with the parking brake, the brake lamps will not light up. If you drive on wet roads or dirt-covered surfaces, road salt and/or dirt could get into the parking brake.

In order to prevent corrosion and a reduction in the braking power of the parking brake, observe the following:

- gently depress the parking brake from time to time before beginning the journey.
- drive for approximately 110 vds (100 m) at a maximum speed of 12 mph (20 km/h).



# **Driving on wet roads**

### Hydroplaning

If water has accumulated to a certain depth on the road surface, there is a danger of hydroplaning occurring, even if:

- you drive at low speeds.
- the tires have adequate tread depth.

For this reason, in the event of heavy rain or in conditions in which hydroplaning may occur, you must drive in the following manner:

- lower your speed.
- · avoid ruts.
- brake carefully.

### Driving on flooded roads

■ Do not drive through flooded areas. Check the depth of any water before driving through it. Drive slowly through standing water. Otherwise, water may enter the vehicle interior or the engine compartment. This can damage the electronic components in the engine or the automatic transmission. Water can also be drawn in by the engine's air suction nozzles and this can cause engine damage.

Prevent water from entering the vehicle interior or the engine compartment. If you must drive through standing water, bear in mind that:

- the maximum permissible depth in still water is 12 in (30 cm)
- you should drive no faster than at walking pace

# Winter driving

# Important safety notes



#### 

If you shift down on a slippery road surface in an attempt to increase the engine's braking effect, the drive wheels could lose their grip.

There is an increased danger of skidding and accidents.

Do not shift down for additional engine braking on a slippery road surface.



#### **↑** DANGER

If the exhaust pipe is blocked or adequate ventilation is not possible, poisonous gases such as carbon monoxide (CO) may enter the vehicle. This is the case, e.g. if the vehicle becomes trapped in snow. There is a risk of fatal injury.

If you leave the engine or the auxiliary heating running, make sure the exhaust pipe and area around the vehicle are clear of snow. To ensure an adequate supply of fresh air, open a window on the side of the vehicle that is not facing into the wind.

Have your vehicle winterproofed at a qualified specialist workshop at the onset of winter. Observe the notes in the "Winter operation" section (⊳ page 330).

### **Driving with summer tires**

Observe the notes in the "Winter operation" section (⊳ page 330).

# Slippery road surfaces



#### ↑ WARNING

If you shift down on a slippery road surface in an attempt to increase the engine's braking effect, the drive wheels could lose their grip. There is an increased danger of skidding and accidents.

Do not shift down for additional engine braking on a slippery road surface.

Drive particularly carefully on slippery road surfaces. Avoid sudden acceleration, steering and braking maneuvers. Do not use the cruise control or DISTRONIC PLUS.

If the vehicle threatens to skid or cannot be stopped when moving at low speed:

► Shift the transmission to position N.



1 For more information on driving with snow chains, see (⊳ page 331).

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Changes in the outside temperature are displayed after a short delay.

Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges. The vehicle could skid if you fail to adapt your driving style. Always adapt your driving style and drive at a speed to suit the prevailing weather conditions

You should pay special attention to road conditions when temperatures are around freezing point.

# Off-road driving

### Important safety notes



#### **↑** WARNING

If you drive on a steep incline at an angle or turn when driving on an incline, the vehicle could slip sideways, tip and rollover. There is a risk of an accident.

Always drive on a steep incline in the line of fall (straight up or down) and do not turn the vehicle.

When driving off-road, sand, mud and water, possibly mixed with oil, for example, could get into the brakes. This could result in a reduced braking effect or in total brake failure and also in increased wear and tear. The braking characteristics change depending on the material ingressing the brakes. Clean the brakes after driving off-road. If you detect a reduced braking effect or grinding noises, have the brake system checked in a qualified specialist workshop as soon as possible. Adapt your driving style to the different braking characteristics.

Driving off-road increases the likelihood of damage to the vehicle, which, in turn, can lead to failure of the mechanical assembly or systems. Adapt your driving style to suit the terrain conditions. Drive carefully. Have damage to the vehicle rectified immediately at a qualified specialist workshop.

Do not switch to transmission position N when driving off-road. If you try to brake the vehicle using the service brake, you could lose control of the vehicle. If the gradient is too steep for your vehicle, drive back down in reverse gear.

#### General notes

#### **Environmental note**

Protection of the environment is of primary importance. Treat nature with respect. Observe all prohibiting signs.

Read this section carefully before driving your vehicle off-road. Practice by driving over more gentle off-road terrain first.

Familiarize yourself with the characteristics of your vehicle and the gear shift operation before driving through difficult terrain.

# Checklist before driving off-road

If the engine oil warning lamp lights up while the vehicle is in motion, stop the vehicle in a safe place as soon as possible. Check the engine oil level. The engine oil warning lamp warning must not be ignored. Continuing the journey while the symbol is displayed could lead to engine damage.

# Checklist after driving off-road

Driving over rough terrain places greater demands on your vehicle than driving on normal roads. After driving off-road, check the vehicle. This allows you to detect damage promptly and reduce the risk of an accident to yourself and other road users.



### Driving on sand

Observe the following rules when driving on

- select a shift range appropriate to the terrain.
- drive quickly to overcome the rolling resistance. Otherwise the vehicle's wheels could become stuck in loose ground.
- drive in the tracks of other vehicles if possible. Make sure that:
  - the tire ruts are not too deep.
  - the sand is sufficiently firm.
  - the ground clearance of the vehicle is sufficient.

### Tire ruts and gravel roads

Observe the following rules when driving along ruts in off-road terrain or on roads with loose gravel:

Check that the ruts are not too deep and that your vehicle has sufficient clearance. Otherwise, your vehicle could be damaged or bottom out and get stuck.

# **Crossing obstacles**

Obstacles could damage the floor of the vehicle or components of the chassis. Ask passengers for guidance when driving over large obstacles. The passenger should always keep a safe distance from the vehicle when doing so in order to avoid injury as a result of unexpected vehicle movements. After driving off-road or over obstacles, check the vehicle for possible damage, especially to the underbody and the components of the chassis.

Observe the following rules when driving over tree stumps, large stones and other obstacles:

- · avoid high engine speeds.
- select shift range 1.

- · drive very slowly.
- try to drive straight over the center of obstacles: front wheel first, then rear wheel.

### Traveling uphill

# Approach/departure angle

#### ★ WARNING

If you drive on a steep incline at an angle or turn when driving on an incline, the vehicle could slip sideways, tip and rollover. There is a risk of an accident.

Always drive on a steep incline in the line of fall (straight up or down) and do not turn the vehicle.

- Observe the rules on off-road driving.
- Do not drive at an angle on slopes, inclines or gradients, but instead follow the direct line of fall. The maximum gradient-climbing capability of your vehicle is 100%, which corresponds to an approach/departure angle of 45°. Note that the climbing ability of your vehicle depends on the terrain conditions.
- · Before tackling steep downhill gradients, select shift range 1.
- Drive slowly.
- Avoid high engine speeds. Drive at appropriate engine speeds (maximum 3000 rpm).
- When driving down an incline, make use of the engine's braking effect. Observe the engine speed; do not overrev the engine.
- Check the brakes after prolonged off-road driving.
- Hill start assist will aid you when pulling away on a hill.

For more information, see "Hill start assist" (⊳ page 144).

Do not switch to transmission position N when driving off-road. If you try to brake the vehicle using the service brake, you could



lose control of the vehicle. If the gradient is too steep for your vehicle, drive back down in reverse gear.

# Maximum gradient-climbing capability

If the load on the front axle is reduced when pulling away on a steep uphill slope, the front wheels have a tendency to spin. 4ETS recognizes this and brakes the wheels accordingly. The rear wheel torque is increased, making it easier to drive off.

# Hilltops

When driving up an uphill gradient, slightly reduce pressure on the accelerator immediately before reaching the brow of the hill. Make use of the vehicle's own impetus to travel over the brow.

This style of driving prevents:

- the vehicle from lifting off the ground on the brow of a hill
- the vehicle from traveling too quickly down the other side

# **Driving downhill**

- Drive slowly.
- Do not drive at an angle down steep inclines. Steer into the line of fall and drive with the front wheels aligned straight.
   Otherwise, the vehicle could slip sideways, tip and rollover.
- Before tackling steep downhill gradients, select shift range 1.
- Activate DSR. If this is not sufficient, brake gently. When doing so, make sure that the vehicle is facing in the direction of the line of fall.
- Check that the brakes are working normally after a long downhill stretch.

### **Driving systems**

#### **Cruise Control**

#### Important safety notes

Cruise control maintains a constant road speed for you. It brakes automatically in order to avoid exceeding the set speed. On long and steep downhill gradients, especially if the vehicle is laden or towing a trailer, you must select shift range 1, 2 or 3 in good time. By doing so, you will make use of the braking effect of the engine. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

Use cruise control only if road and traffic conditions make it appropriate to maintain a steady speed for a prolonged period. You can store any road speed above 20 mph (30 km/h).

If you fail to adapt your driving style, cruise control can neither reduce the risk of an accident nor override the laws of physics. Cruise control cannot take into account the road, traffic and weather conditions. Cruise control is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

Do not use cruise control:


- in road and traffic conditions which do not allow you to maintain a constant speed e.g. in heavy traffic or on winding roads
- on slippery road surfaces. Braking or accelerating could cause the drive wheels to lose traction and the vehicle could then skid
- when there is poor visibility, e.g. due to fog, heavy rain or snow

If there is a change of drivers, advise the new driver of the speed stored.

1 Cruise control should not be activated when driving off-road.



#### Cruise control lever



- 1) To activate or increase speed
- (2) To activate or reduce speed
- ③ To deactivate cruise control
- To activate at the current speed/last stored speed

When you activate cruise control, the stored speed is shown in the multifunction display for five seconds. In the multifunction display, the segments between the stored speed and the maximum speed light up.

# Storing and maintaining the current speed

You can store the current speed if you are driving faster than 20 mph (30 km/h).

- ➤ Accelerate the vehicle to the desired speed.
- ▶ Briefly press the cruise control lever up ① or down ②.
- ► Remove your foot from the accelerator pedal.
  - Cruise control is activated. The vehicle automatically maintains the stored speed.
- Cruise control may be unable to maintain the stored speed on uphill gradients. The stored speed is resumed when the gradient evens out. Cruise control maintains the stored speed on downhill gradients by automatically applying the brakes.

# Storing the current speed or calling up the last stored speed



#### **↑** WARNING

If you call up the stored speed and it differs from the current speed, the vehicle accelerates or decelerates. If you do not know the stored speed, the vehicle could accelerate or brake unexpectedly. There is a risk of an accident.

Pay attention to the road and traffic conditions before calling up the stored speed. If you do not know the stored speed, store the desired speed again.

- ▶ Briefly pull the cruise control lever towards you ④.
- ► Remove your foot from the accelerator pedal.

The first time cruise control is activated, it stores the current speed or regulates the speed of the vehicle to the previously stored speed.

### Setting a speed

Keep in mind that it may take a brief moment until the vehicle has accelerated or braked to the speed set.

- ► Press the cruise control lever up ① for a higher speed or down ② for a lower speed.
- ➤ To adjust the set speed in 1 mph increments (1 km/h increments): briefly press the cruise control lever up ① or down ② to the pressure point.

  Every time the cruise control lever is pressed up ① or down ② the last speed stored is increased or reduced.
- ➤ To adjust the set speed in 5 mph increments (10 km/h increments): briefly press the cruise control lever up ① or down ② beyond the pressure point.

Every time the cruise control lever is pressed up ① or down ② the last speed stored is increased or reduced.



 Cruise control is not deactivated if you depress the accelerator pedal. For example, if you accelerate briefly to overtake, cruise control adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

#### Deactivating cruise control

There are several ways to deactivate cruise control:

▶ Briefly press the cruise control lever forwards (3).

or

▶ Brake.

Cruise control is automatically deactivated if:

- you depress the parking brake.
- you are driving at less than 20 mph (30 km/h).
- ESP® intervenes or you deactivate ESP®.
- you shift the transmission to position N while driving.

If cruise control is deactivated, you will hear a warning tone. You will see the Cruise Control Off message in the multifunction display for approximately five seconds.

1 When you switch off the engine, the last speed stored is cleared.

#### **DISTRONIC PLUS**

# Important safety notes

DISTRONIC PLUS regulates the speed and automatically helps you maintain the distance to the vehicle detected in front. DISTRONIC PLUS brakes automatically so that the set speed is not exceeded.

On long and steep downhill gradients, especially if the vehicle is laden, you must select shift range 1, 2 or 3 in good time. By doing so, you will make use of the braking effect of the engine. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly.

If DISTRONIC PLUS detects a slower-moving vehicle in front, your vehicle is braked in order to maintain the preset distance to the vehicle in front



#### **↑** WARNING

DISTRONIC PLUS does not react to:

- people or animals
- stationary obstacles on the road, e.g. stopped or parked vehicles
- oncoming and crossing traffic

As a result, DISTRONIC PLUS may neither give warnings nor intervene in such situations.

There is a risk of an accident.

Always pay careful attention to the traffic situation and be ready to brake.



#### / WARNING

DISTRONIC PLUS cannot always clearly identify other road users and complex traffic situations.

In such cases, DISTRONIC PLUS may:

- give an unnecessary warning and then brake the vehicle
- neither give a warning nor intervene
- · accelerate unexpectedly

There is a risk of an accident.

Continue to drive carefully and be ready to brake, in particular when warned to do so by DISTRONIC PLUS.



#### **↑** WARNING

DISTRONIC PLUS brakes your vehicle with up to 40% of the maximum braking force. If this braking force is insufficient, DISTRONIC PLUS warns you visually and audibly. There is a risk of an accident.

In such cases, apply the brakes yourself and try to take evasive action.



- I If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:
  - when towing the vehicle
  - · in the car wash

If you fail to adapt your driving style, DISTRONIC PLUS can neither reduce the risk of accident nor override the laws of physics. DISTRONIC PLUS cannot take into account the road, traffic and weather conditions. DISTRONIC PLUS is only an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

Do not use DISTRONIC PLUS:

- in road and traffic conditions which do not allow you to maintain a constant speed e.g. in heavy traffic or on winding roads
- on slippery road surfaces. Braking or accelerating could cause the drive wheels to lose traction and the vehicle could then skid
- when there is poor visibility, e.g. due to fog, heavy rain or snow

DISTRONIC PLUS may not detect narrow vehicles driving in front, e.g. motorcycles, or vehicles driving on a different line.

In particular, the detection of obstacles can be impaired if:

- dirt on the sensors or anything else covering the sensors
- snow or heavy rain
- interference by other radar sources
- strong radar reflections, for example, in parking garages

If DISTRONIC PLUS no longer detects a vehicle in front, DISTRONIC PLUS may unexpectedly accelerate the vehicle to the stored speed.

This speed may:

- be too high if you are driving in a filter lane or an exit lane
- be so high when driving in the right-hand lane that you overtake vehicles in the lefthand lane
- be so high when driving in the left-hand lane that you overtake vehicles in the right-hand lane

If there is a change of drivers, advise the new driver of the speed stored.

For DISTRONIC PLUS to assist you when driving, the radar sensor system must be:

- activated (⊳ page 229)
- operational

If there is no vehicle in front, DISTRONIC PLUS operates in the same way as cruise control in the speed range between 20 mph (Canada: 30 km/h) and 120 mph (Canada: 200 km/h). If a vehicle is driving in front of you, it operates in the speed range between 0 mph (0 km/h) and 120 mph (Canada: 200 km/h).

Do not use DISTRONIC PLUS while driving on roads with steep gradients.

As DISTRONIC PLUS transmits radar waves, it can resemble the radar detectors of the responsible authorities. You can refer to the relevant chapter in the Operator's Manual if questions are asked about this.

① USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removing, tampering with, or altering the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.


Any unauthorized modification to this device could void the user's authority to operate the equipment.



- Canada only: This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:
  - 1. This device may not cause harmful interference, and
  - 2. this device must accept any interference received, including interference that may cause undesired operation of the device. Removal, tampering, or altering of the device will void any warranties, and is not permitted. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

#### Cruise control lever



- To store the current speed or a higher speed
- ② To store the current speed or a lower speed
- ③ To deactivate DISTRONIC PLUS
- To store the current speed or call up the last stored speed
- (5) To set the specified minimum distance

# Switching on DISTRONIC PLUS, storing and maintaining the current speed

#### **Activation conditions**

In order to activate DISTRONIC PLUS, the following conditions must be fulfilled:

- the engine must be started. It may take up to two minutes after pulling away before DISTRONIC PLUS is operational.
- the parking brake must be released.
- ESP® must be active, but not intervening.
- Active Parking Assist must not be activated.
- the transmission must be in position **D**.
- the hood must be closed.
- the driver's door must be closed when you shift from P to D or your seat belt must be fastened.
- the front-passenger door and rear doors must be closed.
- the vehicle must not skid.

### Activating while driving

You can only activate DISTRONIC PLUS when driving at speeds below 20 mph (30 km/h) if the vehicle in front has been detected and is shown in the multifunction display. If the vehicle in front is no longer detected and displayed, DISTRONIC PLUS switches off and a tone sounds.

- ▶ Briefly pull the cruise control lever towards you ④, or press it up ① or down ②.

  DISTRONIC PLUS is selected.
- ▶ Press the cruise control lever repeatedly up ① or down ② until the desired speed is set.
- ▶ Remove your foot from the accelerator pedal.
  - Your vehicle adapts its speed to that of the vehicle in front, but only up to the desired stored speed.
- 1 If you do not fully release the accelerator pedal, the DISTRONIC PLUS Override message appears in the multifunction



display. The set distance to a slowermoving vehicle in front will then not be maintained. You will be driving at the speed you determine by the position of the accelerator pedal.

## Activating when driving towards a stationary vehicle

If the vehicle in front of you is stationary, you can only activate DISTRONIC PLUS once your vehicle is stationary as well.

- ▶ Briefly pull the cruise control lever towards you (4), or press it up (1) or down (2). DISTRONIC PLUS is selected.
- DISTRONIC PLUS can only be activated at under 20 mph (30 km/h) if a vehicle in front has been detected. Therefore, the DISTRONIC PLUS distance display in the instrument cluster should be activated (⊳ page 224).
- ▶ Press the cruise control lever repeatedly up (1) or down (2) until the desired speed is set.
- 1 You can use the cruise control lever to set the stored speed and the control on the cruise control lever to set the specified minimum distance (⊳ page 175).

#### Pulling away

- ▶ If the vehicle in front pulls away: remove your foot from the brake pedal.
- ▶ Briefly pull the cruise control lever towards you (4).

or

► Accelerate briefly. Your vehicle pulls away and adapts its speed to that of the vehicle in front.

#### Driving

If there is no vehicle in front, DISTRONIC PLUS operates in the same way as cruise control.

If DISTRONIC PLUS detects that the vehicle in front has slowed down, it brakes your

vehicle. In this way, the distance you have selected is maintained.

If DISTRONIC PLUS detects that the vehicle in front is driving faster, it accelerates your vehicle, but only up to the speed you have stored

#### Changing lanes

If you change to the passing lane, DISTRONIC PLUS supports you when:

- you are driving faster than 40 mph (60 km/h)
- DISTRONIC PLUS is maintaining the distance to a vehicle in front
- you switch on the appropriate turn signal
- DISTRONIC PLUS does not detect a danger of collision

If these conditions are fulfilled, your vehicle is accelerated. Acceleration will be interrupted if changing lanes takes too long or if the distance between your vehicle and the vehicle in front becomes too small.

1 When changing lanes, DISTRONIC PLUS monitors the left lane on left-hand drive vehicles and the right lane on right-hand drive vehicles.

# Stopping

#### **↑** WARNING

When leaving the vehicle, even if it is braked only by DISTRONIC PLUS, it could roll away if:

- there is a malfunction in the system or in the voltage supply.
- DISTRONIC PLUS has been deactivated with the cruise control lever, e.g. by a vehicle occupant or from outside the vehicle.
- the electrical system in the engine compartment, the battery or the fuses have been tampered with.
- the battery is disconnected.
- the accelerator pedal has been depressed, e.g. by a vehicle occupant.

There is a risk of an accident.



If you wish to exit the vehicle, always turn off DISTRONIC PLUS and secure the vehicle against rolling away.

Deactivating DISTRONIC PLUS (> page 177).

If DISTRONIC PLUS detects that the vehicle in front is stopping, it brakes your vehicle until it is stationary.

Once your vehicle is stationary, it remains stationary and you do not need to depress the brake.

1 Depending on the specified minimum distance, your vehicle will come to a standstill at a sufficient distance behind the vehicle in front. The specified minimum distance is set using the control on the cruise control lever.

When DISTRONIC PLUS is activated, the transmission is shifted automatically to position **P** if:

- the driver's door is open and the driver's seat belt is unfastened.
- the engine is switched off, unless it is automatically switched off by the ECO start/stop function.
- the hood is opened.
- · a system malfunction occurs.
- the power supply is not sufficient.

# Setting a speed

- ▶ Press the cruise control lever up ① for a higher speed or down ② for a lower speed.
- ► To adjust the set speed in 1 mph increments (1 km/h increments): briefly press the cruise control lever up ① or down ② to the pressure point.

  Every time the cruise control lever is pressed up ① or down ② the last speed stored is increased or reduced.
- ► To adjust the set speed in 5 mph increments (10 km/h increments): briefly press the cruise control lever

up ① or down ② beyond the pressure point.

Every time the cruise control lever is pressed up ① or down ②, the last speed stored is increased or reduced.

1 DISTRONIC PLUS is not deactivated if you depress the accelerator pedal. If you accelerate to overtake, DISTRONIC PLUS adjusts the vehicle's speed to the last speed stored after you have finished overtaking.

# Storing the current speed or calling up a stored speed

- ▶ Briefly pull the cruise control lever towards you ④.
- ▶ Remove your foot from the accelerator pedal.


  DISTRONIC PLUS is activated. The first time it is activated, the current speed is stored. Otherwise, it sets the vehicle cruise speed to the previously stored value.

# Setting the specified minimum distance

You can set the specified minimum distance for DISTRONIC PLUS by varying the time span between one and two seconds. With this function, you can set the minimum distance that DISTRONIC PLUS keeps to the vehicle in front, dependent on vehicle speed. You can see this distance in the multifunction display (> page 176).

Make sure that you maintain a sufficient distance to the vehicle in front and comply with the minimum distance as required by law. Adjust the distance to the vehicle in front if necessary.






► To increase: turn control ② in direction ③.

DISTRONIC PLUS then maintains a greater distance between your vehicle and the vehicle in front.

➤ To decrease: turn control ② in direction ①.

DISTRONIC PLUS then maintains a shorter distance between your vehicle and the vehicle in front.

# DISTRONIC PLUS displays in the speedometer



When DISTRONIC PLUS is activated, one or two segments ② in the set speed range light up.

in the speedometer may differ slightly from the speed set for DISTRONIC PLUS.

If DISTRONIC PLUS detects a vehicle in front, segments ② between speed of the vehicle in front ① and stored speed ③ light up.

# DISTRONIC PLUS displays in the multifunction display

#### **General notes**

In the Assistance menu (> page 224) of the on-board computer, you can select the distance display.

# Display when DISTRONIC PLUS is deactivated

► Select the Distance Display function using the on-board computer (> page 224).

When DISTRONIC PLUS is deactivated, you will see the following in the multifunction display:



- ① Symbol for the activated PRE-SAFE® Brake
- (2) Vehicle in front, if detected
- ③ Distance indicator, current distance to the vehicle in front
- 4 Specified minimum distance to the vehicle in front; adjustable
- (5) Own vehicle

# Display when DISTRONIC PLUS is activated

► Select the Distance Display function using the on-board computer (> page 224).


You will see the stored speed for about five seconds when you activate DISTRONIC PLUS. After this time, you will see the following in the multifunction display while DISTRONIC PLUS is activated:





- ① DISTRONIC PLUS activated
- ② Own vehicle
- ③ Specified minimum distance to the vehicle in front; adjustable
- 4 Vehicle in front, if detected

### **Deactivating DISTRONIC PLUS**



There are several ways to deactivate DISTRONIC PLUS:

▶ Briefly press the cruise control lever forwards ①.

or

▶ Brake, unless the vehicle is stationary.

When you deactivate DISTRONIC PLUS, you will see the DISTRONIC PLUS Off message in the multifunction display for approximately five seconds.

The last speed stored remains stored until you switch off the engine. DISTRONIC PLUS is automatically deactivated if:

- you engage the parking brake
- you are driving slower than 15 mph (25 km/h) and there is no vehicle in front, or if the vehicle in front is no longer detected
- ESP® intervenes or you deactivate ESP®
- the transmission is in the P, R or N position
- you switch off the radar sensor system
   (▷ page 229)
- you pull the cruise control lever towards you in order to pull away and the frontpassenger door or one of the rear doors is open
- · the vehicle has skidded

If DISTRONIC PLUS is deactivated, you will hear a warning tone. You will see the DISTRONIC PLUS Off message in the multifunction display for approximately five seconds.

If the vehicle has been stopped by DISTRONIC PLUS and a malfunction occurs in the system, the **Brake Immediately** message appears in the multifunction display. Depress the brake pedal immediately so that the vehicle does not roll away. DISTRONIC PLUS is then deactivated, and the message disappears.


# Tips for driving with DISTRONIC PLUS

#### **General notes**

The following contains descriptions of certain road and traffic conditions in which you must be particularly attentive. In such situations, brake if necessary. DISTRONIC PLUS is then deactivated.




# Cornering, going into and coming out of a bend




The ability of DISTRONIC PLUS to detect vehicles when cornering is limited. Your vehicle may brake unexpectedly or late.

#### Vehicles traveling on a different line




DISTRONIC PLUS may not detect vehicles traveling on a different line. The distance to the vehicle in front will be too short.

#### Other vehicles changing lanes




DISTRONIC PLUS has not detected the vehicle cutting in yet. The distance to this vehicle will be too short.

#### Narrow vehicles



DISTRONIC PLUS has not yet detected the vehicle in front on the edge of the road, because of its narrow width. The distance to the vehicle in front will be too short.

#### Obstructions and stationary vehicles



DISTRONIC PLUS does not brake for obstacles or stationary vehicles. If, for example, the detected vehicle turns a corner and reveals an obstacle or stationary vehicle, DISTRONIC PLUS will not brake for these.



## Crossing vehicles



DISTRONIC PLUS may mistakenly detect vehicles that are crossing your lane. Activating DISTRONIC PLUS at traffic lights with crossing traffic, for example, could cause your vehicle to pull away unintentionally.

#### **HOLD function**

## Important safety notes

#### **↑** WARNING

When leaving the vehicle, it can still roll away despite being braked by the HOLD function if:

- there is a malfunction in the system or in the voltage supply.
- the HOLD function has been deactivated by pressing the accelerator pedal or the brake pedal, e.g. by a vehicle occupant.
- the electrical system in the engine compartment, the battery or the fuses have been tampered with.
- · the battery is disconnected

There is a risk of an accident.

If you wish to exit the vehicle, always turn off the HOLD function and secure the vehicle against rolling away.

- If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:
  - · when towing the vehicle
  - in the car wash

Deactivate the HOLD function (▷ page 180).

#### General notes

The HOLD function can assist the driver in the following situations:

- · when pulling away, especially on steep slopes
- when maneuvering on steep slopes
- · when waiting in traffic

The vehicle is kept stationary without the driver having to depress the brake pedal.

The braking effect is canceled and the HOLD function deactivated when you depress the accelerator pedal to pull away.

1 Do not use the HOLD function when driving off-road, on steep uphill or downhill gradients or on slippery or loose surfaces. The HOLD function cannot hold the vehicle on such surfaces.

#### **Activation conditions**

You can activate the HOLD function if:

- the vehicle is stationary
- the engine is running or if it has been automatically switched off by the ECO start/stop function
- the driver's door is closed or your seat belt is fastened
- the parking brake is released
- · the hood is closed
- the transmission is in position D, R or N
- DISTRONIC PLUS is deactivated.



## **Activating the HOLD function**

- Make sure that the activation conditions are met.
- ▶ Depress the brake pedal.
- Quickly depress the brake pedal further until HOLD appears in the multifunction display.

The HOLD function is activated. You can release the brake pedal.

1 If depressing the brake pedal the first time does not activate the HOLD function, wait briefly and then try again.

## **Deactivating the HOLD function**

The HOLD function is deactivated automatically if:

- you accelerate and the transmission is in position **D** or **R**
- the transmission is in position P.
- you depress the brake pedal again with a certain amount of pressure until HOLD disappears from the multifunction display
- you activate DISTRONIC PLUS

When the HOLD function is activated, the automatic transmission is shifted automatically to position P if:

- the driver's door is open and the driver's seat belt is unfastened.
- the engine is switched off, unless it is automatically switched off by the ECO start/stop function.
- the hood is opened.
- a system malfunction occurs.
- the power supply is not sufficient.

The horn will also sound at regular intervals if the HOLD function is activated and you:

- switch the engine off, open the driver's door and remove your seat belt
- open the hood

The sounding of the horn alerts you to the fact that the vehicle has been parked while the HOLD function is still activated. If you attempt

to lock the vehicle, the tone becomes louder. The vehicle is not locked until the HOLD function is deactivated.

If the engine has been switched off, it cannot be started again until the HOLD function has been deactivated.

If there is a malfunction in the system or power supply while the HOLD function is activated, the Brake Immediately message is shown in the multifunction display. Immediately depress the brake firmly until the warning message in the multifunction display goes out.

You can also shift the transmission to position **P**. This deactivates the HOLD function.

#### **PARKTRONIC**

# Important safety notes

PARKTRONIC is an electronic parking aid with ultrasonic sensors. It indicates visually and audibly the distance between your vehicle and an object.

PARKTRONIC is only an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering, parking and exiting a parking space. When maneuvering, parking or pulling out of a parking space, make sure that there are no persons, animals or objects in the area in which you are maneuvering.

When parking, pay particular attention to objects above or below the sensors, such as flower pots or trailer drawbars.

PARKTRONIC does not detect such objects when they are in the immediate vicinity of the vehicle. You could damage the vehicle or the objects.

The sensors may not detect snow and other objects that absorb ultrasonic waves.

Ultrasonic sources such as an automatic car wash, the compressed-air brakes on a



truck or a pneumatic drill could cause PARKTRONIC to malfunction.


PARKTRONIC may not function correctly on uneven terrain.

PARKTRONIC is activated automatically when you:

- · switch on the ignition
- shift the transmission to position D, R or N
- · release the parking brake

PARKTRONIC is deactivated at speeds above 11 mph (18 km/h). It is reactivated at lower speeds.

PARKTRONIC monitors the area around your vehicle using six sensors in the front and four sensors in the rear.



 Sensors in the front bumper, left-hand side (example)


# Range of the sensors

#### General notes


PARKTRONIC does not take objects into consideration that are:

- below the detection range, e.g. people, animals or objects
- above the detection range, e.g. overhanging loads, truck overhangs or loading ramps

The sensors must be free from dirt, ice or slush. They can otherwise not function correctly. Clean the sensors regularly, taking care not to scratch or damage them (> page 307).



Side view



Top view

#### Front sensors

Center	Approx. 40 in (approx. 100 cm)
Corners	Approx. 24 in (approx. 60 cm)

#### Rear sensors

Center	Approx. 48 in (approx. 120 cm)
Corners	Approx. 32 in (approx. 80 cm)

#### Minimum distance

Center	Approx. 8 in (approx. 20 cm)
Corners	Approx. 6 in (approx. 15 cm)


If there is an obstacle within this range, the relevant warning displays light up and a



warning tone sounds. If the distance falls below the minimum, the distance may no longer be shown.

## Warning displays

The warning displays show the distance between the sensors and the obstacle. The warning display for the front area is located on the dashboard above the center air vents. The warning display for the rear area is located on the headliner in the rear compartment.



Warning display for the front area

- ① Segments on the left-hand side of the vehicle
- ② Segments on the right-hand side of the vehicle
- 3 Segments showing operational readiness

The warning display for each side of the vehicle is divided into five yellow and two red segments. PARKTRONIC is operational if yellow segments showing operational readiness ③ light up.

The selected transmission position and the direction in which the vehicle is rolling determine which warning display is active when the engine is running.

Transmission position	Warning display
D	Front area activated
<b>R</b> , <b>N</b> or the vehicle is rolling backwards	Rear and front areas activated
P	No areas activated

One or more segments light up as the vehicle approaches an obstacle, depending on the vehicle's distance from the obstacle.

#### From the:

- sixth segment onwards, you will hear an intermittent warning tone for approximately two seconds.
- seventh segment onwards, you will hear a warning tone for approximately two seconds. This indicates that you have now reached the minimum distance.

# Deactivating/activating PARKTRONIC



- ① Deactivating/activating PARKTRONIC
- ② Indicator lamp

If indicator lamp ② lights up, PARKTRONIC is deactivated.

PARKTRONIC is automatically activated when you turn the SmartKey to position 2 in the ignition lock.



# Towing a trailer

Fold in the ball coupling if the trailer tow hitch is not required. PARKTRONIC measures the minimum detection range to an obstacle from the bumper, not the ball coupling.

PARKTRONIC is deactivated for the rear area when you establish an electrical connection between your vehicle and a trailer.



#### Problems with PARKTRONIC

Problem	Possible causes/consequences and ▶ Solutions
Only the red segments in the PARKTRONIC warning displays are lit. You also hear a warning tone for approximately two seconds.  PARKTRONIC is deactivated after approximately five seconds, and the indicator lamp in the PARKTRONIC button lights up.	PARKTRONIC has malfunctioned and has switched off.  ▶ If problems persist, have PARKTRONIC checked at a qualified specialist workshop.
Only the red segments in the PARKTRONIC warning displays are lit. PARKTRONIC is deactivated after approximately five seconds.	The PARKTRONIC sensors are dirty or there is interference.  ► Clean the PARKTRONIC sensors (▷ page 307).  ► Switch the ignition back on.
	The problem may be caused by an external source of radio or ultrasound waves.  ▶ See if PARKTRONIC functions in a different location.

#### **Active Parking Assist**

# Important safety notes

Active Parking Assist is an electronic parking aid with ultrasound. Ultrasound is used to measure the road on both sides of the vehicle. A suitable parking space is indicated by the parking symbol. Active steering intervention can assist you during parking. You may also use PARKTRONIC (> page 180). When PARKTRONIC is switched off, Active Parking Assist is also unavailable.



# / WARNING

The vehicle swings out when parking and in doing so could cross into the opposite lane. This could result in a collision with another road user. There is a risk of an accident.

Pay attention to other road users when parking. Stop the vehicle if necessary or cancel the Active Parking Assist parking procedure.

I If unavoidable, you should drive over obstacles such as curbs slowly and not at a sharp angle. Otherwise, you may damage the wheels or tires.

Active Parking Assist is merely an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering, parking and exiting a parking space. When maneuvering, parking or pulling out of a parking space, make sure that there are no persons, animals or objects in the area in which you are maneuvering.



Use Active Parking Assist for parking spaces:

- that are parallel to the direction of travel
- that are on straight roads, not bends
- that are on the same level as the road, e.g. not on the pavement

#### Parking tips:

- On narrow roads, drive as close to the parking space as possible.
- Parking spaces that are littered, overgrown or partially occupied by trailer drawbars might be identified incorrectly or not at all.
- Snowfall or heavy rain may lead to a parking space being measured inaccurately.
- Pay attention to the PARKTRONIC (> page 182) warning messages during the parking procedure.
- You can intervene in the steering procedure to correct it at any time. Active Parking Assist will then be canceled.
- When transporting a load which protrudes from your vehicle, you should not use Active Parking Assist.
- when snow chains or an emergency spare wheel are mounted, you should not use Active Parking Assist here either.
- Make sure that the tire pressures are always correct. This has a direct influence on the parking characteristics of the vehicle.

# **Detecting parking spaces**

Objects located above the height range of Active Parking Assist will not be detected when the parking space is measured. These are not taken into account when the parking procedure is calculated, e.g. overhanging loads, tail sections or loading ramps of goods vehicles. In some circumstances, Active Parking Assist may therefore guide you into the parking space too early.


# **⚠** WARNING

If there are objects above the detection range, Active Parking Assist may turn prematurely. You may cause a collision as a result. There is a risk of an accident.

If there are objects above the detection range, stop and deactivate Active Parking Assist.

Active Parking Assist is switched on automatically when driving forwards. The system is operational at speeds of up to approximately 22 mph (35 km/h). While in operation, the system independently locates and measures parking spaces on both sides of the vehicle. When driving at speeds below 19 mph (30 km/h), you will see the parking symbol as a status indicator in the instrument cluster. By default, Active Parking Assist only displays parking spaces on the frontpassenger side. Parking spaces on the driver's side are displayed as soon as the turn signal on the driver's side is activated. To park on the driver's side, you must leave the driver's side turn signal switched on. This must remain switched on until you acknowledge the use of Active Parking Assist by pressing the OK button on the multifunction steering wheel.

When a parking space has been detected, an arrow towards the right or the left also appears.



Example: detected parking space

- ① Detected parking space on the left
- ② Parking symbol
- ③ Detected parking space on the right

Active Parking Assist will only detect parking spaces:

- that are parallel to the direction of travel
- that are at least 59 in (1.5 m) wide
- that are at least 51 in (1.3 m) longer than your vehicle



A parking space is displayed while you are driving past it, and until you are approximately 50 ft (15 m) away from it.

## **Parking**

#### **↑** WARNING

Active Parking Assist merely aids you by intervening actively in the steering. If you do not brake there is a risk of an accident. Always apply the brakes yourself when maneuvering and parking.

When PARKTRONIC detects obstacles, Active Parking Assist brakes automatically during the parking process. You are responsible for braking in good time.

Active Parking Assist does not support you with parking spaces parallel to the direction of travel if:

- the parking space is on a curb
- the parking space is apparently blocked, for example by foliage or grass paving blocks
- the range of movement is too small
- the parking space is bordered by an obstacle which is not clearly defined such as a tree or a trailer
- ► Stop the vehicle when the parking space symbol shows the desired parking space in the instrument cluster.
- ▶ Shift the transmission to position **R**. The Start Park Assist? Yes: OK No: message appears in the multifunction display.
- ▶ To cancel the procedure: press the button on the multifunction steering wheel or pull away.

or

► To park using Active Parking Assist: press the OK button on the multifunction steering wheel.

The Park Assist Active Accelerate and Brake Observe Surroundings

- message appears in the multifunction display.
- ▶ Let go of the multifunction steering wheel.
- ▶ Back up the vehicle, being ready to brake at all times. When backing up, drive at a speed below approximately 6 mph (10 km/h). Otherwise Active Parking Assist will be canceled.
- 1 In tight parking spaces, you will achieve the best parking results by backing up as far as possible. When doing so, also observe the PARKTRONIC messages.
- ▶ Stop as soon as PARKTRONIC sounds the continuous warning tone, if not before. Maneuvering may be required in tight parking spaces.

The Park Assist Active Select D Observe Surroundings message appears in the multifunction display.

▶ Shift the transmission to position **D** while the vehicle is stationary. Active Parking Assist immediately steers in the other direction.

The Park Assist Active Accelerate and Brake Observe Surroundings message appears in the multifunction display.

- 1 You will achieve the best results by waiting for the steering procedure to complete before pulling away.
- Drive forwards and be ready to brake at all times.
- ▶ Stop as soon as PARKTRONIC sounds the continuous warning tone, if not before.

The Park Assist Active Select R Observe Surroundings message appears in the multifunction display.

► Further transmission shifts may be necessary.

As soon as the parking procedure is complete, the Park Assist Finished message appears in the multifunction display. PARKTRONIC continues to be available.



- ► Maneuver if necessary.
- ► Always observe the warning messages displayed by PARKTRONIC (▷ page 182).

#### Parking tips:

- The way your vehicle is positioned in the parking space after parking is dependent on various factors. These include the position and shape of the vehicles parked in front and behind it and the conditions of the location. It may be the case that Active Parking Assist guides you too far into a parking space, or not far enough into it. In some cases, it may also lead you across or onto the curb. If necessary, you should cancel the parking procedure with Active Parking Assist.
- You can also engage forward gear prematurely. The vehicle redirects and does not drive as far into the parking space. Should a gear be changed too early, the parking procedure will be canceled. A sensible parking position can no longer be achieved from this position.

# Exiting a parking space

In order that Active Parking Assist can support you when you exit the parking space:

- the border of the parking space must not be too low.
- the border of the parking space must not be too wide. The system maneuvers the vehicle into a position at a maximum of 45° to the starting position in the parking space.
- a maneuvering distance of at least 24 in (0.60 m) must be available.

Active Parking Assist can only assist you with exiting a parking space if you have parked the vehicle using Active Parking Assist.

- ► Start the engine.
- Switch on the turn signal on the side facing the street.

- ► Shift the transmission to position **D** or **R**. The Start Park Assist? Yes: OK No:

  \_\_\_\_\_ message appears in the multifunction display.
- ➤ To cancel the procedure: press the button on the multifunction steering wheel or pull away.

or

- ► To exit a parking space using Active
  Parking Assist: press the OK button on
  the multifunction steering wheel.
  The Park Assist Active Accelerate
  and Brake Observe Surroundings
  message appears in the multifunction
  display.
- ▶ Let go of the multifunction steering wheel.
- ▶ Reverse the vehicle or drive forwards, being ready to brake at all times. Do not exceed a maximum speed of approximately 6 mph (10 km/h) when exiting a parking space. Otherwise Active Parking Assist will be canceled.
- ► Stop when PARKTRONIC sounds the continuous warning tone, if not before.
- ► Shift the transmission to position **D** or **R** as required while the vehicle is stationary. Active Parking Assist immediately steers in the other direction. The Park Assist Active Accelerate and Brake Observe Surroundings message appears in the multifunction display.
- 1 You will achieve the best results by waiting for the steering procedure to complete before pulling away.
  - If you back up after activation, the steering wheel is moved to the straight-ahead position.
- ► Drive forwards or back up the vehicle, being ready to brake at all times.
- Stop as soon as PARKTRONIC sounds the continuous warning tone, if not before.
- ▶ Drive forwards and reverse as prompted by the PARKTRONIC warning displays, several times if necessary.



Once you have exited the parking space completely, the steering wheel is moved to the straight-ahead position. You hear a tone and the Park Assist Finished message appears in the multifunction display. You will then have to steer and merge into traffic on your own. PARKTRONIC is still available.

## **Canceling Active Parking Assist**

You can cancel Active Parking Assist at any time.

► Stop the movement of the multifunction steering wheel or steer yourself.

Active Parking Assist will be canceled at once. The Park Assist Canceled message appears in the multifunction display.

or

▶ Press the PARKTRONIC button on the center console (▷ page 182). PARKTRONIC is switched off and Active Parking Assist is immediately canceled. The Park Assist Canceled message appears in the multifunction display.

Active Parking Assist is canceled automatically if:

- · you engage the electric parking brake
- parking using Active Parking Assist is no longer possible
- you are driving faster than 6 mph (10 km/h)
- a wheel spins, ESP® intervenes or fails. The warning lamp lights up in the instrument cluster.

A warning tone sounds. The parking space symbol disappears and the multifunction display shows the Park Assist Canceled message.

If Active Parking Assist is canceled, you must steer again yourself.

If a system malfunction occurs, the vehicle is braked to a standstill. To drive on, depress the accelerator again.

#### Towing a trailer

For vehicles with a trailer tow hitch, the minimum length for parking spaces is slightly increased.

If you have attached a trailer to your vehicle, you should not use Active Parking Assist. Once the electrical connection is established between your vehicle and the trailer, Active Parking Assist is no longer available.

PARKTRONIC is deactivated for the rear area.

#### Rear view camera

#### Important safety notes

The rear view camera is only an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering and parking. When maneuvering or parking, make sure that there are no persons, animals or objects in the area in which you are maneuvering.

Under the following circumstances, the rear view camera will not function, or will function in a limited manner:

- the tailgate is open
- in heavy rain, snow or fog
- at night or in very dark places
- if the camera is exposed to very bright light
- if the area is lit by fluorescent light or LED lighting (the display may flicker)
- if there is a sudden change in temperature,
   e.g. when driving into a heated garage in winter
- if the camera lens is dirty or obstructed
- if the rear of your vehicle is damaged. In this event, have the camera position and setting checked at a qualified specialist workshop.



#### General notes



#### 1 Rear view camera


Rear view camera ① is located in the handle strip of the tailgate.

Rear view camera ① is an optical parking and maneuvering aid. It uses guide lines to show the area behind your vehicle in the Audio/COMAND display.

The area behind the vehicle is displayed as a mirror image, as in the rear view mirror.

1 The text of messages shown in the COMAND display depends on the language setting. The following are examples of rear view camera messages in the COMAND display.

# Activating/deactivating the rear view camera



- ► To activate: make sure that the SmartKey is in position 2 in the ignition lock.
- ► Make sure that the "Activation by R gear" setting is active in COMAND, see the separate COMAND operating instructions.

- ► Engage reverse gear.

  The area behind the vehicle is shown in the COMAND display with guide lines.
- ▶ To change the function mode for vehicles with trailer tow hitch: using the COMAND controller, select symbol ① for the "Reverse parking" function or symbol ② for "Coupling up a trailer" (see the separate COMAND operating instructions).

The symbol of the selected function is highlighted.

**To deactivate:** the rear view camera is deactivated if you:

- shift the transmission to position P
- drive forwards 33 ft (10 m)
- shift the transmission from R to another position after 15 seconds
- drive forwards at a speed of over 5 mph (10 km/h)


# Displays in the Audio/COMAND display

The rear view camera may show a distorted view of obstacles, show them incorrectly or not at all. The rear view camera does not show objects in the following positions:


- very close to the rear bumper
- under the rear bumper
- in the area immediately above the tailgate handle
- Objects not at ground level may appear to be further away than they actually are, e.g.:
  - the bumper of a parked vehicle
  - · the drawbar of a trailer
  - the ball coupling of a trailer tow hitch
  - · the rear section of an HGV
  - a slanted post

Use the guidelines only for orientation. Approach objects no further than the bottom-most guideline.





- P54.65-4727-31
- (1) White guide line without turning the steering wheel, vehicle width including the exterior mirrors (static)
- (2) Yellow guide line at a distance of approximately 13 ft (4.0 m) from the rear of the vehicle
- (3) Yellow guide line for the vehicle width including the exterior mirrors, for current steering wheel angle (dynamic)
- (4) Yellow lane marking tires at current steering wheel angle (dynamic)



- (5) Yellow guide line at a distance of approximately 3 ft (1.0 m) from the rear of the vehicle
- (6) Vehicle center axle (marker assistance)
- (7) Bumper
- (8) Red guide line at a distance of approximately 12 in (0.30 m) from the rear of the vehicle

The guide lines are shown when the transmission is in position R.

The distance specifications only apply to objects that are at ground level.



Additional messages for vehicles with **PARKTRONIC** 

- (1) Front warning display
- (2) Additional PARKTRONIC measurement operational readiness indicator
- (3) Rear warning display

#### Vehicles with PARKTRONIC: if

PARKTRONIC is operational (▷ page 182), an additional operational readiness indicator will appear in COMAND display (2). If the PARKTRONIC warning displays are active or light up, warning displays (1) and (3) are also active or light up correspondingly in the COMAND display.

# "Reverse parking" function

▶ Make sure that the rear view camera is activated and the "Reverse parking" function is selected; see the separate operating instructions for the audio system/COMAND.

The lane and the guide lines are shown.



# Backing up straight into a parking space without turning the steering wheel



- ① White guide line without turning the steering wheel, vehicle width including the exterior mirrors (static)
- ② Yellow guide line for the vehicle width including the exterior mirrors, for current steering wheel angle (dynamic)
- ③ Yellow guide line at a distance of approximately 3 ft (1.0 m) from the rear of the vehicle
- ④ Red guide line at a distance of approximately 12 in (0.30 m) from the rear of the vehicle
- Make sure that the rear view camera is switched on (⊳ page 189).
   The lane and the guide lines are shown.
- ► With the help of white guide line ①, check whether the vehicle will fit into the parking space.
- ► Using white guide line ① as a guide, carefully back up until you reach the end position.

  Red guide line ④ is then at the end of the parking space. The vehicle is almost

parallel in the parking space.

Reverse perpendicular parking with the steering wheel at an angle



Turning the steering wheel

- Yellow guide line for the vehicle width including the exterior mirrors, for current steering wheel angle (dynamic)
- (2) Parking space marking
- Make sure that the rear view camera is switched on (▷ page 189). The lane and the guide lines are shown.
- ► Drive past the parking space and bring the vehicle to a standstill.
- ▶ While the vehicle is at a standstill, turn the steering wheel in the direction of the parking space until yellow guide line ① reaches parking space marking ②.
- ► Keep the steering wheel in that position and back up carefully.



Backing up with the steering wheel turned

 Yellow guide line for the vehicle width including the exterior mirrors, for current steering wheel angle (dynamic)




Stop the vehicle when it is almost exactly in front of the parking space. The white lane should be as close to parallel with the parking space marking as possible.



- White guide line at current steering wheel angle
- (2) Parking space marking

Driving to the final position

► Turn the steering wheel to the center position while the vehicle is stationary.



① Red guide line at a distance of approximately 12 in (0.30 m) from the

- ② White guide line without turning the steering wheel
- 3 End of parking space

the parking space.


rear of the vehicle

▶ Back up carefully until you have reached the final position. Red guide line ① is then at end of parking space ③. The vehicle is almost parallel in

# "Coupling up a trailer" function

This function is only available on vehicles with a trailer tow hitch and COMAND.

I The following distance specifications refer to trailer tow hitches with ball coupling that have been approved for this vehicle by Mercedes-Benz. Distances may differ if you use other ball couplings. In this case, take into account that actual distances will not match the following distance specifications. Otherwise you could damage the trailer and vehicle.




- Vehicle center point on the yellow guide line at a distance of approximately 3 ft (1 m) from the rear of the vehicle
- Trailer drawbar
- (3) Ball coupling

This function is only available on vehicles with a trailer tow hitch.

- ► Set the height of trailer drawbar ② so that it is slightly higher than ball coupling ③.
- ▶ Position the vehicle centrally in front of trailer drawbar ②.





- Ball coupling
- ② Red guide line at a distance of approximately 12 in (0.30 m) from the ball coupling
- Trailer drawbar marker assistant
- (4) Trailer drawbar
- (5) Symbol for the "Coupling up a trailer" function
- ► Select symbol ⑤ using the COMAND controller, see COMAND.

  The "Coupling up a trailer" function is selected. The distance specifications now only apply to objects that are at the same level as the ball coupling.
- ▶ Reverse carefully, making sure that trailer drawbar marker assistant ③ points approximately in the direction of trailer drawbar ④.
- ► Reverse carefully until the trailer drawbar ④ reaches red guide line ②.
- ► Couple up the trailer (> page 208).

#### 360° camera

# Important safety notes

The 360° camera is only an aid. It is not a replacement for your attention to your immediate surroundings. You are always responsible for safe maneuvering and parking. When maneuvering or parking, make sure that there are no persons, animals or objects in the area in which you are maneuvering.

The 360° camera may show a distorted view of obstacles, show them incorrectly or not at all. It cannot show objects in the following areas:

- under the front bumper
- very close to the front bumper
- · very close to the rear bumper
- under the rear bumper
- in close range above the handle on the trunk lid
- · very close to the exterior mirrors

You are always responsible for safety, and must always pay attention to your surroundings when parking and maneuvering. This applies to the areas behind, in front of and beside the vehicle. You could otherwise endanger yourself and others.

The 360° camera will not function or will function in a limited manner:

- if the doors are open
- if the exterior mirrors are folded in
- the tailgate is open
- in heavy rain, snow or fog
- at night or in very dark places
- if the cameras are exposed to very bright light
- if the area is lit by fluorescent light or LED lighting (the display may flicker)
- if you exit a heated garage in winter, resulting in a rapid change in temperature
- if the camera lenses are dirty or covered
- if the vehicle components in which the cameras are installed are damaged. In this event, have the camera position and setting checked at a qualified specialist workshop.

Do not use the 360° camera in this case. You can otherwise injure others or cause damage to objects or the vehicle.

#### **General notes**

The 360° camera is a system consisting of four cameras.



The system analyzes images from the following cameras:

- · rear view camera
- · front camera
- two cameras in the exterior rear view mirrors

The cameras capture the immediate surroundings of the vehicle. The system supports you, e.g. when parking or if vision is restricted at an exit.

The 360° camera images can be shown in full screen mode or in seven different split-screen views on the COMAND display. A split-screen view also includes a top view of the vehicle. This view is calculated from the data supplied by the installed cameras (virtual camera).

The seven split-screen views are:

- top view and picture from the rear view camera (130° viewing angle)
- top view and picture from the front camera (without displaying the maximum steering wheel angle)
- top view and enlarged rear view
- top view and enlarged front view
- top view and trailer view (vehicles with trailer tow hitch)
- top view and pictures from the rearward facing mirror cameras (rear wheel view)
- top view and pictures from the forward facing mirror cameras (front wheel view)
- The top view and trailer view are available for vehicles equipped with a trailer tow hitch.

When the function is active and you shift the transmission from position  $\mathbf{D}$  or  $\mathbf{R}$  to  $\mathbf{N}$ , you see the previous view in the COMAND display. The dynamic guidelines are hidden. When you change between transmission positions  $\mathbf{D}$  and  $\mathbf{R}$ , you see the previously selected front or rear view.

#### **Activation conditions**

The 360° camera image can be displayed if:

- your vehicle is equipped with a 360° camera
- COMAND is switched on, see the separate COMAND operating instructions
- the 360° Camera function is activated

# Activating the 360° camera using the SYS button

- ► Press and hold the sys⊙ button for longer than 2 seconds, see the separate COMAND operating instructions.
  - Depending on whether position **D** or **R** is engaged, the following is shown:
  - full screen display with the image from the front camera
  - full screen display with the image from the rear camera

# Activating the 360° camera with COMAND

- ► Press the sys button, see the separate COMAND operating instructions.
- ► Select System by turning 【◎】 the COMAND controller and press ⑤ to confirm.
- ► Select 360° Camera and press ⑤ to confirm.

Depending on whether position **D** or **R** is engaged, the following is shown:

- a split screen with top view and the image from the front camera or
- a split screen with top view and the image from the rear view camera

For further information about the COMAND Controller, see the separate COMAND operating instructions.



# Activating the 360° camera using reverse gear

The 360° camera images can be automatically displayed by engaging reverse gear.

- Make sure that the SmartKey is in position2 in the ignition lock.
- ► Make sure that the Activation by R gear setting is active in COMAND, see the separate COMAND operating instructions.
- ► To show the 360° camera image: engage reverse gear.

The COMAND display shows the area behind the vehicle in split screen:

- · vehicle with guide lines
- top view of the vehicle

# Selecting the split-screen and full screen displays

- ► To switch between split screen views: switch to the line with the vehicle icons by sliding • ○ the COMAND controller.
- ► Turn 【◎】 the COMAND controller and select one of the vehicle symbols.
- ► To switch to full screen mode: select Full Screen by turning 【◎】 the COMAND controller and press ⑤ to confirm.


# Displays in the COMAND display

# Important safety notes


- Objects not at ground level may appear to be further away than they actually are, e.g.:
  - the bumper of a parked vehicle
  - the drawbar of a trailer
  - the ball coupling of a trailer tow hitch
  - the rear section of an HGV
  - a slanted post

Use the guidelines only for orientation. Approach objects no further than the bottom-most guideline.

# Top view with picture from the rear view camera



- Symbol for the split screen setting with top view and rear view camera image
- ② Yellow guide line at a distance of approximately 13 ft (4.0 m) from the rear of the vehicle
- ③ Yellow guide line for the vehicle width including the exterior mirrors, for current steering wheel angle (dynamic)
- Yellow lane marking tires at current steering wheel angle (dynamic)




- (5) Yellow guide line at a distance of approximately 3 ft (1.0 m) from the rear of the vehicle
- 6 Vehicle center axle (marker assistance)
- Red guide line at a distance of approximately 12 in (0.30 m) from the rear of the vehicle
- 8 Bumper

The guide lines are shown when the transmission is in position  $\mathbf{R}$ .

The distance specifications only apply to objects that are at ground level.




# Top view with picture from the front camera



- Symbol for the split screen setting with top view and front camera image
- ② Yellow guide line at a distance of approximately 13 ft (4.0 m) from the front of the vehicle
- ③ Yellow guide line for the vehicle width including the exterior mirrors, for current steering wheel angle (dynamic)
- 4 Yellow lane marking tires at current steering wheel angle (dynamic)
- (5) Yellow guide line at a distance of approximately 3 ft (1.0 m) from the front of the vehicle
- Red guide line at a distance of approximately 12 in (0.30 m) from the front of the vehicle

# Top view and enlarged rear view




- Symbol for the split screen setting with top view and rear view camera image enlarged
- ② Red guide line at a distance of approximately 12 in (0.30 m) from the rear of the vehicle

This view assists you in estimating the distance to the vehicle behind you.

1 This setting can also be selected as an enlarged front view.


# Top view with picture from the mirror camera



- Symbol for the top view and forwardfacing mirror camera setting
- Yellow guide line for the vehicle width including the exterior mirrors (right side of vehicle)
- 3 Yellow guide line for the vehicle width including the exterior mirrors (left side of vehicle)



## Top view with trailer view



- Symbol for the trailer view setting
- (2) Trailer drawbar marker assistant
- 3 Red guide line at a distance of approximately 12 in (0.30 m) from the ball coupling

## Display with the PARKTRONIC display



Example: full screen mode with PARKTRONIC display

 Symbol for the full screen setting with rear view camera image

If the vehicle is equipped with PARKTRONIC and the function is active (> page 182), warning displays ② in the COMAND display are also active or light up accordingly. PARKTRONIC appears:

- PARKIRONIC appears:
- in split screen view as red or yellow brackets around the vehicle icon in the top view, or
- in the full screen view, on the right-hand side at the bottom as red or yellow brackets around the vehicle icon

1 The full screen display can also be selected as front view.

# Exiting 360° camera display mode

As soon as your vehicle exceeds a speed of 19 mph (30 km/h) with the function activated, the function switches off. The COMAND display switches back to the previously selected view. You can also switch the display by selecting the symbol in the display and pressing the COMAND controller.

#### ATTENTION ASSIST

## Important safety notes

ATTENTION ASSIST is only an aid to the driver. It might not always recognize fatigue or increasing inattentiveness in time or fail to recognize them at all. The system is not a substitute for a well-rested and attentive driver.

ATTENTION ASSIST helps you during long, monotonous journeys, such as on highways. It is active in the range between 50 mph (80 km/h) and 112 mph (180 km/h).

If ATTENTION ASSIST detects typical indicators of fatigue or increasing lapses in concentration on the part of the driver, it suggests you take a break.

ATTENTION ASSIST assesses your level of fatigue or lapses in concentration by taking the following criteria into account:

- your personal driving style, e.g. steering characteristics
- journey details, e.g. time of day and length of journey

The functionality of ATTENTION ASSIST is restricted and warnings may be delayed or not occur at all:

- if the road condition is poor, e.g. if the surface is uneven or if there are potholes
- if there is a strong side wind



- if you have adopted a sporty driving style with high cornering speeds or high rates of acceleration
- if you are predominantly driving slower than 50 mph (80 km/h) or faster than 112 mph (180 km/h)
- if you are currently using COMAND or making a telephone call with it
- · if the time has been set incorrectly
- in active driving situations, such as when you change lanes or change your speed

# Warning and display messages in the multifunction display



Activate ATTENTION ASSIST using the onboard computer (▷ page 225). Symbol ① appears in the multifunction display.

If ATTENTION ASSIST is active, you will be warned no sooner than 20 minutes after your journey has begun. You then hear an intermittent warning tone twice and the Attention Assist: Drowsiness Detected message appears in the multifunction display.

- ▶ If necessary, take a break.
- ► Press the OK button to confirm the message.

On long journeys, take regular breaks in good time to allow yourself to rest properly. If you do not take a break, you will be warned again after 15 minutes at the earliest. The precondition for this is that ATTENTION ASSIST still detects typical indicators of fatigue or increasing lapses in concentration.

ATTENTION ASSIST is reset when you continue your journey and starts assessing your tiredness again if:

- you switch off the engine.
- you take off your seat belt and open the driver's door, e.g. for a change of drivers or to take a break.

#### Lane Tracking package

#### General notes

The Lane Tracking package consists of Blind Spot Assist (▷ page 198) and Lane Keeping Assist (▷ page 200).

#### **Blind Spot Assist**

#### General notes

Blind Spot Assist uses a radar sensor system to monitor the areas on both sides of your vehicle. It supports you from speeds of approximately 20 mph (30 km/h). A warning display in the exterior mirrors draws your attention to vehicles detected in the monitored area. If you then switch on the corresponding turn signal to change lanes, you will also receive a visual and audible collision warning. Blind Spot Assist uses sensors in the rear bumper for monitoring purposes.

For Blind Spot Assist to assist you when driving, the radar sensor system must be:

- activated(⊳ page 229)
- operational

#### Important safety notes

Blind Spot Assist is only an aid. It may fail to detect some vehicles and is no substitute for attentive driving. Always ensure that there is sufficient distance to the side for other road users and obstacles.



#### **↑** WARNING

Blind Spot Assist does not react to:

- vehicles overtaken too closely on the side, placing them in the blind spot area
- vehicles being overtaken at a speed difference of more than 7.5 mph  $(12 \, \text{km/h})$
- · vehicles which approach with a large speed differential and overtake your vehicle

As a result, Blind Spot Assist may not give warnings in such situations. There is a risk of an accident.

Always observe the traffic conditions carefully, and maintain a safe lateral distance.



#### **1** USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removing, tampering with, or altering the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.


Any unauthorized modification to this device could void the user's authority to operate the equipment.

## Monitoring range of the sensors

In particular, the detection of obstacles can be impaired if:

- · dirt on the sensors or anything else covering the sensors
- poor visibility, e.g. due to fog, heavy rain, snow or spray
- narrow vehicles, e.g. motorcycles or bicycles
- the road has very wide lanes
- the road has narrow lanes
- you are not driving in the middle of the lane
- there are barriers or similar lane borders

Vehicles in the monitoring range are then not indicated.



Blind Spot Assist monitors the area up to 10 ft (3m) behind your vehicle and directly next to your vehicle, as shown in the diagram. If the lanes are narrow, vehicles driving in the lane beyond the lane next to your vehicle may be indicated, especially if the vehicles are not driving in the middle of their lane. This may be the case if there are vehicles driving at the inner edge of their lanes.

Due to the nature of the system:


- warnings may be issued in error when driving close to crash barriers or similar solid lane borders
- the warning is canceled when driving for an extended period next to long vehicles, such as trucks.

The two radar sensors for Blind Spot Assist are integrated into the sides of the rear bumper. Make sure that the bumper is free of dirt, ice or slush in the vicinity of the sensors. The sensors must not be covered, for example by cycle racks or overhanging loads. Following a severe impact or in the event of damage to the bumpers, have the function of the sensors checked at a qualified specialist workshop. Blind Spot Assist may otherwise not work properly.



#### Indicator and warning display

Blind Spot Assist is not active at speeds below approximately 20 mph (30 km/h). Vehicles in the monitoring range are then not indicated.



(1) Yellow indicator lamp/red warning lamp

When Blind Spot Assist is activated, indicator lamp ① in the exterior mirrors lights up yellow at speeds of up to 20 mph (30 km/h). At speeds above 20 mph (30 km/h), the indicator lamp goes out and Blind Spot Assist is operational.

If a vehicle is detected within the monitoring range of Blind Spot Assist at speeds above 20 mph (30 km/h), warning lamp ① on the corresponding side lights up red. This warning is always emitted when a vehicle enters the blind spot monitoring range from behind or from the side. When you overtake a vehicle, the warning only occurs if the difference in speed is less than 7 mph (12 km/h).

The yellow indicator lamp goes out if reverse gear is engaged. In this event, Blind Spot Assist is no longer active.

The brightness of the indicator/warning lamps is adjusted automatically according to the ambient light.

#### Collision warning

If a vehicle is detected in the monitoring range of Blind Spot Assist and you switch on the corresponding turn signal, a double warning tone sounds. Red warning lamp ① flashes. If the turn signal remains on, vehicles detected are indicated by the flashing of red warning lamp ①. There are no further warning tones.

#### Switching on Blind Spot Assist

- Make sure that the radar sensor system (▷ page 229) and Blind Spot Assist (▷ page 225) are activated in the on-board computer.
- ► Turn the SmartKey to position 2 in the ignition lock.

  Warning lamps ① in the exterior mirrors light up red for approximately

  1.5 seconds and then turn yellow.

#### Towing a trailer

When you attach a trailer, make sure you have correctly established the electrical connection. This can be accomplished by checking the trailer lighting. In this event, Blind Spot Assist is deactivated. The indicator lamp lights up yellow in the exterior mirrors and the Blind Spot Assist Currently Available See Operator's Manual message appears in the multifunction display.

1 You can deactivate the indicator lamps in the exterior mirrors.

To do so, switch off Blind Spot Assist when:

- the SmartKey is in position 2 in the ignition lock
- the engine is not running
- the electrical connection to the trailer has been established

# Lane Keeping Assist

## Important safety notes

If you fail to adapt your driving style, Lane Keeping Assist can neither reduce the risk of an accident nor override the laws of physics. Lane Keeping Assist cannot take into account the road, traffic and weather conditions. Lane Keeping Assist is merely an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.



#### **↑** WARNING

Lane Keeping Assist may not always clearly recognize lane markings.

In this case, Lane Keeping Assist may:

- · give an unnecessary warning
- not give a warning

There is a risk of an accident.

Always pay particular attention to the traffic situation and stay in lane, in particular if warned by Lane Keeping Assist.



#### **↑** WARNING

The Lane Keeping Assist warning does not return the vehicle to the original lane. There is a risk of an accident.

You should always steer, brake or accelerate yourself, in particular if warned by Lane Keeping Assist.

The Lane Keeping Assist does not keep the vehicle in the lane.


The system may be impaired or may not function if:

- there is poor visibility, e.g. due to insufficient illumination of the road, or due to snow, rain, fog or spray
- there is glare, e.g. from oncoming traffic, the sun or reflections (e.g. when the road surface is wet)
- the windshield is dirty, fogged up, damaged or covered, for instance by a sticker, in the vicinity of the camera
- there are no. several or unclear lane markings for a lane, e.g. in areas with road construction work
- the lane markings are worn away, dark or covered up, e.g. by dirt or snow
- the distance to the vehicle in front is too small and the lane markings thus cannot be detected
- the lane markings change quickly, e.g. lanes branch off, cross one another or merge

- · the road is narrow and winding
- there are strong shadows cast on the lane

#### General notes

Lane Keeping Assist monitors the area in front of your vehicle with camera (1), which is mounted at the top of the windshield. Lane Keeping Assist detects lane markings on the road and warns you before you leave your lane unintentionally.



(1) Active Lane Keeping Assist camera

If you select km on the on-board computer in the Display Unit Speed-/Odometer function (⊳ page 226), Lane Keeping Assist is active starting at a speed of 60 km/h. If the miles display unit is selected, the assistance range begins at 40 mph.

A warning may be given if a front wheel passes over a lane marking. It will warn you by means of intermittent vibration in the steering wheel for up to 1.5 seconds.

# Switching on Lane Keeping Assist



► Switch on Active Lane Keeping Assist using the on-board computer; to do so, select Standard or Adaptive(> page 225). Symbol (1) appears in the multifunction display.



If you drive at speeds above 40 mph (60 km/h) and lane markings are detected, symbol ① is shown in green. Lane Keeping Assist is ready for use.

#### Standard

If Standard is selected, no warning vibration occurs if:

- you switch on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- a driving safety system intervenes, such as ABS, BAS or ESP<sup>®</sup>.

## **Adaptive**

If Adaptive is selected, no warning vibration occurs if:

- you switch on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- a driving safety system intervenes, e.g. ABS, BAS or ESP<sup>®</sup>.
- you accelerate hard, e.g. kickdown.
- you brake hard.
- you steer actively, e.g. swerve to avoid an obstacle or change lanes quickly.
- you cut the corner on a sharp bend.

In order that you are warned only when necessary and in good time if you cross the lane marking, the system recognizes certain conditions and warns you accordingly.

The warning vibration occurs earlier if:

- you approach the outer lane marking on a bend.
- the road has very wide lanes, e.g. a highway.
- the system recognizes solid lane markings. The warning vibration occurs later if:
- the road has narrow lanes.
- you cut the corner on a bend.

#### Towing a trailer

When you attach a trailer, make sure you have correctly established the electrical

connection. This can be accomplished by checking the trailer lighting.

# **Active Driving Assistance package**

#### General notes

The Active Driving Assistance package consists of DISTRONIC PLUS (▷ page 171), Active Blind Spot Assist (▷ page 202) and Active Lane Keeping Assist (▷ page 205).

#### **Active Blind Spot Assist**

#### General notes

Active Blind Spot Assist uses a radar sensor system to monitor the side areas of your vehicle which are behind the driver. A warning display in the exterior mirrors draws your attention to vehicles detected in the monitored area. If you then switch on the corresponding turn signal to change lane, you will also receive an optical and audible warning. If a risk of lateral collision is detected, corrective braking may help you avoid a collision. To support the coursecorrecting brake application, Active Blind Spot Assist uses the forward-facing radar sensor system. The space available in the direction of travel as well as to the side of the vehicle is evaluated before a coursecorrecting braking application is performed. Active Blind Spot Assist supports you from a speed of approximately 20 mph (30 km/h).

For Active Blind Spot Assist to assist you when driving, the radar sensor system must be:

- activated(⊳ page 229)
- operational

#### Important safety notes

Active Blind Spot Assist is only an aid. It does not detect all traffic situations and road users and is no substitute for attentive driving. Always ensure that there is sufficient distance to the side for other road users and obstacles.



#### **↑** WARNING

Active Blind Spot Assist does not react to:

- vehicles overtaken too closely on the side, placing them in the blind spot area
- vehicles being overtaken at a speed difference of more than 7.5 mph  $(12 \, \text{km/h})$
- vehicles which approach with a large speed differential and overtake your vehicle

As a result, Active Blind Spot Assist may neither give warnings nor intervene in such situations. There is a risk of an accident. Always observe the traffic conditions carefully, and maintain a safe lateral distance.

# **1** USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removing, tampering with, or altering the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

- 1 Canada only: This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:
  - 1. This device may not cause harmful interference, and
  - 2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Removal, tampering, or altering of the device will void any warranties, and is not permitted. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

#### Monitoring range of the sensors



#### **↑** WARNING

Active Blind Spot Assist does not detect all traffic situations and road users. There is a risk of an accident.


Always make sure that there is sufficient distance on the side for other traffic or obstacles.

In particular, the detection of obstacles can be impaired if:

- · dirt on the sensors or anything else covering the sensors
- poor visibility, e.g. due to rain, snow or spray

Vehicles in the monitoring range are then not indicated.

Active Blind Spot Assist may not detect narrow vehicles, such as motorcycles or bicycles, or may only detect them too late.



Active Blind Spot Assist monitors the area up to 10 ft (3 m) behind your vehicle and directly next to your vehicle, as shown in the diagram. For this purpose, Active Blind Spot Assist uses radar sensors in the rear bumper.

If the lanes are narrow, vehicles driving in the lane beyond the lane next to your vehicle may be indicated, especially if the vehicles are not driving in the middle of their lane. This may



be the case if there are vehicles driving at the inner edge of their lanes.


Due to the nature of the system:

- warnings may be issued in error when driving close to crash barriers or similar solid lane borders.
- the warning is canceled when driving for an extended period next to long vehicles, such as trucks.

Two Active Blind Spot Assist radar sensors are integrated into the front and rear bumpers respectively. An additional radar sensor is located behind the cover in the radiator grill. Make sure that the sensors and areas around them are free of dirt, ice or slush. The rear sensors must not be covered, for example by cycle racks or overhanging cargo. Following a severe impact or in the event of damage to the bumpers, have the function of the sensors checked at a qualified specialist workshop. Blind Spot Assist may otherwise not work properly.

#### Indicator and warning display

Active Blind Spot Assist is not active at speeds below approximately 20 mph (30 km/h). Vehicles in the monitoring range are then not indicated.



(1) Yellow indicator lamp/red warning lamp

When Active Blind Spot Assist is activated, indicator lamp (1) in the exterior mirrors lights up yellow at speeds of up to 20 mph (30 km/h). At speeds above 20 mph (30 km/h), the indicator lamp goes out and Active Blind Spot Assist is operational.

If a vehicle is detected within the monitoring range of Active Blind Spot Assist at speeds above 20 mph (30 km/h), warning lamp (1) on the corresponding side lights up red. This warning is always emitted when a vehicle enters the blind spot monitoring range from behind or from the side. When you overtake a vehicle, the warning only occurs if the difference in speed is less than 7 mph (12 km/h).

The yellow indicator lamp goes out if reverse gear is engaged. In this event, Active Blind Spot Assist is no longer active.

The brightness of the indicator/warning lamps is adjusted automatically according to the ambient light.

#### Visual and acoustic collision warning

When you switch on the turn signals to change lanes and a vehicle is detected in the side monitoring range, you receive a visual and acoustic collision warning. You then hear a double warning tone and red warning lamp (1) flashes. If the turn signal remains on, detected vehicles are indicated by the flashing of red warning lamp (1). There are no further warning tones.

# Course-correcting brake application



# **↑** WARNING

A course-correcting brake application cannot always prevent a collision. There is a risk of an accident.

Always steer, brake or accelerate yourself, especially if Active Blind Spot Assist warns you or makes a course-correcting brake application. Always maintain a safe distance at the sides.

In very rare cases, the system may make an inappropriate brake application. An inappropriate brake application may be interrupted at any time if you steer slightly in the opposite direction or accelerate.

If Active Blind Spot Assist detects a risk of a lateral collision in the monitoring range, a course-correcting brake application is carried



out. This is meant to assist you in avoiding a collision.

The course-correcting brake application is available in the speed range between 20 mph (30 km/h) and 120 mph (200 km/h). If a course-correcting brake application occurs, red warning lamp (1) flashes in the exterior mirror and the following is shown in the multifunction display, for example:



Either a very slight course-correcting brake application, or none at all, may occur if:

- there are vehicles or obstacles, e.g. crash barriers, located on both sides of your vehicle.
- a vehicle approaches you too closely at the side.
- you have adopted a sporty driving style with high cornering speeds.
- you clearly brake or accelerate.
- a driving safety system intervenes, e.g. ESP® or PRE-SAFE® Brake.
- ESP<sup>®</sup> is switched off.
- the off-road program is activated.
- a loss of tire pressure or a defective tire is detected.

## Switching on Active Blind Spot Assist

- ▶ Make sure that the radar sensor system (▷ page 229) and Active Blind Spot Assist (⊳ page 225) are activated in the on-board computer.
- ► Turn the SmartKey to position 2 in the ignition lock.

Warning lamps (1) in the exterior mirrors light up red for approximately

1.5 seconds and then turn yellow.


#### Towing a trailer

When you attach a trailer, make sure you have correctly established the electrical connection. This can be accomplished by checking the trailer lighting. Active Blind Spot Assist is then deactivated. The indicator lamp lights up yellow in the exterior mirrors and the Active Blind Spot Assist Currently Unavailable See Operator's Manual message appears in the multifunction display.

#### **Active Lane Keeping Assist**

#### General notes

Active Lane Keeping Assist monitors the area in front of your vehicle by means of camera (1) mounted at the top of the windshield. Active Lane Keeping Assist detects lane markings on the road and warns vou before vou leave vour lane unintentionally. If you do not react to the warning, a lane-correcting application of the brakes can bring the vehicle back into the original lane.



(1) Active Lane Keeping Assist camera

If you select km in the Display Unit Speed-/Odometer: function on the on-board computer(⊳ page 226), Active Lane Keeping Assist is activated starting at a speed of 60 km/h. If the miles display unit is selected, the assistance range begins at 40 mph.



## Important safety notes

If you fail to adapt your driving style, Active Lane Keeping Assist can neither reduce the risk of accident nor override the laws of physics. Lane Keeping Assist cannot take into account the road, traffic and weather conditions. Lane Keeping Assist is merely an aid. You are responsible for the distance to the vehicle in front, for vehicle speed, for braking in good time and for staying in your lane.

Active Lane Keeping Assist cannot continuously keep your vehicle in its lane.

# **↑** WARNING

Active Lane Keeping Assist cannot always clearly detect lane markings.

In such cases, Active Lane Keeping Assist can:

- give an unnecessary warning and then make a course-correcting brake application to the vehicle
- not give a warning or intervene

There is a risk of an accident.

Always pay particular attention to the traffic situation and keep within the lane, especially if Active Lane Keeping Assist alerts you. Terminate the intervention in a non-critical driving situation.

The system may be impaired or may not function if:

- there is poor visibility, e.g. due to insufficient illumination of the road, or due to snow, rain, fog or spray
- there is glare, e.g. from oncoming traffic, the sun or reflections (e.g. when the road surface is wet)
- the windshield is dirty, fogged up, damaged or covered, for instance by a sticker, in the vicinity of the camera
- there are no, several or unclear lane markings for a lane, e.g. in areas with road construction work
- the lane markings are worn away, dark or covered up, e.g. by dirt or snow

- the distance to the vehicle in front is too small and the lane markings thus cannot be detected
- the lane markings change quickly, e.g. lanes branch off, cross one another or merge
- the road is narrow and winding
- there are highly variable shade conditions on the roadway
- no vehicle is detected in the adjacent lane and there are broken lane markings

#### Warning vibration in the steering wheel

A warning may be given if a front wheel passes over a lane marking. It will warn you by means of intermittent vibration in the steering wheel for up to 1.5 seconds.

In order that you are warned only when necessary and in good time if you cross the lane marking, the system recognizes certain conditions and warns you accordingly.

The warning vibration occurs earlier if:

- you approach the outer lane marking on a bend.
- the road has very wide lanes, e.g. a highway.
- the system recognizes solid lane markings.

The warning vibration occurs later if:

- · the road has narrow lanes.
- you cut the corner on a bend.

# Lane-correcting brake application



#### **↑** WARNING

A lane-correcting brake application cannot always bring the vehicle back into the original lane. There is a risk of an accident.

Always steer, brake or accelerate yourself, especially if Active Lane Keeping Assist warns you or makes a lane-correcting brake application.



#### **↑** WARNING

Active Lane Keeping Assist does not detect traffic conditions or road users. In very rare cases, the system may make an inappropriate



brake application, e.g. after intentionally driving over a solid lane marking. There is a risk of an accident.

An inappropriate brake application may be interrupted at any time if you steer slightly in the opposite direction. Always make sure that there is sufficient distance on the side for other traffic or obstacles.

If you leave your lane, under certain circumstances the vehicle will brake briefly on one side. This is meant to assist you in bringing the vehicle back to the original lane. This function is available in the range between 40 mph and 120 mph (60 km/h and 200 km/h).

A lane-correcting brake application can only be made after driving over a solid, recognizable lane marking. Before this, a warning must be given by means of intermittent vibration in the steering wheel. In addition, a lane with lane markings on both sides must be recognized. The brake application also slightly reduces vehicle speed.

If a lane-correcting brake application occurs, the following, for example, appears in the multifunction display:



 A further lane-correcting brake application can only occur after your vehicle has returned to the original lane.

No lane-correcting brake application occurs if:

- you clearly and actively steer, brake or accelerate.
- you cut the corner on a sharp bend.
- you switch on the turn signals.

- a driving safety system intervenes, e.g. ESP®, PRE-SAFE® Brake or Active Blind Spot Assist.
- you have adopted a sporty driving style with high cornering speeds or high rates of acceleration.
- on vehicles with a trailer tow hitch, the electrical connection to the trailer has been correctly established.
- ESP® is switched off.
- the transmission is not in position **D**.
- the off-road program is activated.
- a loss of tire pressure or a defective tire has been detected and displayed.

Active Lane Keeping Assist does not detect traffic situations or road users. An inappropriate brake application may be interrupted at any time if you:

- steer slightly in the opposite direction
- use a turn signal.
- · clearly brake or accelerate

A lane-correcting brake application is interrupted automatically if:

- a driving safety system intervenes, e.g. ESP<sup>®</sup>, PRE-SAFE<sup>®</sup> Brake or Active Blind Spot Assist.
- lane markings can no longer be recognized.

# **Switching on Active Lane Keeping Assist**



► Switch on Active Lane Keeping Assist using the on-board computer; to do so, select Standard or Adaptive(> page 225). Symbol ① appears in the multifunction display.

If you drive at speeds above 40 mph (60 km/h) and lane markings are detected,



symbol (1) is shown in green. Active Lane Keeping Assist is ready for use.

If Standard is selected, no warning vibration occurs if:

- vou have switched on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- a driving safety system intervenes, such as ABS, BAS or ESP®.

If Adaptive is selected, no warning vibration occurs if:

- · you have switched on the turn signals. In this event, the warnings are suppressed for a certain period of time.
- a driving safety system intervenes, e.g. ABS, BAS or ESP®.
- you accelerate hard, e.g. kickdown.
- · you brake hard.
- you steer actively, e.g. swerve to avoid an obstacle or change lanes quickly.
- you cut the corner on a sharp bend.

## Towing a trailer

When you attach a trailer, make sure you have correctly established the electrical connection. This can be accomplished by checking the trailer lighting.

# Towing a trailer

# Notes on towing a trailer

# Important safety notes



If you rest your foot on the brake pedal while driving, the braking system can overheat. This increases the stopping distance and can even cause the braking system to fail. There is a risk of an accident.

Never use the brake pedal as a footrest. Never depress the brake pedal and the accelerator pedal at the same time.

#### **↑** WARNING

When the vehicle/trailer combination begins to lurch, you could lose control of it. The vehicle/trailer combination could even rollover. There is a risk of an accident.

On no account should you attempt to straighten up the vehicle/trailer combination by increasing the speed. Reduce vehicle speed and do not countersteer. Apply the brake as necessary.

Depressing the brake pedal constantly results in excessive and premature wear to the brake pads.

Please observe the manufacturer's operating instructions for the trailer coupling if a detachable trailer coupling is used.

Couple and uncouple the trailer carefully. If you do not couple the trailer to the towing vehicle correctly, the trailer could become detached.

Make sure that the following values are not exceeded:

- the permissible trailer drawbar noseweight
- the permissible trailer load
- the permissible rear axle load of the towing vehicle
- the maximum permissible gross vehicle weight of both the towing vehicle and the trailer

The applicable permissible values, which must not be exceeded, can be found:

- in the vehicle documents
- on the identification plates of the trailer tow hitch, the trailer and the vehicle

If the values differ, the lowest value applies. You will find the values approved by the manufacturer on the vehicle identification

plates and those for the towing vehicle under "Technical data".

When towing a trailer, your vehicle's handling characteristics will be different in comparison with when driving without a trailer.



The vehicle/trailer combination:

- · is heavier
- is restricted in its acceleration and gradient-climbing capability
- · has an increased braking distance
- is affected more by strong crosswinds
- · demands more sensitive steering
- · has a larger turning radius

This could impair the handling characteristics.

When towing a trailer, always adjust your speed to the current road and weather conditions. Do not exceed the maximum permissible speed for your vehicle/trailer combination.

#### General notes

- Do not exceed the legally prescribed maximum speed for vehicle/trailer combinations in the relevant country.
   This lowers the risk of an accident.
- Only install an approved trailer coupling on your vehicle.
  - Further information on availability and on installation is available from any authorized Mercedes-Benz Center.
- The bumpers of your vehicle are not suitable for installing detachable trailer couplings.
- Do not install hired trailer couplings or other detachable trailer couplings on the bumpers of your vehicle.
- To reduce the risk of damage to the ball coupling, remove it from the ball coupling recess when not in use.
- i When towing a trailer, set the tire pressure on the rear axle of the towing vehicle for a maximum load; see the tire pressure table in the fuel filler flap (▷ page 349).

You will find installation dimensions and loads in the "Technical data" section (> page 374).

Missing values for the maximum noseweight of the trailer drawbar on the ball coupling were unavailable at the time of going to print. However, the actual noseweight must not exceed the value given on the identification plates of the trailer tow hitch and trailer. The lowest weight applies.

Please note that when towing a trailer, PARKTRONIC (> page 180) is only available with limitations or not at all.

On vehicles without level control, the height of the ball coupling will alter according to the load placed on the vehicle. If necessary, use a trailer with a heightadjustable drawbar.

# **Driving tips**

**1** Observe the notes on ESP<sup>®</sup> trailer stabilization (▷ page 69).

The maximum permissible speed for vehicle/trailer combinations depends on the type of trailer. Before beginning the journey, check the trailer's documents to see what the maximum permissible speed is. Observe the legally prescribed maximum speed in the relevant country.

For certain Mercedes-Benz vehicles, the maximum permissible rear axle load is increased when towing a trailer. Refer to the "Technical data" section to find out whether this applies to your vehicle.

If you utilize any of the added maximum rear axle load when towing a trailer, the vehicle/ trailer combination may not exceed a maximum speed of 60 mph (100 km/h) for reasons concerning the operating permit. This also applies in countries in which the permissible maximum speed for vehicle/ trailer combinations is above 60 mph (100 km/h).

When towing a trailer, your vehicle's handling characteristics will be different in comparison with when driving without a trailer.

On long and steep downhill gradients, you must select shift range 1, 2 or 3 in good time.



1 This also applies if you have activated cruise control.

This will use the braking effect of the engine. so that less braking will be required to maintain the speed. This relieves the load on the brake system and prevents the brakes from overheating and wearing too quickly. If you need additional braking, depress the brake pedal repeatedly rather than continuously.

## **Driving tips**

- · Maintain a greater distance from the vehicle in front than when driving without a trailer.
- Avoid braking abruptly. If possible, brake gently at first to allow the trailer to run on. Then, increase the braking force rapidly.
- The values given for gradient-climbing capabilities from a standstill refer to sea level. When driving in mountainous areas, note that the power output of the engine and, consequently, the vehicle's gradientclimbing capability, decreases with increasing altitude.

If the trailer swings from side to side:

- ▶ Do not accelerate.
- ▶ Do not counter-steer.
- ▶ Brake if necessary.

# Installing the ball coupling


## **↑** WARNING

If the ball coupling is not installed and secured correctly the trailer may come loose. There is a risk of an accident.

Install and secure the ball coupling as described in the ball coupling installation instructions. Make sure that the ball coupling is installed and secured correctly before every journey.

Mercedes-Benz recommends that you only use ball couplings that have been

tested and approved by Mercedes-Benz. This helps to avoid damage to the vehicle.



#### Cover cap

- ▶ Pull protective cap (1) in the direction of the arrow, out of ball coupling recess (2).
- ▶ Store protective cap (1) in a safe place.
- ▶ Observe the manufacturer's installation instructions.



#### **↑** WARNING

If the ball coupling is not installed and secured correctly it can become detached while the vehicle is in motion and fall onto the road. There is a risk of an accident and injury.

Install and secure the ball coupling as described in the ball coupling installation instructions. Make sure that the ball coupling is installed and secured correctly before every journey.

# Coupling up a trailer

Observe the maximum permissible trailer dimensions (width and length).

Most U.S. states and all Canadian provinces require by law:

• safety chains between the towing vehicle and the trailer. The chains should be crosswound under the trailer drawbar. They must be fastened to the vehicle's trailer coupling, not to the bumper or the axle.



Leave enough play in the chains to make tight cornering possible.

- a separate brake system for certain types of trailer.
- a safety switch for braked trailers. Check the specific legal requirements applicable to your state.

If the trailer detaches from the towing vehicle, the safety switch applies the trailer's brakes

- I Do not connect the trailer's brake system (if featured) to the hydraulic brake system of the towing vehicle, as the latter is equipped with an anti-lock brake system. Doing so will result in a loss of function of the brake systems of both the vehicle and the trailer.
- 1 The vehicle's wiring harness features a connection to the brake indicator lamp.
- ► Make sure that the automatic transmission is set to position **P**.
- ► Apply the vehicle's parking brake.
- Close all doors and the tailgate.
- ► Couple up the trailer.
- ► Establish all electrical connections.

# Towing a trailer

There are numerous legal requirements concerning the towing of a trailer, e.g. speed restrictions. Make sure that your car/trailer combination complies with the local regulations:

- in your place of residence
- in the location to which you are driving The police and local authorities can provide reliable information.

Observe the following when towing a trailer:

 To gain driving experience and to become accustomed to the new handling characteristics, you should practice the following in a traffic-free location:

- cornering
- stopping
- backing up
- Before driving, check:
  - the trailer tow hitch
  - the safety switch for braked trailers
  - the safety chains
  - electrical connections
  - the lights
  - the wheels
- Adjust the exterior mirrors to provide an unobstructed view of the rear section of the trailer.
- If the trailer has electronically controlled brakes, pull away carefully. Brake manually using the brake controller and check whether the brakes function correctly.
- Secure any objects on the trailer to prevent the cargo from slipping when the vehicle is in motion.
- When you couple up a trailer, check at regular intervals that the load is firmly secured. If the trailer is equipped with trailer lights and brakes, check the trailer to ensure that these are working.
- Bear in mind that the handling will be less stable when towing a trailer than when driving without one. Avoid sudden steering movements.
- The vehicle/trailer combination is heavier, accelerates more slowly, has a decreased gradient climbing capability and a longer braking distance.

It is more susceptible to side winds and requires more careful steering.

- If possible, avoid abrupt braking. Depress
  the brake pedal moderately at first, so that
  the trailer can activate its own brakes. Then
  increase the pressure on the brake pedal.
- If the automatic transmission continues to shift back and forth between two gears



- when driving up or downhill, restrict the shift range. Select shift range 4, 3, 2, or 1. A lower gear and lower speed reduce the risk of engine failure.
- · When driving downhill, shift to a lower gear to utilize the engine's braking effect. Avoid continuous brake application as this may overheat the vehicle brakes and, if installed, the trailer brakes.
- If the coolant temperature increases dramatically while the air-conditioning system is switched on, switch off the airconditioning system.
  - Coolant heat can additionally be dissipated by opening the windows and by setting the blower fan and the interior temperature to maximum.
- When overtaking, pay particular attention to the extended length of your vehicle/ trailer combination.

Due to the length of the vehicle/trailer combination, you require additional road space in relation to the vehicle you are overtaking, before you can change back to the original lane.

# Decoupling a trailer

# **↑** WARNING

If you uncouple a trailer with the overrun brake engaged, you could trap your hand between the vehicle and the trailer drawbar. There is a risk of injury.

Do not uncouple a trailer if the overrun brake is engaged.

- Do not disconnect a trailer with an engaged overrun brake. Otherwise, your vehicle could be damaged by the rebounding of the overrun brake.
- ▶ Make sure that the automatic transmission is set to position P.
- ► Apply the vehicle's parking brake.

- ▶ Close all doors and the tailgate.
- ► Apply the trailer's parking brake.
- ▶ Remove the trailer cable and decouple the trailer.

#### Permissible trailer loads and drawbar loads

## Weight specifications

The gross trailer weight is calculated by adding the weight of the trailer to the weight of the load and equipment on the trailer. Missing values were not available at the time of going to print.

The maximum permissible trailer drawbar noseweight is the maximum weight with which the trailer drawbar can be loaded. Missing values were not available at the time of going to print.

#### Loading a trailer

• When loading the trailer, make sure that neither the permissible gross weight of the trailer nor the gross vehicle weight is exceeded. The permissible gross vehicle weight is indicated on the identification plate on the B-pillar on the driver's side of the vehicle.

You can find the maximum permissible values on the type plates of your vehicle and the trailer. When calculating how much weight the vehicle and trailer may carry, pay attention to the respective lowest values.

- The trailer drawbar load on the ball coupling must be added to the rear axle load to avoid exceeding the permissible gross axle weight. The permissible gross vehicle weight is indicated on the identification plate on the B-pillar on the driver's side of the vehicle.
- Mercedes-Benz recommends a trailer load where the trailer drawbar noseweight



accounts for 8% to 15% of the trailer's permissible gross weight.

- The weight of other accessories, passengers and loads reduces:
  - the permissible trailer load
  - the permissible noseweight that your vehicle can tow

# Checking the vehicle and trailer weight

- To ensure compliance of the weight of the towing vehicle and the trailer with the maximum permissible values, have the vehicle/trailer combination (towing vehicle including driver, passenger, load and fully laden trailer) weighed on a calibrated weighbridge.
- Check the gross axle weight rating of the front and rear axles, the gross weight of the trailer and trailer drawbar load

# Removing the ball coupling

- ▶ Observe the manufacturer's installation instructions.
- ▶ Press the protective cap into the ball coupling recess.
- ▶ Make sure that the protective cap is firmly in place.

# Storing the ball coupling



#### **↑** WARNING

Do not carry the ball coupling in the vehicle interior if it is not secured.

Otherwise, you and others could be injured by the ball coupling being thrown around if you:

- · brake sharply
- · change direction suddenly
- · are involved in an accident
- Observe the manufacturer's installation instructions.

# Trailer power supply

The trailer socket of your vehicle is equipped at the factory with a permanent power supply. The permanent power supply is supplied via trailer socket pin 4.

You can connect accessories with a maximum power consumption of 240 W to the permanent power supply.

You must not charge a trailer battery using the power supply.

The trailer's permanent power supply is switched off in the event of low vehicle supply voltage and after six hours at the latest.

A qualified specialist workshop can provide more information about installing the trailer electrics.





Useful information	21
Important safety notes	21
Displays and operation	21
Menus and submenus	21
Display messages	23
Warning and indicator lamps in the	
instrument cluster	25

#### **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (⊳ page 27).

#### Important safety notes

#### **↑** WARNING

If you operate information systems and communication equipment integrated in the vehicle while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident.

Only operate the equipment when the traffic situation permits. If you are not sure that this is possible, park the vehicle paying attention to traffic conditions and operate the equipment when the vehicle is stationary.



#### **↑** WARNING

If the instrument cluster has failed or malfunctioned, you may not recognize function restrictions in systems relevant to safety. The operating safety of your vehicle may be impaired. There is a risk of an accident.

Drive on carefully. Have the vehicle checked at a qualified specialist workshop immediately.

You must observe the legal requirements for the country in which you are currently driving when operating the on-board computer.

The on-board computer only shows messages or warnings from certain systems in the

multifunction display. You should therefore make sure your vehicle is operating safely at all times. Otherwise, a vehicle that is not operating safely may cause an accident.

For an overview, see the instrument panel illustration (⊳ page 31).

#### Displays and operation

#### Coolant temperature display



#### **↑** WARNING

Opening the hood when the engine is overheated or when there is a fire in the engine compartment could expose you to hot gases or other service products. There is a risk of injury.

Let an overheated engine cool down before opening the hood. If there is a fire in the engine compartment, keep the hood closed and contact the fire department.

The coolant temperature gauge is in the instrument cluster on the left-hand side. Under normal operating conditions and with the specified coolant level, the coolant temperature may rise to 248 °F (120 °C).

A display message is shown if the coolant temperature is too high.

If the coolant temperature is over 248 °F(120 °C), do not continue driving. The engine will otherwise be damaged.

#### **Tachometer**

The red band in the tachometer indicates the engine's overrevving range.

Do not drive in the overrevving range, as this could damage the engine.

The fuel supply is interrupted to protect the engine when the red band is reached.



#### Outside temperature display

You should pay special attention to road conditions when temperatures are around freezing point.

The outside temperature display is in the multifunction display (> page 218).

Changes in the outside temperature are displayed after a short delay.

#### Speedometer with segments

The segments in the speedometer indicate which speed range is available.

- Cruise control activated (> page 169):
   The segments light up from the stored speed to the maximum speed.
- DISTRONIC PLUS activated (▷ page 171):
   One or two segments in the set speed range light up.
- DISTRONIC PLUS detects a vehicle in front:
   The segments between the speed of the vehicle in front and the stored speed light up.

#### Operating the on-board computer

#### Overview

The on-board computer is activated as soon as you turn the SmartKey to position 1 in the ignition lock.

You can control the multifunction display and the settings in the on-board computer using the buttons on the multifunction steering wheel.



- Multifunction display
- ② Switches on the Voice Control System; see the separate operating instructions
- (3) Right control panel
- (4) Left control panel
- (5) Back button

#### Left control panel



Calls up the menu and menu bar



#### Press briefly:



- · Scrolls in lists
- Selects a submenu or function
- In the Audio menu: selects a stored station, an audio track or a video scene
- In the Te1 (telephone) menu: switches to the phone book and selects a name or telephone number



#### Press and hold:

- In the Audio menu: selects the previous/next station or selects an audio track or a video scene using rapid scrolling
- In the Tel (Telephone) menu: starts rapid scrolling of the phone book if it is open



- Confirms a selection/display message
- In the Te1 (Telephone) menu: switches to the telephone book and starts dialing the selected number
- In the Audio menu: stops the station search function at the desired station

#### Right control panel



- Rejects or ends a call
- Exits phone book/redial memory



- · Makes or accepts a call
- Switches to the redial memory



- Adjusts the volume
- Mute

#### **Back button**



#### Press briefly:

- Back
- Switches off the Voice Control System; see the separate operating instructions
- Hides display messages/calls up the last Trip menu function used
- Exits the telephone book/redial memory



#### Press and hold:

 Calls up the standard display in the Trip menu

#### **Multifunction display**

Values and settings as well as display messages are shown in the multifunction display.



- 1 Text field
- ② Menu bar
- ③ Drive program (⊳ page 149)
- (4) Transmission position (> page 149)
- (5) Time
- ⑥ Permanent display: outside temperature or speed (▷ page 227)
- ► To show menu bar ②: press the or ► button on the steering wheel.

Menu bar ② disappears after a few seconds.



Text field ① shows the selected menu or submenu as well as display messages.

1 You can set the time using the audio system or COMAND, see the separate operating instructions.

The following messages may appear in the multifunction display:

CRUISE Cruise control (> page 169)

Rear window wiper (> page 121)

Adaptive Highbeam Assist (▷ page 114)

The state of the

ECO start/stop function (> page 144)

Lane Keeping Assist (▷ page 200) or Active Lane Keeping Assist (▷ page 205)

HOLD function (⊳ page 179)

 PRE-SAFE® Brake (▷ page 69)

#### Menus and submenus

#### Menu overview

Operating the on-board computer (⊳ page 217).

Depending on the equipment installed in the vehicle, you can call up the following menus:

- Trip menu (⊳ page 219)
- Navi menu (navigation instructions)
   (▷ page 221)
- Audio menu (⊳ page 222)
- Te1 menu (telephone) (⊳ page 223)
- DriveAssist menu (assistance)
   (▷ page 224)
- Serv menu (⊳ page 226)
- Sett. menu (settings) (⊳ page 226)

The Audio, Navi and Tel menus differ slightly in vehicles with an audio system and in vehicles with COMAND. The examples given in this Operator's Manual apply to vehicles equipped with COMAND.

#### Trip menu

#### Standard display



► Press and hold the button on the steering wheel until the Trip menu with trip odometer ① and odometer ② is shown.

### Trip computer "From Start" or "From Reset"



Example: trip computer "From Start"

- ① Distance
- ② Time
- 3 Average speed
- 4 Average fuel consumption
- ► Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select From Start or From Reset.

The values in the From Start submenu are calculated from the start of a journey, whereas the values in the From Reset submenu are calculated from the last time the submenu was reset (▷ page 220).

The From Start trip computer is automatically reset if:

- the ignition has been switched off for more than four hours.
- 999 hours have been exceeded.
- 9999 miles have been exceeded.



The From Reset trip computer is automatically reset if the value exceeds 9,999 hours or 99,999 miles.

# Displaying the range and current fuel consumption



- ► Press the or button on the steering wheel to select the Trip menu.
- ▶ Press the ▲ or ▼ button to select the current fuel consumption and approximate range.

The approximate range that can be covered depends on the fuel level and your current driving style. If there is only a small amount of fuel left in the fuel tank, the display shows a vehicle being refueled instead of the range.

#### **ECO** display



Example: ECO display

- ► Press the or button on the steering wheel to select the Trip menu.
- ▶ Press or to select ECO DISPLAY.

If the ignition remains switched off for longer than four hours, the ECO display will be automatically reset.

Further information on the ECO display (> page 163).

#### Digital speedometer



- 1 Digital speedometer
- ► Press the or button on the steering wheel to select the Trip menu.
- ► Press the ▲ or ▼ button to select the digital speedometer.

#### Resetting values



Example: resetting the trip computer "From Start"

- ► Press the or button on the steering wheel to select the Trip menu.
- ► Press the or button to select the function that you wish to reset.
- ► Press the OK button.
- ► Press the ▼ button to select Yes and press the OK button to confirm.

You can reset the values of the following functions:

- Trip odometer
- "From Start" trip computer
- "From Reset" trip computer
- ECO display



#### Navigation system menu

#### Displaying navigation instructions

In the Navi menu, the multifunction display shows navigation instructions. For more information, see the separate operating instructions.

- Switch on the audio system with Becker<sup>®</sup> MAP PILOT or COMAND; see the separate operating instructions.
- ► Press the or button on the steering wheel to select the Navi menu.

#### Route guidance not active



- Direction of travel
- (2) Current road

#### Route guidance active

#### No change of direction announced



- (1) Distance to the destination
- ② Distance to the next change of direction
- (3) Current road
- 4 "Follow the road's course" symbol

### Change of direction announced without a lane recommendation



- Road into which the change of direction leads
- Distance to change of direction and visual distance display
- ③ Change-of-direction symbol

When a change of direction is announced, you will see symbol ③ for the change of direction and distance graphic ②. The distance indicator shortens towards the top of the display as you approach the point of the announced change of direction.

### Change of direction announced with a lane recommendation



- Road into which the change of direction leads
- ② Distance to change of direction and visual distance display
- ③ New lane during a change of direction
- 4 Uninterrupted lane
- 5 Lane recommendation
- 6 Change-of-direction symbol

On multilane roads, the system can display lane recommendation (5) for the next change of direction. During the change of direction, additional lanes may be displayed.

Lane recommendations are only displayed if the relevant data is available on the digital map.



# Other status indicators of the navigation system

- 🔯 : you have reached the destination or an intermediate destination.
- New Route... or Calculating Route: calculating a new route
- Off Map or Off Mapped Road: the vehicle position is outside the area of the digital map (off-map position).
- No Route: no route could be calculated to the selected destination.

#### Audio menu

#### Selecting a radio station

1 SIRIUS XM satellite radio functions like a normal radio.

For more information on satellite radio operation, see the separate operating instructions.

- 1 For information on switching waveband and storing stations; see the separate operating instructions.
- Switch on the audio system or COMAND and select Radio (see the separate operating instructions).
- ► Press the or button on the steering wheel to select the Audio menu.



- Waveband
- ② Station frequency with memory position

- ► To select a stored station: briefly press the a or button.
- ► To select a station from the station list: press and briefly hold the 
  or ▼ button.

If no station list is received:

➤ To select a station using the station search: press and briefly hold the 
or ▼ button.

### Operating an audio player or audio media

Audio data from various audio devices or media can be played, depending on the equipment installed in the vehicle.

- Switch on the audio system or COMAND and select the audio player or medium, see the separate operating instructions.
- ► Press the or button on the steering wheel to select the Audio menu.



Example: CD/DVD changer display

- Current title

If you press and hold or , the rapid scrolling speed is increased. Not all audio drives or data carriers support this function. If track information is stored on the audio device or medium, the multifunction display will show the number and name of the track. The current track does not appear in audio AUX mode (Auxiliary audio mode: external audio source connected).



#### Video DVD operation

- ► Switch on COMAND and select video DVD; see the separate operating instructions.
- ► Press the or button on the steering wheel to select the Audio menu.



Example: CD/DVD changer display

- ① Current scene
- ► To select the next/previous scene: briefly press the or button.

#### Telephone menu

#### Introduction

### **↑** WARNING

If you operate information systems and communication equipment integrated in the vehicle while driving, you will be distracted from traffic conditions. You could also lose control of the vehicle. There is a risk of an accident.

Only operate the equipment when the traffic situation permits. If you are not sure that this is possible, park the vehicle paying attention to traffic conditions and operate the equipment when the vehicle is stationary.

When telephoning, you must observe the legal requirements for the country in which you are currently driving.

- Switch on your mobile phone and audio system or COMAND, see the separate operating instructions.
- Establish a Bluetooth® connection to the audio system or COMAND; see the separate operating instructions.
- ► Press the or button on the steering wheel to select the Tel menu.

You will see one of the following display messages in the multifunction display:

- Phone READY or the name of the network provider: the mobile phone has found a network and is ready to receive.
- Phone No Service: there is no network available or the mobile phone is searching for a network.

#### Accepting a call

If someone calls you when you are in the Tel menu, a display message appears in the multifunction display, for example:



► Press the button on the steering wheel to accept an incoming call.

You can accept a call even if you are not in the Te1 menu.

#### Rejects or ends a call

▶ Press the button on the steering wheel.

You can end or reject a call even if you are not in the Te1 menu.



#### Dialing a number from the phone book

- ► Press the or button on the steering wheel to select the Te1 menu.
- ▶ Press the ▲, ▼ or OK button to switch to the phone book.
- ▶ Press the ▲ or ▼ button to select the desired name.

Or

- ➤ To begin rapid scrolling: press and hold the ▲ or ▼ button for longer than one second.
  - Rapid scrolling stops when you release the button or reach the end of the list.
- ▶ If only one telephone number is stored for a name: press the or OK button to start dialing.

or

- ▶ If there is more than one number for a particular name: press the or OK button to display the numbers.
- ▶ Press the ▲ or ▼ button to select the number you want to dial.
- ► Press the or OK button to start dialing.

or

► To exit the telephone book: press the ☐ or ☐ button.

#### Redialing

The on-board computer saves the last names or numbers dialed in the redial memory.

- ► Press the or button on the steering wheel to select the Te1 menu.
- ► Press the button to switch to the redial memory.
- ▶ Press the ▲ or ▼ button to select the desired name or number.
- ► Press the or OK button to start dialing.

or

▶ If you do not want to make a call: press the or button.

#### Assistance menu

#### Introduction



In the DriveAssist menu, you have the following options:

- Showing the distance display
   (▷ page 224)
- Activating/deactivating PRE-SAFE® Brake (> page 225)
- Activating/deactivating ATTENTION ASSIST (> page 225)
- Activating/deactivating Blind Spot Assist or Active Blind Spot Assist (▷ page 225)
- Activating/deactivating Lane Keeping Assist or Active Lane Keeping Assist (▷ page 225)

#### showing the distance display

This function is only available with DISTRONIC PLUS.

- ▶ Press the or button on the steering wheel to select the DriveAssist menu.
- ▶ Press the or button to select Distance Display.
- ► Press the OK button. The DISTRONIC PLUS distance display (> page 176) appears in the multifunction display.

If the Sensors Deactivated message appears, the radar sensor system is deactivated.

► Switch on the radar sensor system (> page 229).



### Activating/deactivating PRE-SAFE® Brake

PRE-SAFE® Brake is only available in vehicles with DISTRONIC PLUS.

- ► Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select PRE-SAFE Brake.
- ► Press the OK button.

  The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

When PRE-SAFE® Brake (▷ page 69) is activated, the multifunction display shows the □□[c] symbol as long as the HOLD function is not activated (▷ page 179).

#### Vehicles with Parking Guidance: if

PARKTRONIC is activated and you are driving at a speed below 22 mph (35 km/h), the Parking Guidance symbol is shown instead of the state symbol.

If the PRE-SAFE Brake: Sensors
Deactivated message appears, the radar sensor system is deactivated.

➤ Switch on the radar sensor system (> page 229).

For more information on PRE-SAFE® Brake, see (▷ page 69).

### Activating/deactivating ATTENTION ASSIST

- ► Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Attention Assist.
- ► Press the OK button.
  The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

When ATTENTION ASSIST (> page 197) is activated, the \_\_\_\_\_\_ symbol appears in the multifunction display when the ignition is on. For further information about ATTENTION ASSIST, see (> page 197).

### Activating/deactivating Blind Spot Assist

- ▶ Press the ◀ or ▶ button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Blind Spot Assist.
- ► Press the OK button.
  The current selection is displayed.
- ► To activate/deactivate: press the OK button again.

If the Blind Spot Assist Sensors Deactivated or Act. Blind Spot Asst. Sensors Deactivated message appears, the radar sensor system is deactivated.

► Switch on the radar sensor system (> page 229).

For further information about Blind Spot Assist, see (▷ page 198).

For further information about Active Blind Spot Assist, see (▷ page 202).

### activating/deactivating Lane Keeping Assist

- ► Press the or button on the steering wheel to select the DriveAssist menu.
- ► Press the ▲ or ▼ button to select Lane Keep. Asst.
- ► Press the OK button.
  The current selection is displayed.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to set Off, Standard or Adaptive.
- ▶ Press the OK button to save the setting.



When Lane Keeping Assist or Active Lane Keeping Assist is activated, the Asymbol appears in the multifunction display when the ignition is on.

For further information about Lane Keeping Assist, see (▷ page 200).

For further information about Active Lane Keeping Assist, see (> page 205).

#### Maintenance menu



In the Serv. menu, you have the following options:

- Calling up display messages
   (▷ page 231)
- Restarting the tire pressure loss warning system (Canada only) (▷ page 335)
- Checking the tire pressure electronically (USA only) (⊳ page 336)
- Calling up the service due date (> page 298)

#### Settings menu

#### Introduction



In the Sett. menu, you have the following options:

- Changing the instrument cluster settings (▷ page 226)
- Changing the light settings (> page 227)

- Changing the vehicle settings
   (▷ page 228)
- Changing the convenience settings (▷ page 229)
- Restoring the factory settings (> page 230)

#### Instrument cluster

### Selecting the unit of measurement for distance

#### The Display Unit Speed-/Odometer:

function allows you to choose whether certain displays appear in kilometers or miles in the multifunction display.

You can determine whether the multifunction display shows some messages in miles or kilometers.

- ▶ Press the ◀ or ▶ button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Instr. Cluster submenu.
- ► Press OK to confirm.
- ▶ Press the ▼ or ▲ button to select the Display Unit Speed-/Odometer: function.

You will see the selected setting: km or miles.

► Press the OK button to save the setting.

The selected unit of measurement for distance applies to:

- the digital speedometer in the Trip menu
- the odometer and the trip odometer
- the trip computer
- current consumption and the range
- the navigation instructions in the Navi menu
- cruise control
- DISTRONIC PLUS
- ASSYST PLUS service interval display



#### Selecting the permanent display function

You can determine whether the multifunction display permanently shows your speed or the outside temperature.

- ► Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Instr. Cluster submenu.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Permanent Display: function.

  You will see the selected setting Outside Temperature or Speedometer [km/h]

  (USA)/Speedometer [mph] (Canada).
- ▶ Press the OK button to save the setting.
- 1 The speed is shown in km/h (USA)/mph (Canada).

### Lights

### Switching the daytime running lamps on/

Daytime running lamps are required by law (Canada only). You cannot set the "daytime running lamps" function via the on-board computer.

- ► Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ▶ Press OK to confirm.
- Press the ▼ or ▲ button to select the Day Lights function.
  If the Day Lights function has been switched on, the cone of light and the ★ symbol in the multifunction display are shown in red.
- ▶ Press the OK button to save the setting.

Further information on daytime running lamps (▷ page 111).

### Setting the brightness of the display/ switch

- ▶ Press the or button on the steering wheel to select the Sett. menu.
- ▶ Press the ▼ or ▲ button to select the Lights submenu.
- ► Press OK to confirm.
- ▶ Press the ▼ or ▲ button to select the Brightness Display/Switches: function.

You will see the selected setting.

- ▶ Press OK to confirm.
- ▶ Press the ▼ or ▲ button to adjust the brightness to any level from Level 1 to Level 5 (bright).
- ► Press the OK or <u></u> button to save the setting.

### Switching Adaptive Highbeam Assist on/

- ► Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Adapt. Highbeam function.

  If the Adapt. Highbeam function has been switched on, the cone of light and the 

  symbol in the upper multifunction display are shown in red.
- ► Press the OK button to save the setting.

For further information about Adaptive Highbeam Assist, see (▷ page 114).

# Activating/deactivating surround lighting and exterior lighting delayed switch-off

- ▶ Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ► Press OK to confirm.



- ► Press the ▼ or ▲ button to select the Surround Lighting function.

  When the Surround Lighting function is activated, the light cone and the area around the vehicle are displayed in red in the multifunction display.
- ► Press the OK button to save the setting.

Deactivating delayed switch-off of the exterior lighting temporarily:

- ► Before leaving the vehicle, turn the SmartKey to position **0** in the ignition lock.
- ► Turn the SmartKey to position 2 in the ignition lock.

  The exterior lighting delayed switch-off in the exte

The exterior lighting delayed switch-off is deactivated.

Delayed switch-off of the exterior lighting is reactivated the next time you start the engine.

If you have activated the Surround Lighting function and the light switch is set to AUTO, the following functions are activated when it is dark:

- surround lighting: the exterior lighting remains lit for 40 seconds after unlocking with the key. If you start the engine, the surround lighting is switched off and automatic headlamp mode is activated (> page 111).
- exterior lighting delayed switch-off: the exterior lighting remains lit for 60 seconds after the engine is switched off. If you close all the doors and the tailgate, the exterior lighting goes off after 5 seconds.
- 1 Depending on your vehicle's equipment, when the surround lighting and delayed switch-off exterior lighting are on, the following light up:
  - Parking lamps
  - Front fog lamps
  - Low-beam headlamps
  - Daytime running lamps
  - Side marker lamps
  - · Surround lighting in the exterior mirrors

### Activating/deactivating the interior lighting delayed switch-off

If you activate the Light. Delay function, the interior lighting remains on for 20 seconds after you remove the key from the ignition lock.

- ▶ Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Lights submenu.
- ▶ Press OK to confirm.
- ▶ Press the ▼ or ▲ button to select the Light. Delay function. When the Light. Delay function is activated, the vehicle interior is displayed in red in the multifunction display.
- ▶ Press the OK button to save the setting.

#### Vehicle

### Activating/deactivating the automatic door locking mechanism

- ► Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Vehicle submenu.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Auto. Door Locks function.

  When the Auto. Door Locks function is activated, the vehicle doors are displayed in red in the multifunction display.
- ► Press the OK button to save the setting.

If you activate the Auto. Door Locks function, the vehicle is centrally locked above a speed of around 9 mph (15 km/h).

For further information on the automatic locking feature, see (▷ page 80).

# Activating/deactivating the acoustic locking verification signal

If you switch on the Acoustic Lock function, an acoustic signal sounds when you lock the vehicle.



- ▶ Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Vehicle submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Acoustic Lock function.

  If the Acoustic Lock function is activated, the ⑤ symbol in the multifunction display lights up red.
- ▶ Press the OK button to save the setting.

### Activating/deactivating the radar sensor system

- ▶ Press the or button on the steering wheel to select the Sett. menu.
- ▶ Press the or button to select the Vehicle submenu.
- ▶ Press OK to confirm.
- Press the ▲ or ▼ button to select Radar Sensor (See Oper. Manual):. You will see the selected setting: Enabled or Disabled.
- ► Press the OK button to save the setting.

The following systems are switched off when the radar sensor system is deactivated:

- DISTRONIC PLUS (> page 171)
- BAS PLUS (⊳ page 65)
- PRE-SAFE® Brake (▷ page 69)
- Blind Spot Assist (> page 198) or Active Blind Spot Assist (> page 202)

#### Convenience

#### Activating/deactivating the EASY-ENTRY/EXIT feature



When the EASY-ENTRY/EXIT feature adjusts the steering wheel and the driver's seat, you and other vehicle occupants – particularly children – could become trapped. There is a risk of injury.

While the EASY-ENTRY/EXIT feature is making adjustments, make sure that no one has any body parts in the sweep of the seat and the steering wheel.

If somebody becomes trapped:

- press one of the memory function position buttons, or
- move the switch for steering wheel adjustment in the opposite direction to that in which the steering wheel is moving.

The adjustment process is stopped.

- ▶ Press the ◀ or ▶ button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Convenience submenu.
- ► Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Easy Entry/Exit function.

  If the Easy Entry/Exit function is activated, the vehicle steering wheel is displayed in red in the multifunction display.
- ► Press the OK button to save the setting.

Further information on the EASY-ENTRY/EXIT feature (> page 102).

#### Switching the belt adjustment on/off

- ▶ Press the ◀ or ▶ button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Convenience submenu.
- ► Press OK to confirm.
- ▶ Press the ▼ or ▲ button to select the Belt Adjustment function. When the Belt Adjustment function is activated, the vehicle seat belt is displayed in red in the multifunction display.
- ► Press the OK button to save the setting.

For further information on belt adjustment, see (▷ page 56).



### Switching the fold-in mirrors when locking feature on/off

This function is only available on vehicles with the memory function (▷ page 106).

This function is only available in Canada.

When you activate the Auto. Mirror Folding function, the exterior mirrors are folded in when the vehicle is locked. If you unlock the vehicle and then open a door, the exterior mirrors fold out again.

- ▶ Press the ◀ or ▶ button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Convenience submenu.
- ▶ Press OK to confirm.
- ► Press the ▼ or ▲ button to select the Auto. Mirror Folding function. If the Auto. Mirror Folding function is activated, the vehicle's exterior mirror is displayed in red in the multifunction display.
- ▶ Press the OK button to save the setting.

If you have switched the Auto. Mirror Folding function on and you fold the exterior mirrors in using the button on the door (⊳ page 104), they will not fold out automatically. The exterior mirrors can then only be folded out using the button on the door.

#### Restoring the factory settings

- ► Press the or button on the steering wheel to select the Sett. menu.
- ► Press the ▼ or ▲ button to select the Factory Setting submenu.
- ► Press OK to confirm.

  The Reset All Settings? message appears.

- ► Press the ▼ or ▲ button to select No or Yes.
- ► Press the OK button to confirm the selection.

If you have selected Yes, the multifunction display shows a confirmation message.

For safety reasons, the Day Lights function in the Lights submenu is only reset if the vehicle is stationary.



#### Display messages

#### **General notes**

Display messages appear in the multifunction display.

Display messages with graphic displays may be shown in simplified form in the Operator's Manual and may therefore differ from the multifunction display.

Please respond in accordance with the display messages and follow the additional notes in this Operator's Manual.

Certain display messages are accompanied by an audible warning tone or a continuous tone. When the ignition is switched off, all display messages are deleted, apart from some high-priority display messages. Once the causes of the high-priority display messages have been rectified, the corresponding display messages are also deleted.

When you stop and park the vehicle, please observe the notes on the HOLD function ( $\triangleright$  page 179) and parking ( $\triangleright$  page 160).

#### Hiding display messages

▶ Press the OK or button on the steering wheel to hide the display message. The display message is cleared.

The multifunction display shows high-priority display messages in red. Some high-priority display messages cannot be hidden.

The multifunction display shows these messages continuously until the causes for the messages have been remedied.

#### Message memory

The message memory allows you to call up previous display messages.

- ► Press the o or button on the steering wheel to select the Serv. menu.

  If there are display messages, the multifunction display shows 2 messages, for example.
- ▶ Press the ▲ or ▼ button to select the entry, e.g. 2 messages.
- ▶ Press OK to confirm.
- ▶ Press the or button to scroll through the display messages.



#### Safety systems

#### Display messages



Current1v Unavailable See Operator's Manual

#### Possible causes/consequences and ▶ Solutions

ABS (Anti-lock Braking System), ESP® (Electronic Stability Program), BAS (Brake Assist), PRE-SAFE®, the HOLD function, hill start assist and ESP® trailer stabilization are temporarily unavailable.

BAS PLUS and PRE-SAFE® Brake may also have failed.

In addition, the 🗐, 🔚 and 🍥 warning lamps light up in the instrument cluster.

ATTENTION ASSIST is deactivated.

Possible causes are:

- self-diagnosis is not yet complete.
- the on-board voltage may be insufficient.

#### **↑** WARNING

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle.

There is an increased risk of skidding and an accident.

► Carefully drive on a suitable stretch of road, making slight steering movements at a speed above 12 mph (20 km/h). If the display message disappears, the functions mentioned above are available again.

If the display message continues to be displayed:

- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.



Inoperative See Operator's Manual ESP®, BAS, PRE-SAFE®, the HOLD function, hill start assist and ESP® trailer stabilization are unavailable due to a malfunction.

BAS PLUS and PRE-SAFE® Brake may also have failed.

In addition, the 📳 and 🐉 warning lamps light up in the instrument cluster.

The self-diagnosis function might not be complete, for example. ATTENTION ASSIST is deactivated.



#### **↑** WARNING

The brake system continues to function normally, but without the functions listed above.



Dienley masses	Pensible serves /senserveness and N Colutions
Display messages	Possible causes/consequences and ▶ Solutions  The braking distance in an emergency braking situation can thus increase.  If ESP® is not operational, ESP® is unable to stabilize the vehicle.  There is an increased risk of skidding and an accident.  ▶ Carefully drive on a suitable stretch of road, making slight steering movements at a speed above 12 mph (20 km/h). If the display message disappears, the functions mentioned above are available again.  If the display message continues to be displayed:  ▶ Drive on carefully.
	► Visit a qualified specialist workshop.
EBD (m) Inoperative See Operator's Manual	EBD (electronic brake force distribution), ABS, ESP®, BAS, PRE-SAFE®, the HOLD function, hill start assist and ESP® trailer stabilization are unavailable due to a malfunction.  BAS PLUS and PRE-SAFE® Brake may also have failed.  In addition, the , and warning lamps light up in the instrument cluster and a warning tone sounds.
	MARNING  The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.  The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.  If ESP® is not operational, ESP® is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.  ▶ Drive on carefully.  ▶ Visit a qualified specialist workshop immediately.
PARK (USA only) (Canada only) Release Parking Brake	You are driving with the parking brake applied. A warning tone also sounds.  ▶ Release the parking brake.



Display messages	Possible causes/consequences and ▶ Solutions
only) (Canada only) Check Brake Fluid Level	There is not enough brake fluid in the brake fluid reservoir.  In addition, the RAME (USA only)/ (①) (Canada only) warning lamp lights up in the instrument cluster and a warning tone sounds.  ★ WARNING  The braking effect may be impaired.  There is a risk of an accident.  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.  ▶ Secure the vehicle against rolling away (▷ page 160).  ▶ Consult a qualified specialist workshop.  ▶ Do not add brake fluid. This does not correct the malfunction.
Check Brake Pad Wear	The brake pads/linings have reached their wear limit.  ▶ Visit a qualified specialist workshop.
mbrace Inoperative	One or more main features of the mbrace system are malfunctioning.  ▶ Have the mbrace system checked immediately at a qualified specialist workshop.
PRE-SAFE Inoperative See Operator's Manual	Important functions of PRE-SAFE® have failed. All other occupant safety systems, e.g. air bags, remain available.  ► Visit a qualified specialist workshop immediately.



Display messages	Possible causes/consequences and ▶ Solutions
PRE-SAFE Functions Currently Limited See Operator's Manual	<ul> <li>PRE-SAFE® Brake is temporarily inoperative. Possible causes are:</li> <li>function is impaired due to heavy rain or snow.</li> <li>the sensors in the radiator grill and the bumper are dirty.</li> <li>the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.</li> <li>the system is outside the operating temperature range.</li> <li>the on-board voltage is too low.</li> <li>When the causes stated above no longer apply, the display message disappears.</li> <li>PRE-SAFE® Brake is operational again.</li> <li>If the display message does not disappear:</li> <li>Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>Secure the vehicle against rolling away (&gt; page 160).</li> <li>Clean the sensors in the radiator grill and the bumper (&gt; page 307).</li> <li>Restart the engine.</li> </ul>
PRE-SAFE Functions Limited See Operator's Manual	PRE-SAFE <sup>®</sup> Brake is inoperative due to a malfunction. BAS PLUS or the distance warning signal may also have failed.  ▶ Visit a qualified specialist workshop.
SRS Malfunction Service Required	There is a malfunction in the SRS (Supplemental Restraint System). The → warning lamp also lights up in the instrument cluster.



#### Display messages



Front Left
Malfunction
Service Required
or Front Right
Malfunction
Service Required

#### Possible causes/consequences and ▶ Solutions

SRS has malfunctioned at the front on the left or right. The yarning lamp also lights up in the instrument cluster.

#### **MARNING**

The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

▶ Visit a qualified specialist workshop.



Rear Left Malfunction Service Required or Rear Right Malfunction Service Required

#### **↑** WARNING

The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

SRS has malfunctioned at the rear on the left or right. The xarning lamp also lights up in the instrument cluster.

▶ Visit a qualified specialist workshop.



Rear Center Malfunction Service Required

#### **№ WARNING**

The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

Visit a qualified specialist workshop.



Left Side Curtain Airbag Malfunction Service Required or Right Side Curtain Airbag Malfunction Service Required There is a malfunction in the left-hand or right-hand window curtain air bag.

The yarning lamp also lights up in the instrument cluster.

#### **⚠ WARNING**

The left or right window curtain air bag may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

► Visit a qualified specialist workshop.



#### Display messages

#### Front Passenger Airbag Disabled See Operator's Manual

#### Possible causes/consequences and ▶ Solutions

The front-passenger air bag is disabled during the journey, even though:

- an adult
- a person larger than a certain size is occupying the frontpassenger seat

If additional forces are applied to the seat, the system may interpret the occupant's weight as lower than it actually is.

#### **↑** WARNING

The front-passenger air bag does not deploy during an accident. There is an increased risk of injury.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.
- ► Secure the vehicle against rolling away (> page 160).
- ▶ Switch the ignition off.
- ► Have the occupant get out of the vehicle.
- ► Keep the seat unoccupied, close the front-passenger door and switch on the ignition.
- ► Observe the PASSENGER AIRBAG OFF indicator lamp in the center console and the multifunction display and check the following:

Seat unoccupied and ignition switched on:

- the PASSENGER AIRBAG OFF indicator lamp must light up and remain lit. If the indicator lamp is on, OCS has disabled the front-passenger air bag (▷ page 47).
- the Front Passenger Airbag Enabled See Operator's Manual or Front Passenger Airbag Disabled See Operator's Manual display messages must not be shown in the multifunction display.
- ▶ Wait for a period of at least 60 seconds until the necessary system checks have been completed.
- ► Make sure that the display messages do not appear in the multifunction display.

If these conditions are fulfilled, the front-passenger seat can be occupied again. Whether the PASSENGER AIRBAG OFF indicator lamp remains lit or goes out depends on how OCS classifies the occupant.

If the conditions are not fulfilled, the system is not operating correctly.

► Visit a qualified specialist workshop immediately.



Possible causes/consequences and ▶ Solutions
For further information about the Occupant Classification System, see ( $\rhd$ page 47).
see (▷ page 47).  The front-passenger air bag is enabled during the journey, even though:  • a child, a small adult or an object weighing less than the system's weight threshold is located on the front-passenger seat or  • the front-passenger seat is unoccupied  The system may detect objects or forces applying additional weight on the seat.  ★ WARNING  The air bag may deploy unintentionally.  There is an increased risk of injury.  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Secure the vehicle against rolling away (▷ page 160).  ▶ Switch the ignition off.  ▶ Open the front-passenger door.  ▶ Remove the child and the child restraint system from the front-passenger seat.  ▶ Make sure that there are no objects on the seat adding to the weight.  The system may otherwise detect the additional weight and interpret the seat occupant's weight as greater than it actually is.  ▶ Keep the seat unoccupied, close the front-passenger door and switch on the ignition.  ▶ Observe the PASSENGER AIRBAG OFF indicator lamp in the center console and the multifunction display and check the following:  Seat unoccupied and ignition switched on:  • the PASSENGER AIRBAG OFF indicator lamp must light up and remain lit. If the indicator lamp is on, OCS (Occupant Classification System) has disabled the front-passenger air bag (▷ page 47).  • the Front Passenger Airbag Enabled See Operator's Manual or Front Passenger Airbag Disabled See
<ul> <li>▶ Observe the PASSENGER AIRBAG OFF indicator lamp in the center console and the multifunction display and check the following:</li> <li>Seat unoccupied and ignition switched on:</li> <li>• the PASSENGER AIRBAG OFF indicator lamp must light up and remain lit. If the indicator lamp is on, OCS (Occupant Classification System) has disabled the front-passenger air bag (▷ page 47).</li> <li>• the Front Passenger Airbag Enabled See Operator's</li> </ul>



Display messages	Possible causes/consequences and ▶ Solutions
	► Wait for a period of at least 60 seconds until the necessary system checks have been completed.
	► Make sure that the display messages do not appear in the multifunction display.
	If these conditions are fulfilled, the front-passenger seat can be occupied again. Whether the PASSENGER AIRBAG OFF indicator lamp remains lit or goes out depends on how OCS classifies the occupant.
	If the conditions are not fulfilled, the system is not operating correctly.
	► Visit a qualified specialist workshop immediately.
	For further information about the Occupant Classification System, see (> page 47).

### Lights

1 Display messages about LEDs:

This display message will only appear if all LEDs have failed.

This display message will only appear it all EEDs have falled.	
Display messages	Possible causes/consequences and ▶ Solutions
Check Left Cornering Light or Check Right Cornering Light	The left or right-hand cornering light is defective.  ▶ Check whether you are permitted to replace the bulb yourself (▷ page 116).  or  ▶ Visit a qualified specialist workshop.
Check Left Low Beam or Check Right Low Beam	The left or right-hand low-beam headlamp is defective.  ► Check whether you are permitted to replace the bulb yourself (> page 116).  or  ► Visit a qualified specialist workshop.
Check Trailer Left Tail Lamp or Check Trailer Right Tail Lamp	The left or right-hand trailer tail lamp is faulty.  ▶ Check whether you are permitted to change the bulb yourself. or  ▶ Visit a qualified specialist workshop.



and Brake Lamps

#### Display messages Possible causes/consequences and ▶ Solutions The left or right-hand trailer turn signal lamp is defective. -<u>Ö</u>-► Check whether you are permitted to change the bulb yourself. Check Trailer Left or Turn Signal or ► Visit a qualified specialist workshop. Check Trailer Right Turn Signal The trailer brake lamp is defective. -<u>Ö</u>-▶ Check whether you are permitted to change the bulb yourself. Check Trailer Brake Lamp ► Visit a qualified specialist workshop. The rear left-hand or rear right-hand turn signal is defective. -<u>Ö</u>-► Check whether you are permitted to replace the bulb yourself Check Rear Left (⊳ page 116). Turn Signal or or Check Rear Right ► Visit a qualified specialist workshop. Turn Signal <u>-Ö</u>: The front left-hand or front right-hand turn signal is defective. ► Check whether you are permitted to replace the bulb yourself Check Front Left (⊳ page 116). Turn Signal or or Check Front Right Visit a qualified specialist workshop. Turn Signal The turn signal in the left-hand or right-hand exterior mirror is -<u>Ö</u>defective. Check Left Mirror ► Check whether you are permitted to replace the bulb yourself Turn Signal or (⊳ page 116). Check Right Mirror or Turn Signal ▶ Visit a qualified specialist workshop. The high-mounted brake lamp is faulty. -<u>Ö</u>-► Check whether you are permitted to replace the bulb yourself Check Center Brake (⊳ page 116). Lamp or Visit a qualified specialist workshop. The left or right-hand tail lamp/brake lamp is defective. -<u>Ö</u>-► Check whether you are permitted to replace the bulb yourself Check Left Tail (⊳ page 116). and Brake Lamps or or Check Right Tail



► Visit a qualified specialist workshop.

Display messages	Possible causes/consequences and ▶ Solutions
Check Left High BeamorCheck Right High Beam	The left or right-hand high beam is defective.  ▶ Check whether you are permitted to replace the bulb yourself (▷ page 116).  or  ▶ Visit a qualified specialist workshop.
Check Left License Plate LamporCheck Right License Plate Lamp	The left or right-hand license plate lamp is defective.  ► Check whether you are permitted to replace the bulb yourself (> page 116).  or  ► Visit a qualified specialist workshop.
Check Left Fog LamporCheck Right Fog Lamp	The left-hand or right-hand front fog lamp is defective.  ► Check whether you are permitted to replace the bulb yourself (> page 116).  or  ► Visit a qualified specialist workshop.
歌 Rear fog lamp	The rear fog lamp is defective.  ► Check whether you are permitted to replace the bulb yourself (> page 116).  or  ► Visit a qualified specialist workshop.
Check Front Left Parking Lamp or Check Front Right Parking Lamp	The front left or front right parking or standing lamp is defective.  ► Check whether you are permitted to replace the bulb yourself (> page 116).  or  ► Visit a qualified specialist workshop.
Check Left Reverse Lamp or Check Right Reverse Lamp	The left or right-hand backup lamp is defective.  ▶ Check whether you are permitted to replace the bulb yourself (▷ page 117).  or  ▶ Visit a qualified specialist workshop.
Check Front Left Sidemarker Lamp or Check Front Right Sidemarker Lamp	The left or right front side marker lamp is defective.  ► Check whether you are permitted to replace the bulb yourself (> page 116).  or  ► Visit a qualified specialist workshop.



Display messages	Possible causes/consequences and ▶ Solutions
Check Rear Left Sidemarker Lamp or Check Rear Right Sidemarker Lamp	The rear left or right side marker lamp is defective.  ► Check whether you are permitted to replace the bulb yourself (> page 116).  or  ► Visit a qualified specialist workshop.
Check Left Daytime Running Light or Check Right Daytime Running Light	The left-hand or right-hand daytime running lamp is faulty.  ▶ Check whether you are permitted to replace the bulb yourself (▷ page 116).  or  ▶ Visit a qualified specialist workshop.
Active Headlamps Inoperative	The active light function is defective.  ▶ Visit a qualified specialist workshop.
Malfunction See Operator's Manual	The exterior lighting is defective.  ▶ Visit a qualified specialist workshop.
Malfunction See Operator's Manual	The exterior lighting is defective.  ▶ Visit a qualified specialist workshop.
Auto Lamp Function Inoperative	The light sensor is defective.  ▶ Visit a qualified specialist workshop.
Switch Off Lights	The lights are still switched on when you leave the vehicle. A warning tone also sounds.  ▶ Turn the light switch to ▲  ■  ■  ■  ■  ■  ■  ■  ■  ■  ■  ■  ■  ■



Display messages	Possible causes/consequences and ▶ Solutions
Adaptive Highbeam Assist Inoperative	Adaptive Highbeam Assist is faulty.  ▶ Visit a qualified specialist workshop.
Adaptive Highbeam Assist Currently Unavailable See Operator's Manual	Adaptive Highbeam Assist is deactivated and temporarily inoperative. Possible causes are:  • the windshield in the camera's field of vision is dirty.  • visibility is impaired due to heavy rain, snow or fog.  • Clean the windshield.
	If the system detects that the camera is fully operational again, the Adaptive Highbeam Assist Now Available message is displayed.  Adaptive Highbeam Assist is operational again.

Engine	
Display messages	Possible causes/consequences and ▶ Solutions
	The coolant level is too low.
Check Coolant Level See	Avoid making long journeys with too little coolant in the engine cooling system. The engine will otherwise be damaged.
Operator's Manual	► Add coolant, observing the warning notes before doing so (> page 302).
	▶ If coolant needs to be added more often than usual, have the engine coolant system checked at a qualified specialist workshop.
	The fan motor is faulty.
	► At coolant temperatures below 248 °F (120 °C) drive to the nearest qualified specialist workshop.
	Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.



#### Display messages



Coolant Too Hot Stop Vehicle Turn Engine Off

#### Possible causes/consequences and ▶ Solutions

The coolant is too hot.

A warning tone also sounds.

#### **⚠ WARNING**

Do not drive when your engine is overheated. This can cause some fluids which may have leaked into the engine compartment to catch fire.

Steam from the overheated engine can also cause serious burns which can occur just by opening the hood.

There is a risk of injury.

- Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
- ▶ Secure the vehicle against rolling away (▷ page 160).
- Wait until the engine has cooled down.
- Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
- ▶ Do not start the engine again until the display message goes out and the coolant temperature is below 248 °F (120 °C). Otherwise, the engine could be damaged.
- ▶ Pay attention to the coolant temperature display.
- ► If the temperature increases again, visit a qualified specialist workshop immediately.

Under normal operating conditions and with the specified coolant level, the coolant temperature may rise to 248 °F (120 °C).



Display messages	Possible causes/consequences and ▶ Solutions
	The battery is not being charged.  A warning tone also sounds.  Possible causes are:  • a defective alternator  • a torn poly-V-belt  • a malfunction in the electronics  ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.  ▶ Secure the vehicle against rolling away (▷ page 160).  ▶ Open the hood.  ▶ Check whether the poly-V-belt is torn.  If the poly-V-belt is torn:  ■ Do not continue driving. The engine could otherwise overheat.  ▶ Consult a qualified specialist workshop.  If the poly-V-belt is not damaged:  ▶ Visit a qualified specialist workshop.
Check Engine Oil At Next Refueling	The engine oil level has dropped to the minimum level.  A warning tone also sounds.  Check the oil level when next refueling, at the latest (▷ page 301).  If necessary, add engine oil (▷ page 301).  Have the engine checked at a qualified specialist workshop if engine oil needs to be added more often than usual.  Avoid long journeys with too little engine oil. The engine will otherwise be damaged.  Information on approved engine oils can be obtained from any qualified specialist workshop or on the Internet at http://bevo.mercedes-benz.com.  The fuel level has dropped into the reserve range.
Fuel Level Low	▶ Refuel at the nearest gas station.
	There is only a very small amount of fuel in the fuel tank.  ▶ Refuel at the nearest gas station without fail.



Display messages	Possible causes/consequences and ▶ Solutions
Gas Cap Loose	The fuel system pressure is too low. The fuel filler cap is not closed correctly or the fuel system is leaking.  Check that the fuel filler cap is correctly closed.
	If the fuel filler cap is not correctly closed:
	Close the fuel filler cap.
	If the fuel filler cap is correctly closed:
	► Visit a qualified specialist workshop.
Replace Air Filter	Vehicles with a diesel engine: the engine air filter is dirty and must be replaced.  ▶ Visit a qualified specialist workshop.
Check Fuel Filter	Vehicles with a diesel engine: there is water in the fuel filter. The water must be drained off.  ▶ Visit a qualified specialist workshop.
Refill AdBlue At Workshop See Operator's Manual	The DEF level has fallen below the reserve range. A warning tone also sounds.  ▶ Have DEF refilled as soon as possible at a qualified specialist workshop.
Refill AdBlue At Workshop No Start in km	The DEF level is only sufficient for the indicated distance. A warning tone also sounds.  ▶ Have DEF refilled as soon as possible at a qualified specialist workshop.
Refill AdBlue At Workshop Eng. Start Not Possible	The DEF tank is empty. A warning tone also sounds. You can no longer start the engine.  ▶ Consult a qualified specialist workshop immediately.
Check AdBlue See Operator's Manual	The DEF system is malfunctioning. A warning tone also sounds.  ▶ Visit a qualified specialist workshop.



Display messages	Possible causes/consequences and ▶ Solutions
Eng. Start Not Possible inkm	The DEF system is malfunctioning. A warning tone also sounds.  ▶ Visit a qualified specialist workshop immediately.
Eng. Start Not Possible	The DEF system is malfunctioning. A warning tone also sounds. You can no longer start the engine.  ▶ Consult a qualified specialist workshop immediately.

Driving systems	
Display messages	Possible causes/consequences and ▶ Solutions
Attention Assist: Take a Break!	Based on certain criteria, ATTENTION ASSIST has detected fatigue or a lack of concentration on the part of the driver. A warning tone also sounds.  If necessary, take a break.
	During long journeys, take regular breaks in good time so you get enough rest.
Attention Assist Inoperative	ATTENTION ASSIST is inoperative.  ▶ Visit a qualified specialist workshop.
HOLD Off	The HOLD function is deactivated. The vehicle is skidding. A warning tone also sounds.  ▶ Reactivate the HOLD function later (▷ page 179).
	The HOLD function is deactivated. When the brake pedal is firmly depressed, an activation condition is not fulfilled.  A warning tone also sounds.  ▶ Check the activation conditions for the HOLD function (▷ page 179).
Radar Sensor Deactivated See Operator's Manual	The radar sensor system is deactivated.  ▶ Switch on the radar sensor system (▷ page 229).



Display messages	Possible causes/consequences and ▶ Solutions
Lane Keeping Assist Currently Unavailable See Operator's Manual or Active Lane Keeping Assist Currently Unavailable See Operator's Manual	Lane Keeping Assist or Active Lane Keeping Assist is deactivated and temporarily inoperative. Possible causes are:  • the windshield in the camera's field of vision is dirty.  • visibility is impaired due to heavy rain, snow or fog.  • there are no lane markings for a longer period.  • the lane markings are worn, dark or covered, e.g. by dirt or snow. When the causes stated above no longer apply, the display message disappears.  Lane Keeping Assist or Active Lane Keeping Assist is operational again.  If the display message does not disappear:  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Secure the vehicle against rolling away (▷ page 160).  ▶ Clean the windshield.
Lane Keeping Assist Inoperative or Active Lane Keeping Assist Inoperative	Lane Keeping Assist or Active Lane Keeping Assist is defective.  ▶ Visit a qualified specialist workshop.



#### Display messages Possible causes/consequences and ▶ Solutions Blind Spot Assist Blind Spot Assist or Active Blind Spot Assist is temporarily Currently inoperative. Possible causes are: Unavailable See • the sensors are dirty. Operator's Manual • function is impaired due to heavy rain or snow. or Active Blind • the radar sensor system is outside the operating temperature Spot Assist range. Current1v • the radar sensor system is temporarily inoperative, e.g. due to Unavailable See electromagnetic radiation emitted by nearby TV or radio Operator's Manual stations or other sources of electromagnetic radiation. The yellow indicator lamps also light up in the exterior mirrors. When the causes stated above no longer apply, the display message disappears. Blind Spot Assist or Active Blind Spot Assist is operational again. If the display message does not disappear: ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions ▶ Secure the vehicle against rolling away (▷ page 160). ► Clean the sensors (> page 307). ► Restart the engine. Blind Spot Assist Blind Spot Assist or Active Blind Spot Assist is defective. Inoperative or The yellow indicator lamps also light up in the exterior Active Blind Spot mirrors. Assist Inoperative ► Visit a qualified specialist workshop. Park Assist The driver's door is open and the driver's seat belt has not been Canceled. fastened. ▶ Repeat the parking process with the seat belt fastened and the driver's door closed. You have inadvertently touched the multifunction steering wheel while steering intervention was active. ▶ While steering intervention is active, make sure that the multifunction steering wheel is not touched unintentionally. The vehicle has started to skid and ESP® has intervened. ▶ Use Active Parking Assist again later (▷ page 184).



Display messages	Possible causes/consequences and ▶ Solutions
Park Assist Inoperative	You have just carried out a large number of turning or parking maneuvers.  Active Parking Assist will become available again after approximately ten minutes (▷ page 184).  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Switch off and restart the engine.  If the display message continues to be displayed:  ▶ Visit a qualified specialist workshop.
	PARKTRONIC is defective.  ► Visit a qualified specialist workshop.
Parking Guidance Finished	The vehicle is parked. A warning tone also sounds.  The display message disappears automatically.
DISTRONIC PLUS Off	DISTRONIC PLUS has been deactivated (▷ page 171). If it was deactivated automatically, a warning tone also sounds.
DISTRONIC PLUS Now Available	DISTRONIC PLUS is operational again after having been temporarily unavailable. You can now reactivate DISTRONIC PLUS (▷ page 171).
DISTRONIC PLUS Currently Unavailable See Operator's Manual	<ul> <li>DISTRONIC PLUS is temporarily inoperative. Possible causes are:</li> <li>• function is impaired due to heavy rain or snow.</li> <li>• the sensors in the radiator grill and the bumper are dirty.</li> <li>• the radar sensor system is temporarily inoperative, e.g. due to electromagnetic radiation emitted by nearby TV or radio stations or other sources of electromagnetic radiation.</li> <li>• the system is outside the operating temperature range.</li> <li>• the on-board voltage is too low.</li> <li>A warning tone also sounds.</li> <li>When the causes stated above no longer apply, the display message disappears.</li> <li>DISTRONIC is operational again.</li> <li>If the display message does not disappear:</li> <li>▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.</li> <li>▶ Secure the vehicle against rolling away (▷ page 160).</li> </ul>
	<ul> <li>► Clean the sensors in the radiator grill and the bumper (&gt; page 307).</li> <li>► Restart the engine.</li> </ul>



Display messages	Possible causes/consequences and ▶ Solutions
DISTRONIC PLUS Inoperative	DISTRONIC PLUS is defective. BAS PLUS and PRE-SAFE® Brake may also have failed.  A warning tone also sounds.  ▶ Visit a qualified specialist workshop.
DISTRONIC PLUS Passive	You have depressed the accelerator pedal. DISTRONIC PLUS is no longer controlling the speed of the vehicle.  ▶ Remove your foot from the accelerator pedal.
DISTRONIC PLUS mph	An activation condition for DISTRONIC PLUS is not fulfilled.  ▶ Check the activation conditions for DISTRONIC PLUS (> page 171).
Cruise Control Inoperative	Cruise control is defective. A warning tone also sounds.  ▶ Visit a qualified specialist workshop.
Cruise Control	A condition for activating cruise control has not been fulfilled.  You have tried to store a speed below 20 mph (30 km/h), for example.  ▶ If conditions permit, drive faster than 20 mph (30 km/h) and store the speed.  ▶ Check the activation conditions for cruise control (▷ page 169).



Tires	
Display messages	Possible causes/consequences and ▶ Solutions
Check Tire Pressure Soon	Canada only: The tire pressure loss warning system has detected a significant loss in pressure. A warning tone also sounds.
	★ WARNING With tire pressures which are too low, there is a risk of the following hazards:
	they may burst, especially as the load and vehicle speed increase.
	• they may wear excessively and/or unevenly, which may greatly impair tire traction.
	<ul> <li>the driving characteristics, as well as steering and braking, may be greatly impaired.</li> <li>There is a risk of an accident.</li> </ul>
	<ul> <li>Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.</li> <li>Secure the vehicle against rolling away (▷ page 160).</li> <li>Check the tires and, if necessary, follow the instructions for a flat tire (▷ page 312).</li> <li>Check the tire pressures and, if necessary, correct the tire pressure.</li> <li>Restart the tire pressure loss warning system when the tire pressure is correct (▷ page 335).</li> </ul>
Run Flat Indicator Then Restart Run Flat Indicator	Canada only:  The tire pressure loss warning system generated a display message and has not been restarted since.  ▶ Set the correct tire pressure in all four tires.  ▶ Restart the tire pressure loss warning system (▷ page 335).
Run Flat Indicator Inoperative	Canada only:  The tire pressure loss warning system is faulty.  ▶ Visit a qualified specialist workshop.
Correct Tire Pressure	The tire pressure is too low in at least one of the tires, or the tire pressure difference between the wheels is too great.  ▶ Check the tire pressures at the next opportunity (▷ page 336).  ▶ If necessary, correct the tire pressure.  ▶ Restart the tire pressure monitor (▷ page 338).



Display messages	Possible causes/consequences and ▶ Solutions
Check Tires	The tire pressure in one or more tires has dropped significantly. The wheel position is displayed in the multifunction display. A warning tone also sounds.
	<b>⚠</b> WARNING
	With tire pressures which are too low, there is a risk of the following hazards:
	• they may burst, especially as the load and vehicle speed increase.
	• they may wear excessively and/or unevenly, which may greatly impair tire traction.
	the driving characteristics, as well as steering and braking, may be greatly impaired.  There is a sigle of an assistant.
	<ul> <li>There is a risk of an accident.</li> <li>Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.</li> <li>Secure the vehicle against rolling away (▷ page 160).</li> <li>Check the tires and, if necessary, follow the instructions for a flat tire (▷ page 312).</li> <li>Check the tire pressure (▷ page 336).</li> <li>If necessary, correct the tire pressure.</li> </ul>
Warning Tire Malfunction	The tire pressure in one or more tires has dropped suddenly. The wheel position is shown in the multifunction display.  MARNING
	If you drive with a flat tire, there is a risk of the following hazards:  • a flat tire affects the ability to steer or brake the vehicle.  • you could lose control of the vehicle.  • continued driving with a flat tire will cause excessive heat build-up and possibly a fire.  There is a risk of an accident.
	<ul> <li>Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.</li> <li>Secure the vehicle against rolling away (▷ page 160).</li> <li>Check the tires and, if necessary, follow the instructions for a flat tire (▷ page 312).</li> </ul>



Display messages	Possible causes/consequences and ▶ Solutions
Tire Press. Monitor Currently Unavailable	Due to a source of radio interference, no signals can be received from the wheel sensors. The tire pressure monitor is temporarily malfunctioning.
	▶ Drive on.  The tire pressure monitor restarts automatically as soon as the problem has been solved.
TirePress. Sensor(s) Missing	There is no signal from the tire pressure sensor of one or several wheels. The pressure of the affected tire is not displayed in the multifunction display.  ▶ Have the faulty tire pressure sensor replaced at a qualified specialist workshop.
Tire Pressure Monitor Inoperative No Wheel Sensors	The wheels mounted do not have a suitable tire pressure sensor. The tire pressure monitor is deactivated.  ▶ Mount wheels with suitable tire pressure sensors.  The tire pressure monitor is activated automatically after driving for a few minutes.
Tire Press. Monitor Inoperative	The tire pressure monitor is faulty.  ▶ Visit a qualified specialist workshop.


Vehicle	
Display messages	Possible causes/consequences and ▶ Solutions
Shift to 'P' or 'N' to Start Engine	You have attempted to start the engine with the transmission in position <b>R</b> or <b>D</b> .  ▶ Shift the transmission to position <b>P</b> or <b>N</b> .
P Shift to P	You have attempted to stop the engine with the Start/Stop button while the transmission was not in position <b>P</b> .  ▶ Shift the transmission to position <b>P</b> .
6-01	The tailgate is open.



Display messages	Possible causes/consequences and ▶ Solutions
Fig. 1. Social Section 1. Soci	The hood is open.
	At least one door is open.  ▶ Close all the doors.
Power Steering Malfunction See Operator's Manual	The power steering is malfunctioning. A warning tone also sounds.  ✓ WARNING  You will need to use more force to steer. There is a risk of an accident.  ► Check whether you are able to apply the extra force required.  ► If you are able to steer safely: carefully drive on to a qualified specialist workshop.  ► If you are unable to steer safely: do not drive on. Contact the nearest qualified specialist workshop.
Phone No Service	Your vehicle is outside the network provider's transmitter/ receiver range.  ► Wait until the mobile phone operational readiness symbol appears in the multifunction display.
Check Washer Fluid	The washer fluid level in the washer fluid reservoir has dropped below the minimum.  ▶ Add washer fluid (▷ page 303).



SmartKey	
Display messages	Possible causes/consequences and ▶ Solutions
Key Does Not Belong to Vehicle	You have put the wrong SmartKey in the ignition lock.  ▶ Use the correct SmartKey.
Take Your Key from Ignition	The SmartKey is in the ignition lock.  ▶ Remove the SmartKey.
Obtain a New Key	The SmartKey needs to be replaced.  ▶ Visit a qualified specialist workshop.
Replace Key Battery	The batteries of the KEYLESS-GO key are discharged.  ▶ Change the batteries (▷ page 77).
Don't Forget Your Key	The display message is shown for a maximum of 60 seconds and is only a reminder.  You have opened the driver's door with the engine switched off. The KEYLESS-GO key is not in the ignition lock.  ▶ Remember to take the KEYLESS-GO key with you when you leave the vehicle.
Key Not Detected (red display message)	The KEYLESS-GO key is not in the vehicle.  A warning tone also sounds.  If the engine is switched off, you can no longer lock the vehicle centrally or start the engine.  ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions.  ▶ Secure the vehicle against rolling away (▷ page 160) (▷ page 160).  ▶ Locate the KEYLESS-GO key.
	The KEYLESS-GO key is not detected while the engine is running because there is interference from a strong source of radio waves. A warning tone also sounds.



► Secure the vehicle against rolling away (> page 160).

▶ Pull over and stop the vehicle safely as soon as possible, paying



attention to road and traffic conditions.

Display messages	Possible causes/consequences and ▶ Solutions
Key Not Detected (white display	The KEYLESS-GO key cannot be detected at present.  ▶ Change the location of the SmartKey with the KEYLESS-GO functions in the vehicle.
message)	If the KEYLESS-GO key is still not detected:
	▶ Operate the vehicle with the SmartKey in the ignition lock.
Key Detected in Vehicle	The KEYLESS-GO key has been detected inside the vehicle during locking.  ▶ Remove the KEYLESS-GO key from the vehicle.
Remove 'Start' Button and Insert Key	The KEYLESS-GO key can continuously not be detected.  KEYLESS-GO is temporarily malfunctioning or is defective. A warning tone also sounds.  ▶ Insert the SmartKey into the ignition lock and turn it to the desired position.  ▶ Visit a qualified specialist workshop.
Close Doors to Lock Vehicle	At least one door is open. A warning tone also sounds.  ▶ Close all doors and lock the vehicle again.

# Warning and indicator lamps in the instrument cluster

#### Seat belts **Problem** Possible causes/consequences and ▶ Solutions 4 The seat belt warning lamp reminds the driver and front passenger to fasten their seat belts. After starting the engine, the red seat ► Fasten your seat belt (> page 56). belt warning lamp lights up for 6 seconds. 4 The driver's seat belt is not fastened. After starting the ► Fasten your seat belt (> page 56). engine, the red seat The warning tone ceases. belt warning lamp lights up. In addition, a warning tone sounds for up to six seconds.





The red seat belt warning lamp lights up after the engine starts, as soon as the driver's or the front-passenger door is closed.

# Possible causes/consequences and ▶ Solutions

The driver or front passenger has not fastened their seat belt.

► Fasten your seat belt (▷ page 56). The warning lamp goes out.

There are objects on the front-passenger seat.

 Remove the objects from the front-passenger seat and stow them in a secure place.
 The warning lamp goes out.



The red seat belt warning lamp flashes and an intermittent audible warning sounds.

The driver or front passenger has not fastened their seat belt. The car is being driven faster than 15 mph (25 km/h) or has briefly been driven faster than 15 mph (25 km/h).

► Fasten your seat belt (> page 56).

The warning lamp goes out and the intermittent warning tone ceases.

There are objects on the front-passenger seat. The car is being driven faster than 15 mph (25 km/h) or has briefly been driven faster than 15 mph (25 km/h).

► Remove the objects from the front-passenger seat and stow them in a secure place.

The warning lamp goes out and the intermittent warning tone ceases.



# Safety systems

#### **Problem**

BRAKE (USA only) (Canada only)

The red brake system warning lamp comes on while the engine is running. A warning tone also sounds.

# Possible causes/consequences and ▶ Solutions

There is not enough brake fluid in the brake fluid reservoir.

#### **↑** WARNING

The braking effect may be impaired.

There is a risk of an accident.

- ▶ Pull over and stop the vehicle safely as soon as possible, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- ▶ Secure the vehicle against rolling away (> page 160).
- ▶ Do not add brake fluid. Topping up will not remedy the malfunction.
- ► Consult a qualified specialist workshop.
- ▶ Observe the additional display messages in the multifunction display.



The yellow ABS warning lamp is lit while the engine is running.

ABS (Anti-lock Brake System) is deactivated due to a malfunction. BAS (Brake Assist), BAS PLUS, ESP® (Electronic Stability Program), PRE-SAFE®, PRE-SAFE® Brake, the HOLD function, hill start assist and ESP® trailer stabilization are therefore also deactivated, for example.

ATTENTION ASSIST is deactivated.

#### 

The brake system continues to function normally, but without the functions listed above. The wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle.

There is an increased risk of skidding and an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- Visit a qualified specialist workshop.

If the ABS control unit is faulty, there is also a possibility that other systems, such as the navigation system or the automatic transmission, will not be available.





The yellow ABS warning lamp is lit while the engine is running.

# Possible causes/consequences and ▶ Solutions

ABS is temporarily unavailable. BAS, BAS PLUS, ESP®, EBD (electronic brake force distribution), PRE-SAFE®, PRE-SAFE® Brake, the HOLD function, hill start assist and ESP® trailer stabilization are therefore also deactivated, for example.

Possible causes are:

- Self-diagnosis is not yet complete.
- The on-board voltage may be insufficient.

ATTENTION ASSIST is deactivated.

### **↑** WARNING

The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle.

There is a risk of an accident.

► Carefully drive a suitable distance, making slight steering movements at a speed above 12 mph (20 km/h). The functions mentioned above are available again when the warning lamp goes out.

If the warning lamp is still on:

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ▶ Visit a qualified specialist workshop.





The vellow ABS warning lamp is lit while the engine is running. A warning tone also sounds.

### Possible causes/consequences and ▶ Solutions

EBD is not available due to a malfunction. Therefore, BAS, BAS PLUS, ESP®, PRE-SAFE®, PRE-SAFE® Brake, the HOLD function, hill start assist and ESP® trailer stabilization are also unavailable. for example.

ATTENTION ASSIST is deactivated.

### **↑** WARNING


The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.

BRAKE (USA only)



The red brake warning lamp, the yellow ESP® and ESP® OFF warning lamps and the yellow ABS warning lamp are lit while the engine is running.

ABS and ESP® are not available due to a malfunction. Therefore, BAS, BAS PLUS, EBD, PRE-SAFE®, PRE-SAFE® Brake, the HOLD function, hill start assist and ESP® trailer stabilization are also unavailable, for example.

ATTENTION ASSIST is deactivated.

### **↑** WARNING

The brake system continues to function normally, but without the functions listed above. The front and rear wheels could therefore lock if you brake hard, for example.

The steerability and braking characteristics may be severely affected. The braking distance in an emergency braking situation can increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle. There is an increased risk of skidding and an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.





The yellow ESP® warning lamp flashes while the vehicle is in motion.

# Possible causes / consequences and ▶ Solutions

ESP® or traction control has intervened because there is a risk of skidding or at least one wheel has started to spin.

Cruise control or DISTRONIC PLUS is deactivated.

- ▶ When pulling away, only depress the accelerator pedal as far as necessary.
- ► Ease off the accelerator pedal while the vehicle is in motion.
- ► Adapt your driving style to suit the road and weather conditions.
- ▶ Do not deactivate FSP<sup>®</sup>.

For exceptions, see: (▷ page 66).



The vellow ESP® OFF warning lamp is lit while the engine is running.

ESP® is deactivated.

### **↑** WARNING

If ESP® is switched off, ESP® is unable to stabilize the vehicle.

There is an increased risk of skidding and an accident.

▶ Reactivate FSP®.

For exceptions, see: (⊳ page 66).

▶ Adapt your driving style to suit the road and weather conditions.

If FSP® cannot be activated:

- ▶ Drive on carefully.
- ► Have ESP<sup>®</sup> checked at a qualified specialist workshop.



The vellow ESP® and ESP® OFF warning lamps are lit while the engine is running.

ESP®, BAS, BAS PLUS, PRE-SAFE®, PRE-SAFE® Brake, the HOLD function, hill start assist and ESP® trailer stabilization are unavailable due to a malfunction.

ATTENTION ASSIST is deactivated.

#### **↑** WARNING

The brake system continues to function normally, but without the functions listed above.

The braking distance in an emergency braking situation can thus increase.

If ESP® is not operational, ESP® is unable to stabilize the vehicle.

There is an increased risk of skidding and an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ► Visit a qualified specialist workshop.





The vellow ESP® and ESP® OFF warning lamps are lit while the engine is running.

# Possible causes / consequences and ▶ Solutions

ESP®, BAS, PRE-SAFE®, the HOLD function, hill start assist and ESP® trailer stabilization are temporarily unavailable.

BAS PLUS and PRE-SAFE® Brake may also have failed.

ATTENTION ASSIST is deactivated. Self-diagnosis is not vet complete.

# **↑** WARNING

The brake system continues to function normally, but without the functions listed above.

The braking distance in an emergency braking situation can thus increase.

If ESP® is not operational. ESP® is unable to stabilize the vehicle.

There is an increased risk of skidding and an accident.

► Carefully drive a suitable distance, making slight steering movements at a speed above 12 mph (20 km/h). The functions mentioned above are available again when the warning lamp goes out.

If the warning lamp is still on:

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Drive on carefully.
- ▶ Visit a qualified specialist workshop.



The red SRS warning lamp is lit while the engine is running.

There is a malfunction in the SRS (Supplemental Restraint System).

# **↑** WARNING

The air bags or Emergency Tensioning Devices may either be triggered unintentionally or, in the event of an accident, may not be triggered.

There is an increased risk of injury.

- ▶ Drive on carefully.
- ► Have SRS checked at a qualified specialist workshop immediately.

For further information about the Supplemental Restraint System, see (⊳ page 41).



# **Engine**

# Problem

# Possible causes/consequences and ▶ Solutions



The yellow Check Engine warning lamp lights up while the engine is running. There may be a malfunction, for example:

- in the engine management
- in the fuel injection system
- in the exhaust system
- in the ignition system
- in the fuel system

The emission limit values may be exceeded and the engine may be in emergency mode.

- ► Have the vehicle checked as soon as possible at a qualified specialist workshop.
- i In some states, you must immediately visit a qualified specialist workshop as soon as the yellow Check Engine warning lamp lights up. This is due to the legal requirements in effect in these states. If in doubt, check whether such legal regulations apply in the state in which you are currently driving.



The yellow reserve fuel warning lamp flashes while the vehicle is in motion. In addition, the Check Engine warning lamp may light up.

The fuel system pressure is too low. The fuel filler cap is not closed correctly or the fuel system is leaking.

- Observe the additional display messages in the multifunction display.
- ► Check that the fuel filler cap is correctly closed.
- If the fuel filler cap is not correctly closed: close the fuel filler cap.
- ▶ If the fuel filler cap is closed: visit a qualified specialist workshop.



The yellow reserve fuel warning lamp lights up while the engine is running.

The fuel level has dropped into the reserve range.

► Refuel at the nearest gas station.





The red coolant warning lamp lights up while the engine is running and the coolant temperature gauge is at the start of the scale.

### Possible causes/consequences and ▶ Solutions

The temperature sensor for the coolant temperature gauge is defective.

The coolant temperature is no longer being monitored. There is a risk of engine damage if the coolant temperature is too high.

- ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions. Do not continue driving under any circumstances.
- ► Secure the vehicle against rolling away (> page 160).
- ► Consult a qualified specialist workshop.





The red coolant warning lamp comes on while the engine is running.

# Possible causes/consequences and ▶ Solutions

The coolant level is too low

If the coolant level is correct, the airflow to the engine radiator may be blocked or the electric engine radiator fan may be malfunctioning.

The coolant is too hot and the engine is no longer being cooled sufficiently.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Pull over and stop the vehicle safely and switch off the engine. paying attention to road and traffic conditions.
- ► Secure the vehicle against rolling away (> page 160).
- ▶ Wait until the engine has cooled down.
- ▶ Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
- ► Check the coolant level and add coolant (> page 302). Observe the warning notes.
- If you need to add coolant more often than usual, have the engine coolant system checked.
- ► At coolant temperatures below 248 °F (120 °C) drive to the nearest qualified specialist workshop.
- ► Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.



The red coolant warning lamp comes on while the engine is running. A warning tone also sounds.

The coolant temperature has exceeded 248 °F (120 °C). The airflow to the engine radiator may be blocked or the coolant level may be too low.



### **↑** WARNING

catch fire.

The engine is not being cooled sufficiently and may be damaged. Do not drive when your engine is overheated. This can cause some fluids which may have leaked into the engine compartment to

Steam from the overheated engine can also cause serious burns which can occur just by opening the hood.

There is a risk of injury.

- ▶ Observe the additional display messages in the multifunction display.
- ▶ Pull over and stop the vehicle safely and switch off the engine, paying attention to road and traffic conditions.
- ► Secure the vehicle against rolling away (> page 160).
- ▶ Wait until the engine has cooled down.



Problem	Possible causes/consequences and ▶ Solutions
	Make sure that the air supply to the engine radiator is not blocked, e.g. by snow, slush or ice.
	► Check the coolant level and add coolant (> page 302). Observe the warning notes.
	► If you need to add coolant more often than usual, have the engine coolant system checked.
	► At coolant temperatures below 248 °F (120 °C) drive to the nearest qualified specialist workshop.
	► Avoid subjecting the engine to heavy loads, e.g. driving in mountainous terrain, and stop-and-go traffic.

### **Driving systems**



**Problem** 

The red distance warning lamp lights up while the vehicle is in motion.



The distance to the vehicle in front is too small for the speed selected.

Possible causes/consequences and ▶ Solutions

There is a risk of an accident.

► Increase the distance.



The red distance warning lamp lights up while the vehicle is in motion. A warning tone also sounds.

# **↑** WARNING

You are approaching a vehicle or a stationary obstacle in your line of travel at too high a speed.

There is a risk of an accident.

- ▶ Be prepared to brake immediately.
- ▶ Pay careful attention to the traffic situation. You may have to brake or take evasive action.

More information about DISTRONIC PLUS ( $\triangleright$  page 171) and PRE-SAFE® Brake ( $\triangleright$  page 69).



#### **Tires**

#### **Problem**



The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) is lit.

# Possible causes/consequences and ▶ Solutions

The tire pressure monitor has detected a loss of pressure in at least one of the tires.

#### **↑** WARNING

With tire pressures which are too low, there is a risk of the following hazards:

- they may burst, especially as the load and vehicle speed
- they may wear excessively and/or unevenly, which may greatly impair tire traction.
- the driving characteristics, as well as steering and braking, may be greatly impaired.

There is a risk of an accident.

- ▶ Stop the vehicle without making any sudden steering or braking maneuvers. Pay attention to the traffic conditions as you do so.
- ▶ Secure the vehicle against rolling away (▷ page 160).
- ▶ Observe the additional display messages in the multifunction display.
- ▶ Check the tires and, if necessary, follow the instructions for a flat tire (⊳ page 312).
- ► Check the tire pressure (> page 336).
- ▶ If necessary, correct the tire pressure.

(i)

USA only:

The yellow tire pressure monitor warning lamp (pressure loss/ malfunction) flashes for approximately one minute and then remains lit.

The tire pressure monitor is faulty.



#### **↑** WARNING

The system is possibly unable to recognize or register low tire pressure.

There is a risk of an accident.

- ▶ Observe the additional display messages in the multifunction display.
- ► Visit a qualified specialist workshop.



Useful information	
Loading guidelines	270
Stowage areas	27
Features	278

# **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (⊳ page 27).

# Loading guidelines

### **↑** WARNING

If objects, luggage or loads are not secured or not secured sufficiently, they could slip, tip over or be flung around and thereby hit vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

Always store objects so that they cannot be flung around. Secure objects, luggage or loads against slipping or tipping before the journey.

# **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. If the tailgate is open when the engine is running, particularly if the vehicle is moving, exhaust fumes could enter the passenger compartment. There is a risk of poisoning. Turn off the engine before opening the tailgate. Never drive with the tailgate open.

The gross vehicle weight (GVW) is the vehicle weight including fuel, vehicle tool kit, spare wheel, installed accessories, vehicle occupants and luggage/cargo.

The gross load limit and the gross vehicle weight rating (GVWR) for your vehicle must never be exceeded. The gross load limit and the GVWR are specified on the vehicle identification plate on the B-pillar of the driver's door (⊳ page 339).

The load must also be distributed so that the weight on each axle never exceeds the gross axle weight rating (GAWR) for the front and rear axles. The specifications for GVWR and GAWR are on the vehicle identification plate on the B-pillar of the driver's door (⊳ page 339).

Further information can be found in the "Loading the vehicle" section (▷ page 339).

The handling characteristics of a laden vehicle are dependent on the distribution of the load within the vehicle. For this reason. you should observe the following notes when transporting a load:

- The cargo compartment is the preferred place to carry objects.
- Position heavy loads as far forwards as possible and as low down in the cargo compartment as possible.
- The load must not protrude above the upper edge of the seat backrests.
- · Always place the load against the rear or front seat backrests. Make sure that the seat backrests are securely locked into place.
- Always place the load behind unoccupied seats if possible.
- Use the cargo tie down rings and the parcel nets to transport loads and luggage.
- Use cargo tie-down rings and fastening materials appropriate for the weight and size of the load.
- Hook in the cargo net (if installed) when loading.
- Secure the load with sufficiently strong and wear-resistant tie-downs, pad sharp edges for protection.



### Stowage areas

### Stowage space

### Important safety notes

#### **↑** WARNING

If objects in the passenger compartment are stowed incorrectly, they can slide or be thrown around and hit vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction.

- Always stow objects so that they cannot be thrown around in such situations.
- Always make sure that objects do not protrude from stowage spaces, parcel nets or stowage nets.
- Close the lockable stowage spaces while driving.
- Stow and secure objects that are heavy, hard, pointy, sharp-edged, fragile or too large in the cargo compartment.

Observe the loading guidelines (⊳ page 270).


# Stowage compartments in the front

#### Glove box




- ▶ To open: pull handle (1) and open glove box
- ▶ To close: fold glove box flap ② upwards until it engages.

The glove box can only be locked and unlocked using the mechanical key.



- ▶ To lock: insert the mechanical key into the lock and turn it 90° clockwise to position 2 .
- ▶ To unlock: insert the mechanical key into the lock and turn it 90° counter-clockwise to position 1.
- 1 The glove box can be ventilated (⊳ page 137).

### Stowage compartment under the armrest



- ▶ To open: press left-hand button ② or righthand button (1). The stowage compartment opens.
- 1 Depending on the vehicle's equipment, a USB connection and an AUX IN connection or a Media Interface are installed in the stowage compartment. A Media Interface is a universal interface for portable audio equipment, e.g. for an iPod® or MP3 player (see the separate Audio or COMAND Operating Instructions).



# Stowage space in the rear

# Stowage compartment in the rear

- Do not sit or lean your bodyweight on the armrests when they are folded out as you could damage them.
- Close the cover of the stowage compartment before folding the rear seat armrest back into the seat backrest.



- ▶ To open: fold down seat armrest ②.
- ▶ Fold cover (1) of the armrest upwards.

# Stowage net

Stowage nets are located in the front-passenger footwell and on the left-hand side of the cargo compartment.

Observe the loading guidelines (▷ page 270) and the safety notes regarding stowage spaces (▷ page 271).

# Cargo compartment enlargement

# Important safety notes



If the rear bench seat/rear seat and seat backrest are not engaged they could fold forwards, e.g. when braking suddenly or in the event of an accident.

 The vehicle occupant would thereby be pushed into the seat belt by the rear bench seat/rear seat or by the seat backrest. The seat belt can no longer offer the intended


- level of protection and could even cause injuries.
- Objects or loads in the trunk/cargo compartment cannot be restrained by the seat backrest.

There is an increased risk of injury.

Before every trip, make sure that the seat backrests and the rear bench seat/rear seat are engaged.

Observe the loading guidelines (> page 270). The left-hand and right-hand rear seat backrests can be folded forwards separately to increase the cargo compartment capacity.


# Folding the rear seat backrest forward



- ► Fully insert the backrest head restraints (> page 99).
- ► Move the driver's or front-passenger seat forward if necessary.
- ▶ Pull left-hand or right-hand release handle ② of the seat backrest forwards. Corresponding seat backrest ① is released.
- ► Fold backrest (1) forwards.
- ► Move the driver's or front-passenger seat back if necessary.



### Folding the rear seat backrest back



- Backrest
- ② Lock verification indicator
- (3) Backrest release handle
- ▶ Move the driver's or front-passenger seat forward if necessary.
- Make sure that the seat belt does not become trapped when folding the rear seat backrest back. Otherwise, it could be damaged.
- ► Fold seat backrest (1) back until it engages. Red lock status indicator (2) is no longer visible.
- ► Adjust the head restraints if necessary (⊳ page 99).
- ► Move the driver's or front-passenger seat back if necessary.

# Securing cargo

# Cargo tie-down rings

#### **↑** WARNING

The Top Tether anchorages cannot secure a load. If you secure a load with the Top Tether anchorages, the Top Tether anchorages could be pulled out during braking, abrupt changes in direction or in the event of an accident. The load could slip, tip over or be flung around and thereby hit vehicle occupants. There is a risk of injury.

Only use the cargo tie down rings when securing a load.

Observe the following notes on securing loads:

- · Observe the loading guidelines (⊳ page 270).
- Secure the load using the cargo tie-down rings.
- · Distribute the load on the cargo tie down rings evenly.
- Do not use elastic straps or nets to secure a load, as these are only intended as an anti-slip protection for light loads.
- Do not route tie-downs across sharp edges or corners.
- Pad sharp edges for protection.

There are four cargo tie down rings in the cargo compartment and two in the rearcompartment footwells 14.



(1) Cargo tie-down rings in the cargo compartment





 Cargo tie down rings in the rearcompartment footwell (Canada only)


# Bag hook

# **↑** WARNING

The bag hooks cannot restrain heavy objects or items of luggage. Objects or items of luggage could be flung around and thereby hit vehicle occupants when braking or abruptly changing directions. There is a risk of injury. Only hang light objects on the bag hooks. Never hang hard, sharp-edged or fragile objects on the bag hooks.

I The bag hook can bear a maximum load of 11lbs (5kg) and should not be used to secure a load.

There is one bag hook on the left side wall in the cargo compartment and there are two hooks on the right and left of the lower D-pillar trim.



# Cargo compartment cover

### Important safety notes

# $\Lambda$

#### **↑** WARNING

On its own, the cargo compartment cover cannot secure or restrain heavy objects, items of luggage and heavy loads. You could be hit by an unsecured load during sudden changes in direction, braking or in the event of an accident. There is an increased risk of injury or even fatal injury.

Always store objects so that they cannot be flung around. Secure objects, luggage or loads against slipping or tipping over, e.g. by using tie downs, even if you are using the cargo compartment cover.

When loading the vehicle, make sure that you do not stack the load in the cargo compartment higher than the lower edge of the side windows. Do not place heavy objects on top of the cargo compartment cover.

The cargo compartment cover is located behind the rear bench seat backrest.

1 You can fold up the solid section of the cargo compartment cover approximately 45° to facilitate loading the cargo compartment.


# Extending/retracting the cargo compartment cover





- ▶ To extend: pull cargo compartment cover (1) back and clip it into the retainers on the left and right.
- ► To retract: unhook cargo compartment cover (1) from the retainers on the left and right and guide it forwards by the grab handle until it is fully retracted.

# Installing/removing the cargo compartment cover



- ► To remove: make sure that cargo compartment cover (1) is rolled up.
- ▶ Press handle ② on the right underside to the left
- ▶ Remove cargo compartment cover (1).
- ► To install: attach cargo compartment cover (1) to the opening on the left-hand side.
- ▶ Press handle ② to the left.
- ▶ Allow cargo compartment cover (1) to engage in the appropriate recess.

# Cargo net

# Important safety notes



### **↑** WARNING

On its own, the cargo net cannot secure or restrain heavy objects, items of luggage and heavy loads. You could be hit by an unsecured load during sudden changes in direction, braking or in the event of an accident. There


is an increased risk of injury or even fatal injury.

Always store objects so that they cannot be flung around. Secure objects, luggage or loads against slipping or tipping over, e.g. by using tie downs, even if you are using the cargo net.

It is important to use a cargo net if you load the vehicle with small objects above the seat backrests. For safety reasons, always use a cargo net when transporting loads.

# Preparing the cargo net

The cargo net can be used in two different positions (behind the B-pillar or the C-pillar).



- The brackets behind B-pillar (1) are required for the cargo compartment enlargement (⊳ page 272).
- The corresponding cargo tie down rings to tighten the net are located in the footwell of the rear bench seat (⊳ page 273).
- The brackets behind C-pillar (2) are required for the cargo compartment behind the rear bench seat.

The corresponding cargo tie down rings to tension the net are located in the cargo compartment (⊳ page 273).

The cargo net is located in the loading tray in the stowage well under the cargo compartment floor (⊳ page 277).



- ► Open both Velcro fasteners and remove the cargo net.
- Unroll and unfold the cargo net. The upper and lower guide rods must engage audibly.


# Attaching the cargo net



Cargo net installed behind the C-pillar

- ► Insert guide rod ② into retainer ① in the direction of the arrow.
- ► Slide guide rod ② forwards into retainer ① in the direction of the arrow.

# Tightening the cargo net



Seat belt reel holder behind the front seats

- ► Insert belt hook ① into cargo tie-down ring ② in the direction of the arrow.
- ▶ Pull tensioning strap ③ by the loose end in the direction of the arrow until the cargo net is tight.
- After driving a short distance, check the tension of the cargo net and retighten it if necessary.

### Releasing the cargo net



Seat belt reel holder behind the front seats

- ▶ Pull belt adjuster ① upwards in the direction of the arrow to reduce the tension on the tensioning strap.
- ► Unhook belt hook ② from cargo tie-down ring ③.

# Detaching and storing the cargo net

- ▶ Detach guide rod ② from bracket ① (▷ page 276).
- Press the red button on the upper and lower guide rods.
- ► Fold the cargo net and roll it up.
- ► Close the two Velcro fasteners on the cargo net holder.

# Coat hooks on the tailgate



(1) Coat hook




# Stowage well under the cargo compartment floor

### **↑** WARNING

If you drive when the cargo compartment floor is open, objects could be flung around, thus striking vehicle occupants. There is a risk of injury, particularly in the event of sudden braking or a sudden change in direction. Always close the cargo compartment floor

before a journey.



- ► To open: open the tailgate.
- ► Holding the ribbing, press handle (1) downwards (2). Handle (1) folds up.
- ► Swing the cargo compartment floor upwards using handle (1) until it rests against the cargo compartment cover.



▶ Release hook (3) from the bracket on the underside of the cargo compartment floor.



- ► Engage hook (3) into rain trough (4).
- 1 Stowage compartments (5) and (6) can be used to stow small, light and flat objects.
- Before you close the tailgate, unhook the hook from the rain trough and fold the trunk floor down
- ► To close: unhook hook ③ from rain trough (4).
- ► Fasten hook (3) to the bracket on the underside of the cargo compartment floor.
- ► Fold the trunk floor down.
- ▶ Press the cargo compartment floor down until it engages.

#### **Roof carrier**

# Important safety notes



# **↑** WARNING

When you load the roof, the center of gravity of the vehicle rises and the driving characteristics change. If you exceed the maximum roof load, the driving characteristics, as well as steering and braking, will be greatly impaired. There is a risk of an accident.

Never exceed the maximum roof load and adjust your driving style.

Mercedes-Benz recommends that you only use roof carriers that have been tested and approved for Mercedes-Benz vehicles.



This helps to prevent damage to the vehicle.

Position the load on the roof rack in such a way that the vehicle will not sustain damage even when it is in motion.

Ensure that, depending on the vehicle's equipment, you can raise the panorama roof with power tilt/sliding panel fully and open the tailgate fully when the roof carrier is installed.

The maximum roof load is 165 lbs(75 kg). An incorrectly secured roof carrier or roof load could become detached from the vehicle. Therefore, always comply with the installation instructions supplied by the manufacturer of the roof carrier.

# Attaching the roof carrier

- ▶ Secure the roof carrier to the roof rails.
- ▶ Observe the manufacturer's installation. instructions.


### **Features**

### Cup holder

# Important safety notes

Only use the cup holders for containers of the right size and which have lids. The drinks could otherwise spill.


# Cup holder in the front-compartment center console



# (1) Cup holder

# Cup holder in the rear seat armrest

- Do not sit on or support your body weight on the rear seat armrest when it is folded down, as you could otherwise damage it.
- Close the cup holder before folding the rear seat armrest up. Otherwise, the cup holder could be damaged.



- ▶ Fold down the rear seat armrest.
- ▶ To open: raise the rear seat armrest cover.
- ▶ Press release catch (1). Cup holder (2) folds out forwards.
- ► Swing the rear seat armrest cover back down, if necessary.
- ► To close: raise the rear seat armrest cover. Swing cup holder (2) back until it engages.

#### Sun visors

#### Overview



# **↑** WARNING

If the mirror cover of the vanity mirror is folded up when the vehicle is in motion, you could be blinded by incident light. There is a risk of an accident.

Always keep the mirror cover folded down while driving.






- Mirror light
- Bracket
- 3 Retaining clip, e.g. for a car park ticket
- 4 Vanity mirror
- (5) Mirror cover

# Vanity mirror in the sun visor

Mirror light ① only functions if the sun visor is clipped into bracket ② and mirror cover ⑤ has been folded up.

#### Glare from the side

- ► Fold down the sun visor.
- ▶ Pull the sun visor out of retainer ②.
- ► Swing the sun visor to the side.




▶ Pull or push the sun visor in the direction of the arrow.

# **Ashtray**

# Front ashtray

I The stowage space under the ashtray is not heat resistant. Before placing lit cigarettes in the ashtray, make sure that the ashtray is properly engaged. Otherwise, the stowage space could be damaged.



- ▶ To open: slide cover (1) forwards.
- ► To remove: open the cover of ashtray (3).
- ► Hold ashtray ③ at the sides and lift it up ② and out.
- ► To re-install: press ashtray ③ into the holder until engages.
- ► Close the lid of ashtray ③.
- ► To close: pull cover ① back.

# Rear-compartment ashtray





- ▶ To open: pull cover ② out by its top edge.
- ▶ To remove the insert: press release button (3) and lift the insert up and out.
- ▶ To install the insert: install insert (1) from above into the holder and press down into the holder until it engages.
- ▶ Press in cigarette lighter ②. Cigarette lighter (2) will pop out automatically when the heating element is red-hot.
- ► To close: pull cover (1) back.

# Cigarette lighter

# **↑** WARNING

You can burn yourself if you touch the hot heating element or the socket of the cigarette lighter.


In addition, flammable materials can ignite if:

- the hot cigarette lighter falls
- a child holds the hot cigarette lighter to objects, for example

There is a risk of fire and injury.

Always hold the cigarette lighter by the knob. Always make sure that the cigarette lighter is out of reach of children. Never leave children. unsupervised in the vehicle.

Your attention must always be focused on the traffic conditions. Only use the cigarette lighter when road and traffic conditions permit.



- ► Turn the SmartKey to position 2 in the ignition lock (⊳ page 141).
- ▶ To open: slide cover (1) forwards.

#### 12 V sockets

#### General notes


The sockets can be used for accessories with a maximum draw of 180 W (15 A).

Accessories include such items as lamps or chargers for mobile phones.

If you use the sockets for long periods when the engine is switched off, the battery may discharge.

- ► Turn the SmartKey to position 1 in the ignition lock (⊳ page 141).
- 1 An emergency cut-out ensures that the on-board voltage does not drop too low. If the on-board voltage is too low, the power to the sockets is automatically cut. This ensures that there is sufficient power to start the engine.

# Socket in the front-compartment center console



- ▶ To open: slide cover (1) forwards.
- ▶ Lift up the cover of socket ②.
- ► To close: pull cover (1) back.




### Socket in the rear-compartment center console



- ▶ Pull cover (2) out by its top edge.
- ▶ Lift up the cover of socket ①.

# Socket in the cargo compartment



▶ Lift up the cover of socket ①.

#### 115 V socket

# Important safety notes

#### **↑** DANGER

When a suitable device is connected, the 115 V power socket will be carrying a high voltage. You could receive an electric shock if the connector cable or the 115 V power socket is pulled out of the trim or is damaged or wet. There is a risk of fatal injury.

- Use only connector cables that are dry and free of damage.
- When the ignition is off, make sure that the 115 V power socket is dry.

- Have the 115 V power socket checked or replaced immediately at a qualified specialized workshop if it is damaged or has been pulled out of the trim.
- Never plug the connector cable into a 115 V power socket that is damaged or has been pulled out of the trim.

#### **↑** DANGER

If you reach into the power socket or plug inappropriate devices into the power socket. you could receive an electric shock. There is a risk of fatal injury.

Only connect appropriate devices to the power socket.

Note that work and repairs on the 115 V power socket should only be carried out by qualified specialist personnel.

#### General notes

115 V power socket (1) provides an alternating voltage of 115 V so that small electronic devices can be connected. These devices, such as games consoles, chargers and laptops, should not consume more than a maximum of 150 watts altogether.

Requirements for operation of these devices:

- the electronic device that you connect has a suitable connector and conforms to standards specific to the country you are
- the plug of the electronic device is plugged into 115 V power socket (1).
- the maximum wattage of the device to be connected must not exceed 150 watts.
- the on-board power supply is within a permissible voltage range.
- the 12 V sockets in the rear compartment and the cargo compartment are operational (⊳ page 280).



# Using the 115 V power socket



- ► To switch on: switch the ignition on.
- ► Open flap ③.
- ► Insert the plug of the electronic device into 115 V power socket ①.
  Indicator lamp ② lights up.
- ► To switch off: remove the connector from 115 V socket (1).

Ensure that you do not pull on the cord.



### Problems with the 115 V power socket

Problem	Possible causes/consequences and ▶ Solutions
The warning lamp on the 115 V power socket is not lit.	The on-board voltage is too low because the battery is too weak.  ▶ Start the engine.  or  ▶ Charge the battery (▷ page 316).  If the indicator lamp still does not light up:  ▶ Visit a qualified specialist workshop.
	The temperature of the DC/AC converter is temporarily too high.  ▶ Remove the electronic device connector from the 115 V socket.  ▶ Let the DC/AC converter cool down.  If the indicator lamp still does not light up after cooling down the converter:  ▶ Visit a qualified specialist workshop.
	You have connected a small electronic device that has a constant nominal power of less than 150 W, but a very high switch-on current. This device will not work. If you connect such a device, the 115 V power socket will not supply it with power.  Connect a suitable device.

#### mbrace

# Important safety notes

You must have a license agreement to activate the mbrace service. Make sure that your system is activated and ready for use. To register, press the **1** MB Info call button. If any of the steps mentioned are not carried out, the system may not be activated.

If you have questions about the activation, contact one of the following telephone hotlines:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

Shortly after successfully registering with the mbrace service (Canada: TELEAID), a user ID and password will be sent to you by post. USA only: you can use this password to log onto the mbrace area under "Owners Online" at http://www.mbusa.com.

The mbrace system is available if:

- it has been activated and is operational
- the corresponding mobile phone network is available for transmitting data to the Customer Center
- a service subscription is available
- the starter battery is sufficiently charged
- ① Determining the location of the vehicle on a map is only possible if:
  - GPS reception is available.
  - the vehicle position can be forwarded to the Customer Assistance Center.



# The mbrace system

To adjust the volume during an mbrace call, proceed as follows:

▶ Press the + or - button on the multifunction steering wheel.

or

► Use the volume controller of the audio system/COMAND.

The mbrace system provides various services, e.g.:

- · automatic and manual emergency call
- · Roadside Assistance call
- MB Info call

USA only: you can find information and a description of all available features under "Owners Online" at http://www.mbusa.com.

### System self-test

After you have switched on the ignition, the system carries out a self-diagnosis.

A malfunction in the system has been detected if one of the following occurs:

- The indicator lamp in the SOS button does not come on during the system self-test.
- The indicator lamp in the Roadside Assistance button does not light up during self-diagnosis of the system.
- The indicator lamp in the **\( \)** i MB Info call button does not light up during self-diagnosis of the system.
- The indicator lamp in one or more of the following buttons continues to light up red after the system self-diagnosis:
  - SOS button
  - the Roadside Assistance call button
  - the 🕓 i MB Info call button
- The mbrace Inoperative or mbrace Service Not Activated message appears in the multifunction display after the system self-diagnosis.

If a malfunction is indicated as outlined above, the system may not operate as expected. In the event of an emergency, help will have to be summoned by other means.

Have the system checked at the nearest authorized Mercedes-Benz Center or contact the following service hotlines:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

### **Emergency call**

### Important safety notes

You must have a license agreement to activate the mbrace service. Make sure that your system is activated and ready for use. To register, press the MB Info call button. If any of the steps mentioned are not carried out, the system may not be activated.

If you have questions about the activation, contact one of the following telephone hotlines:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

#### General notes

An emergency call is dialed automatically if an air bag or Emergency Tensioning Device is triggered.

1 You cannot end an automatically triggered emergency call yourself.

An emergency call can also be initiated manually.

As soon as the emergency call has been initiated, the indicator lamp in the SOS button



flashes. The Connecting Call message appears in the multifunction display.

The audio output is muted.

Once the connection has been made, the Call Connected message appears in the multifunction display.

All important information on the emergency is transmitted, for example:

- · Current location of the vehicle (as determined by the GPS system)
- Vehicle identification number
- Information on the severity of the accident Shortly after the emergency call has been initiated, a voice connection is automatically established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants.
- If the vehicle occupants respond, the Mercedes-Benz Customer Assistance Center attempts to get more information on the emergency.
- If there is no response from the vehicle occupants, an ambulance is immediately sent to the vehicle.

The mbrace system has not been able to initiate an emergency call if no voice connection to the Response Center has been established. This can occur, for example, if the relevant mobile phone network is not available. The indicator lamp in the SOS button flashes continuously.

The Call Failed message appears in the multifunction display and must be confirmed. In this case, seek assistance by other means.


# Making an emergency call

### **↑** WARNING

It can be dangerous to remain in the vehicle, even if you have pressed the SOS button in an emergency if:

- · vou see smoke inside or outside of the vehicle, e.g. if there is a fire after an accident
- the vehicle is on a dangerous section of road
- the vehicle is not visible or cannot easily be seen by other road users, particularly when dark or in poor visibility conditions

There is a risk of an accident and injury. Leave the vehicle immediately in this or similar situations as soon as it is safe to do so. Move to a safe location along with other vehicle occupants. In such situations, secure the vehicle in accordance with national regulations, e.g. with a warning triangle.



- ► To initiate an emergency call manually: press cover (1) briefly to open.
- ▶ Press SOS button ② briefly. The indicator lamp in SOS button (2) flashes until the emergency call is concluded.
- ▶ Wait for a voice connection to the Mercedes-Benz Customer Assistance Center.
- ▶ After the emergency call, close cover (1).
- 1 If the mobile phone network is not available, mbrace is not able to make an emergency call. If you leave the vehicle



immediately after pressing the SOS button, you do not know if mbrace has successfully made the emergency call. In this situation, seek additional assistance by other means.

# **Roadside Assistance button**



▶ Press Roadside Assistance button ①.

This initiates a call to the Mercedes-Benz
Customer Assistance Center. The indicator
lamp in Roadside Assistance button ①
flashes while the call is active. The
Connecting Call message appears on
the multifunction display. The audio output
is muted.

If a connection can be made, the Call Connected message appears in the multifunction display.

If a cellular phone network is available and there is sufficient GPS reception, the mbrace system transmits data to the Mercedes-Benz Customer Assistance Center, for example:

- Current location of the vehicle
- Vehicle identification number
- 1 The display of the audio system or COMAND shows that an mbrace call is active. During the call, you can change to the navigation menu by pressing the NAVI button on COMAND, for example.

Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants.

From the vehicle remote malfunction diagnosis, the Mercedes-Benz Customer

Assistance center can ascertain the nature of the problem (> page 289).

The Mercedes-Benz Customer Assistance Center either sends a qualified Mercedes-Benz technician or arranges for your vehicle to be transported to the nearest authorized Mercedes-Benz Center. You may be charged for services such as repair work and/or towing. Further details are available in your mbrace manual.

- 1 The mbrace system failed to initiate a Roadside Assistance call if:
  - the indicator lamp for Roadside Assistance call button (1) is flashing continuously.
  - no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This may be because the corresponding mobile phone network is not available.

The Call Failed message appears in the multifunction display.

► To end a call: press the button on the multifunction steering wheel.

or

 Press the corresponding button for ending a phone call on the audio system or on COMAND

### MB Info call button





▶ Press MB Info call button ①.

This initiates a call to the Mercedes-Benz
Customer Assistance Center. The indicator
lamp in MB Info call button ① flashes while
the connection is being made. The
Connecting Call message appears on
the multifunction display. The audio system
is muted.

If a connection can be made, the Call Connected message appears in the multifunction display.

If a cellular phone network is available and there is sufficient GPS reception, the mbrace system transmits data to the Mercedes-Benz Customer Assistance Center, for example:

- · Current location of the vehicle
- Vehicle identification number
- 1 The display of the audio system or COMAND shows that an mbrace call is active. During the call, you can change to the navigation menu by pressing the NAVI button on COMAND, for example.

Voice output is not available.

A voice connection is established between the Mercedes-Benz Customer Assistance Center and the vehicle occupants. You can obtain information on how to operate your vehicle's systems, on the location of the nearest authorized Mercedes-Benz Center, and on further products and services offered by Mercedes-Benz USA.

USA only: you can find further information on the mbrace system under "Owners Online" at http://www.mbusa.com.

- 1 The mbrace system failed to initiate an MB Info call if:
  - the indicator lamp in MB Info call button ① is flashing continuously.
  - no voice connection to the Mercedes-Benz Customer Assistance Center was established.

This may be because the corresponding mobile phone network is not available.

- The Call Failed message appears in the multifunction display.
- ► To end a call: press the button on the multifunction steering wheel.

or

 Press the corresponding button for ending a phone call on the audio system or on COMAND.

## Call priority

When service calls are active, e.g. Roadside Assistance or MB Info calls, an emergency call can still be initiated. In this case, an emergency call will take priority and override all other active calls.

The indicator lamp of the respective button flashes until the call is ended. An emergency call can only be terminated by the Mercedes-Benz Customer Assistance Center.

All other calls can be ended by pressing:

- the button on the multifunction steering wheel
- the corresponding button on the audio system or on COMAND for ending a telephone call
- i If an mbrace call is initiated, audio output is muted. The mobile phone is no longer connected to COMAND. However, if you would like to use your mobile phone, do so only when the vehicle is stationary and in a safe location.

# Downloading destinations in COMAND

## **Downloading destinations**

Destination Download gives you access to a data bank with over 15 million Points of Interest (POIs). These can be downloaded on the navigation system in your vehicle. If you know the destination, the address can be downloaded. Alternatively, you can obtain the location of Points of Interest (POIs)/important destinations in the vicinity.



Furthermore, you can download routes with up to 20 way points.

You are prompted to confirm route guidance to the address entered.

The system calculates the route and subsequently starts the route guidance with the address entered.

- 1 If you select No, the address can be stored in the address book.
- The Destination Download function is available if the corresponding mobile phone network is available and data transfer is possible.
- 1 You can only use the Destination Download function if the vehicle is equipped with a navigation system.

#### **Route Assistance**

This service is part of the mbrace PLUS Package and cannot be purchased separately.

1 You can also use the Route Assistance function if your vehicle is not equipped with a navigation system.

Within the framework of this service, you receive a professional and reliable form of navigation support without having to leave your vehicle.

The customer service representative finds a suitable route depending on your vehicle's current position and the desired destination. You will then be guided live through the current route section.

#### Search & Send

"Search & Send" is a destination entry service. You can find further information on "Search & Send" in the separate COMAND operating instructions.

# Vehicle remote opening

You can use the vehicle remote opening if you have unintentionally locked your vehicle and a replacement SmartKey is not available. The

vehicle can be opened by the Mercedes-Benz Customer Assistance Center.

The vehicle can be immediately opened remotely within four days of the ignition being turned off. After this time, the remote opening may be delayed by 15 to 60 minutes. After 30 days the vehicle can no longer be opened remotely.

- ► Contact the following service hotlines:
  - USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
  - Canada: Customer Service at 1-888-923-8367

You will be asked for your password.

 Return to your vehicle at the time agreed upon with the Mercedes-Benz Customer Assistance Center.

USA only: alternatively, the vehicle can be opened via:

- the Internet, under the "Owners Online" section
- the telephone application (e.g. iPhone<sup>®</sup>, Blackberry)

To do this, you will need your identification number and password.

• Vehicle remote opening is only possible if the corresponding mobile phone network is accessible.

# Vehicle remote closing

The remote closing feature can be used when you have forgotten to lock the vehicle and you are no longer nearby. The vehicle can then be locked by the Mercedes-Benz Customer Assistance Center.

The vehicle can be immediately remotely locked within four days of the ignition being turned off. After this time, the remote closing may be delayed by 15 to 60 minutes. After 30 days the vehicle can no longer be closed remotely.

► Contact the following service hotlines:



- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) or 1-866-990-9007
- Canada: Customer Service at 1-888-923-8367

You will be asked for your PIN.

The next time you are inside the vehicle and you switch on the ignition, the Doors Locked Remotely message appears in the multifunction display.

USA only: alternatively, the vehicle can be locked via:

- the Internet, under the "Owners Online" section
- the telephone application (e.g. iPhone®, Blackberry)

To do this, you will need your identification number and password.

1 The vehicle remote closing feature is available when the relevant mobile phone network is available and data connection is possible.

# Stolen vehicle recovery service

If your vehicle has been stolen:

- ► Notify the police.

  The police will issue a numbered incident report.
- ▶ This number will be forwarded to the Mercedes-Benz Customer Assistance Center together with your PIN.

  The Mercedes-Benz Customer Assistance Center then attempts to locate the mbrace system. The Mercedes-Benz Customer Assistance Center contacts you and the local law enforcement agency if the vehicle is located. However, only the law enforcement agency is informed of the location of the vehicle.
- 1 If the anti-theft alarm system is activated for longer than 30 seconds, the Mercedes-Benz Customer Assistance center is automatically informed.

# Vehicle remote malfunction diagnosis

With the vehicle remote malfunction diagnosis (Vehicle Health Check), the Customer Assistance center can provide improved support for problems with your vehicle. During an existing call, vehicle data is transferred to the Customer Assistance center. The customer service representative can use the received data to decide what kind of assistance is required. You are then, for example, guided to the nearest Mercedes-Benz Service center or a recovery vehicle is called.

If vehicle data needs to be transferred during an MB Info call or a Roadside Assistance call, this is initiated by the Customer Assistance center. You will see the Roadside Assistance Connected message in the COMAND display. If the vehicle remote malfunction diagnosis is able to be started, the Request for vehicle diagnosis received. Start vehicle diagnosis? message appears in the display.

- ▶ Press Yes to confirm the message.
- ► If the Vehicle Diagnosis: Please switch on ignition. message appears: turn the key to position 2 in the ignition lock.
- ▶ If the Please follow the instructions received by phone and move your vehicle to a safe position. message appears: follow the instructions of the customer service representative.

The message in the display disappears. If you select Cance1, the vehicle remote malfunction diagnosis is canceled completely.

The vehicle operating state check begins. Meanwhile, the Vehicle diagnosis activated message appears.

When the check is finished, the Sending vehicle diagnosis data...(Voice connection may be interrupted during data transfer.) message



appears. The vehicle data can now be sent to the Customer Assistance center.

Press OK to confirm the message. The voice connection with the Customer Assistance center is terminated.

The Vehicle Diagnosis: Transferring data... appears.

The vehicle data is sent to the Customer Assistance center.

Depending on what the customer service representative agreed with you, the voice connection is re-established after the transfer is complete. If necessary, you will be contacted at a later time by another means, e.g. by E-Mail or telephone.

Further functions of the vehicle remote malfunction diagnosis include, for example:

- transfer of service data to the Customer Assistance center. If a service is overdue, the COMAND display shows a message about various special offers at your workshop.
- monthly status information E-Mail on oil level, air pressure, maintenance, brakes, etc. If applicable, you will receive information on special offers in the E-Mail. USA only: this information can also be called up under "Owners Online" at http:// www.mbusa.com.

Information on the data stored in the vehicle ( $\triangleright$  page 28).

Information on roadside assistance ( $\triangleright$  page 24).

# **Downloading routes**

Downloading routes allows you to transfer and save predefined routes in the navigation system. To do this, an SD memory card must be inserted into the COMAND system. If no SD memory card is inserted, you must insert the card into the card slot on the COMAND system before saving.

A route can be prepared and sent either by a customer service representative or via the mbrace portal on the Internet. Each route can

include up to 20 way points. When a route has been received by the navigation system, the 'Route name' has been saved to memory card. Do you want to start route guidance? message appears on the COMAND display. The route is saved to the SD memory card.

- ➤ To start route guidance: select Yes.

  An overview of the route is shown in the display.
- 1 If you select No, the saved route can be called up later in the navigation menu.
- ► Select Start.

  Route guidance is started.
- ① Downloaded and saved data can be called up again in COMAND.

You can find further information in the separate COMAND operating instructions.

# Speed alert

You can define the upper speed limit, which must not be exceeded by the vehicle. If this selected speed is exceeded by the vehicle, a message will be sent to the Customer Assistance center. The Customer Assistance center then forwards this information to you. You can select the way in which you receive this information beforehand. Possible options include SMS, E-Mail or an automated call.

The data which is sent to the Customer Assistance center contains the following information:

- the location where the speed limit was exceeded
- the time at which the speed limit was exceeded
- the selected speed limit which was exceeded

# Geo fencing

Geo fencing allows you to select areas which the vehicle should not enter or leave. You will be informed if the vehicle crosses the boundaries of the selected areas. You can



select the way in which you receive this information beforehand. Possible options include SMS. F-Mail or an automated call.

The area can be determined as either a circle or a polygon with a maximum of ten corners. You can specify up to ten areas simultaneously. Different settings are possible for each area.

USA only: these settings can be called up under "Owners Online" at http:// www.mbusa.com.

Alternatively, you can trigger an MB Info call and inform the customer service representative that you wish to activate geo fencing.

Currently inactive areas can be activated by

## Triggering the vehicle alarm

With this function, you can trigger the vehicle's panic alarm via SMS. An alarm sounds and the exterior lighting flashes. Depending on the setting, the panic alarm lasts five or ten seconds. Afterwards, the alarm switches off.

# Garage door opener

# Important safety notes



#### ♠ WARNING

When you operate or program the garage door with the integrated garage door opener, persons in the range of movement of the garage door can become trapped or struck by the garage door. There is a risk of injury.

When using the integrated garage door opener, always make sure that nobody is within the range of movement of the garage door.



### **↑** WARNING

Combustion engines emit poisonous exhaust gases such as carbon monoxide. Inhaling these exhaust gases leads to poisoning. There is a risk of fatal injury. Therefore never leave the engine running in enclosed spaces without sufficient ventilation

The HomeLink® garage door opener integrated in the rear-view mirror allows you to operate up to three different door and gate systems.

Only operate garage doors using the integrated garage door opener if:

- they are equipped with a safety stop and reverse feature, and
- they conform to the current U.S. safety standards.

When programming a garage door opener, park vehicle outside the garage.

1 Certain garage door drives are incompatible with the integrated garage door opener. If you have difficulty programming the integrated garage door opener, contact an authorized Mercedes-Benz Center.

Alternatively, you can call the following telephone assistance services:

- USA: Mercedes-Benz Customer Assistance Center at 1-800-FOR-MFRCedes
- . Canada: Customer Service at 1-800-387-0100
- HomeLink® hotline 1-800-355-3515 (free of charge)

More information on HomeLink® and/or compatible products is also available online at http://www.homelink.com.


1 Notes on the declaration of conformity (⊳ page 26).

# **Programming**

# Programming buttons

Observe the "Important safety notes" (⊳ page 291).





Integrated garage door opener in the rear-view mirror

Garage door remote control (5) is not part of the integrated garage door opener.

- ► The first time before programming, clear the integrated garage door opener memory (> page 294).
- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Press and hold one of buttons ② to ④ on the integrated garage door opener. After a short time, indicator lamp ① lights up yellow.
- i Indicator lamp i lights up yellow as soon as button 2, 3 or 4 is programmed for the first time. If the selected button has already been programmed, indicator lamp i will only light up yellow after ten seconds have elapsed.
- ▶ Release button ②, ③ or ④. Indicator lamp ① flashes yellow.
- ▶ Point garage door remote control ⑤ towards buttons ② to ④ on the rear-view mirror at a distance of 2 to 8 inches (5 to 20 cm).
- 1 The required distance between remote control (5) and the integrated garage door opener depends on the garage door drive system. Several attempts might be necessary. You should test every position for at least 25 seconds before trying another position.

- ▶ Press and hold button ⑥ on remote control ⑤ until indicator lamp ① lights up green. If indicator lamp ① lights up green or flashes, then programming has been successful.
- ▶ Release button ⑥ on remote control ⑤ for the garage door drive system.
- ▶ If indicator lamp ① lights up red: repeat the programming procedure for the corresponding button on the rear-view mirror. When doing so, vary the distance between remote control ⑤ and the rear-view mirror.
- If the indicator lamp flashes green after successful programming, the garage door system is using a rolling code. After programming, you must synchronize the garage door opener integrated in the rearview mirror with the receiver of the garage door system.

# Synchronizing the rolling code

Observe the "Important safety notes" (> page 291).

Your vehicle must be within reach of the garage door or exterior gate drive. Make sure that neither your vehicle nor any persons/ objects are present within the sweep of the door or gate.

- ► Turn the SmartKey to position 2 in the ignition lock.
- Press the program button of the door or gate drive (see the door or gate drive operating instructions, e.g. under "programming of additional remote controls").
- ① Usually, you now have 30seconds to initiate the next step.
- Press previously programmed button ②,
   ③ or ④ of the integrated garage door opener until the door closes.
   The rolling code synchronization is then complete.



# Notes on programming the remote control

Canadian radio frequency laws require a "break" (or interruption) of the transmission signals after broadcasting for a few seconds. Therefore, these signals may not last long enough for the integrated garage door opener. The signal is not recognized during programming. Comparable with Canadian law, some U.S. garage door openers also feature a "break".

#### Proceed as follows:

- if you live in Canada
- if you have difficulties programming the garage door opener (regardless of where you live) when using the programming steps
- ► Press and hold one of buttons ② to ④ on the integrated garage door opener. After a short time, indicator lamp ① lights up yellow.
- ► Release the button.
  Indicator lamp ① flashes yellow.
- ▶ Press button ⑥ of garage door remote control ⑤ for two seconds, then release it for two seconds.
- ▶ Press button ⑥ again for two seconds.
- ► Repeat this sequence on button ⑥ of remote control ⑤ until indicator lamp ① lights up green.
  If indicator lamp ① turns red, repeat the process.
- ► Continue with the other programming steps (see above).

# Problems when programming

If you are experiencing problems programming the integrated garage door opener on the rear-view mirror, take note of the following instructions:

 Check the transmitter frequency of garage door drive remote control (5). This can usually be found on the back of the remote control.

- The integrated garage door opener is compatible with devices that have units which operate in the frequency range of 280to 433MHz.
- Replace the batteries in garage door remote control ⑤. This increases the likelihood that garage door remote control ⑤ will transmit a strong and precise signal to the integrated garage door opener in the rear-view mirror.
- When programming, hold remote control
   at varying distances and angles from the button that you are programming. Try various angles at a distance between 2and 12 inches (5to 30 cm) or at the same angle but at varying distances.
- If another remote control for the same garage door drive is available, repeat the same programming steps with this remote control. Before performing these steps, make sure that new batteries have been installed in garage door drive remote control (5).
- Note that some remote controls only transmit for a limited amount of time (the indicator lamp on the remote control goes out). Press button (a) on remote control
   (5) again before transmission ends.
- Align the antenna cable of the garage door opener unit. This can improve signal reception/transmission.

# Opening/closing the garage door

After it has been programmed, the integrated garage door opener performs the function of the garage door system remote control. Please also read the operating instructions for the garage door system.

- ► Turn the SmartKey to position 2 in the ignition lock.
- ▶ Press button ②, ③ or ④ which you have programmed to operate the garage door. Garage door system with a fixed code: indicator lamp ① lights up green.



Garage door system with a rolling code: indicator lamp (1) flashes green.

1 The transmitter will transmit a signal as long as the button is pressed. The transmission is halted after a maximum of ten seconds and indicator lamp 1 lights up yellow. Press button 2, 3 or 4 again if necessary.

# Clearing the memory

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► Press buttons ② and ④.

  The indicator lamp lights up yellow.
- ▶ Press and hold buttons ② and ④ until the indicator lamp turns green.
- 1 Make sure that you clear the memory of the integrated garage door opener before selling the vehicle.

# Compass

# Calling up the compass


The compass displays in which compass direction the vehicle is currently traveling: N, NE, E, SE, S, SW, W or NW.




To receive a correct display in rear-view mirror ①, the compass must be calibrated and the magnetic field zone set.

# Setting the compass

Determine your position using the following zone maps.



North America zone map



South America zone map



▶ Push a round pen into opening (3)(⊳ page 294) for approximately three seconds.

The zone currently selected appears in compass display (2)(⊳ page 294).

▶ To select the zone: push a round pen into opening (3)(⊳ page 294) until the desired zone is selected.

If, after a few seconds, the display in compass display (2)(⊳ page 294) changes direction, the zone has been selected.

## Calibrating the compass


► Make sure that there is sufficient space for you to drive in a circle without impeding traffic.

In order to calibrate the compass correctly, do the following:

- calibrate the compass in the open and not in the vicinity of steel structures or highvoltage transmission lines.
- switch off electrical consumers such as the climate control, windshield wipers or rear window defroster.
- close all doors and the tailgate.
- ► Switch on the ignition.
- ▶ Push a round pen into opening (3)(⊳ page 294) for approximately six seconds, until symbol C is shown in compass display (2)(⊳ page 294).
- ▶ Drive your vehicle in a full circle at approximately 3 mph (5 km/h) to 6 mph (10 km/h).

When the calibration has successfully been completed, the current direction is shown in compass display (2)(⊳ page 294).

The operating and road safety of the vehicle is jeopardized. There is a risk of an accident. Make sure that all objects in the vehicle are stowed correctly, and that they cannot enter the driver's footwell. Install the floormats securely and as specified in order to ensure sufficient clearance for the pedals. Do not use loose floormats.



- Slide the seat backwards.
- ▶ To install: place the floormat in the footwell.
- ▶ Press studs (1) onto retainers (2).
- ► To remove: pull the floormat off retainers (2).
- ▶ Remove the floormat.

# Floormat on the driver's side



# **↑** WARNING

Objects in the driver's footwell can restrict the pedal travel or obstruct a depressed pedal.





Useful information	298
ASSYST PLUS	298
Engine compartment	299
Care	303

# **Useful information**

- This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops: (▷ page 27).

### **ASSYST PLUS**

# Service messages

The ASSYST PLUS service interval display informs you of the next service due date. Information on the type of service and service intervals (see the separate Maintenance Booklet).

You can obtain further information from an authorized Mercedes-Benz Center or at http://www.mbusa.com (USA only).

1 The ASSYST PLUS service interval display does not show any information on the engine oil level. Observe the notes on the engine oil level (▷ page 300).

The multifunction display shows a service message for several seconds, e.g.:

- Next Service A in .. days
- Service A Due
- Service A Exceeded by .. days

Depending on the operating conditions of the vehicle, the remaining time or distance until the next service due date is displayed.

The letter A or B, possibly in connection with a number or another letter, shows the type of service. A stands for a minor service and B for a major service.

You can obtain further information from an authorized Mercedes-Benz Center.

The ASSYST PLUS service interval display does not take into account any periods of time during which the battery is disconnected.

Maintaining the time-dependent service schedule:

Note down the service due date displayed in the multifunction display before disconnecting the battery.

or

► After reconnecting the battery, subtract the battery disconnection periods from the service date shown on the display.

# Hiding a service message

► Press the or OK button on the steering wheel.

## Displaying service messages

- ► Switch on the ignition.
- ► Press the or button on the steering wheel to select the Serv. menu.
- ▶ Press the or button to select the ASSYST PLUS submenu and confirm with OK .

The service due date appears in the multifunction display.

#### Information about Service

# Resetting the ASSYST PLUS service interval display

If the ASSYST PLUS service interval display has been inadvertently reset, this setting can be corrected at a qualified specialist workshop.

Have service work carried out as described in the Maintenance Booklet. This may otherwise lead to increased wear and damage to the major assemblies or the vehicle.



A qualified specialist workshop, e.g. an authorized Mercedes-Benz Center, will reset the ASSYST PLUS service interval display after the service work has been carried out You can also obtain further information on maintenance work, for example.

# Special service requirements

The specified maintenance interval takes only the normal operation of the vehicle into account. Under arduous operating conditions or increased load on the vehicle. maintenance work must be carried out more frequently, for example:

- regular city driving with frequent intermediate stops
- if the vehicle is primarily used to travel short distances
- use in mountainous terrain or on poor road surfaces
- if the engine is often left idling for long periods

Under these or similar conditions, have, for example, the air filter, engine oil and oil filter replaced or changed more frequently. Under arduous operating conditions, the tires must be checked more often. Further information can be obtained at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

# **Driving abroad**

An extensive Mercedes-Benz Service network is also available in other countries. You can obtain further information from any authorized Mercedes-Benz Center.

# **Engine compartment**

#### Hood

### Important safety notes



#### **↑** WARNING

If the hood is unlatched, it may open up when the vehicle is in motion and block your view. There is a risk of an accident.

Never unlatch the hood while driving.



#### **↑** WARNING

When opening and closing the hood, it may suddenly fall into the closed position. There is a risk of injury to persons within range of movement of the hood.

Open and close the hood only when no one is within its range of movement.



### **↑** WARNING

Certain components in the engine compartment, such as the engine, radiator and parts of the exhaust system, can become very hot. Working in the engine compartment poses a risk of injury.

Where possible, let the engine cool down and touch only the components described in the following.



### **↑** WARNING

Opening the hood when the engine is overheated or when there is a fire in the engine compartment could expose you to hot gases or other service products. There is a risk of injury.

Let an overheated engine cool down before opening the hood. If there is a fire in the engine compartment, keep the hood closed and contact the fire department.



### **↑** WARNING

The engine compartment contains moving components. Certain components, such as the radiator fan, may continue to run or start again suddenly when the ignition is off. There is a risk of injury.



If you need to do any work inside the engine compartment,

- switch off the ignition
- never reach into the area where there is a risk of danger from moving components, such as the fan rotation area
- keep clothing away from moving parts

# **↑** WARNING

The ignition system and the fuel injection system work under high voltage. If you touch components which are under voltage, you could get an electric shock. There is a risk of injury.

Never touch components of the ignition system or fuel injection system when the ignition is switched on.

# Opening the hood

# **↑** WARNING

The windshield wipers and wiper linkage could be set in motion.

When the hood is open, you or others could be injured by the wiper linkage.

Make sure that the windshield wipers are switched off. Remove the SmartKey or make sure that no ignition position has been selected with KEYLESS-GO. All indicator lamps must be off in the instrument panel.

- Make sure that the windshield wipers are not folded away from the windshield. You could otherwise damage the windshield wipers or the hood.
- Make sure that the windshield wipers are turned off.



▶ Pull release lever ① on the hood. The hood is released.



► Reach into the gap, pull hood catch handle (2) up and lift the hood.

If you lift the hood by approximately 15 inches (40 cm), the hood is opened and held open automatically by the gas-filled strut.

# Closing the hood

- ► Lower the hood and let it fall from a height of approximately 8 in (20 cm).
- Check that the hood has engaged properly. If the hood can be raised slightly, it is not properly engaged. Open it again and close it with a little more force.

# **Engine oil**

#### General notes on the oil level

Depending on the driving style, the vehicle consumes up to 0.9 US qt (0.8 liters) of oil over a distance of 600 miles (1,000 km). The




oil consumption may be higher than this when the vehicle is new or if you frequently drive at high engine speeds.

Depending on the engine, the oil dipstick may be in a different location.


When checking the oil level:

- park the vehicle on a level surface.
- the engine should be switched off for approximately five minutes if the engine is at normal operating temperature.
- if the engine is not at normal operating temperature, e.g. if the engine was only started briefly: wait about 30 minutes before carrying out the measurement.

# Checking the oil level using the oil dipstick



Example: vehicles with a gasoline engine



Example: vehicles with a diesel engine

▶ Park the vehicle on a level surface.

- To check the oil level with the engine at operating temperature, switch the engine off and wait for approximately five minutes.
- ▶ Pull oil dipstick (1) out of the dipstick guide tube.
- ▶ Wipe off oil dipstick ①.
- ▶ Slowly slide oil dipstick (1) into the guide tube to the stop, and take it out again. If the level is between MIN mark (3) and MAX mark (2), the oil level is correct.
- ▶ If the oil level has dropped to MIN mark (3) or below, add 1.1 US gt (1.0 liter) of engine oil.

# Adding engine oil

### **↑** WARNING

If engine oil comes into contact with hot components in the engine compartment, it may ignite. There is a risk of fire and injury. Make sure that engine oil is not spilled next to the filler neck. Let the engine cool down and thoroughly clean the engine oil off the components before starting the engine.

#### **Environmental note**

When adding oil, take care not to spill any. If oil enters the soil or waterways, it is harmful to the environment.

I Only use engine oils and oil filters that have been approved for vehicles with a service system. You can obtain a list of the engine oils and oil filters tested and approved in accordance with the Mercedes-Benz Specifications for Service Products at any Mercedes-Benz Service center.



Damage to the engine or exhaust system is caused by the following:

- using engine oils and oil filters that have not been specifically approved for the service system
- replacing engine oil and oil filters after the interval for replacement specified by the service system has been exceeded
- · using engine oil additives.
- Do not add too much oil. If the oil level is above the "max" mark on the dipstick, too much oil has been added. This can lead to damage to the engine or the catalytic converter. Have excess oil siphoned off.



Example: engine oil cap

- ► Turn cap (1) counter-clockwise and remove it.
- ► Add engine oil. If the oil level is at or below the MIN mark on the oil dipstick, add 1.1 US gt (1.0 liter) of engine oil.
- ▶ Replace cap (1) on the filler neck and turn clockwise. Ensure that the cap locks into place securely.
- ▶ Check the oil level again with the oil dipstick (⊳ page 301).

Further information on engine oil (⊳ page 369).

# Checking and adding other service products

# Checking coolant level

### **↑** WARNING

The engine cooling system is pressurized. particularly when the engine is warm. When opening the cap, you could be scalded by hot coolant spraying out. There is a risk of injury. Let the engine cool down before opening the cap. Wear eve and hand protection when opening the cap. Open the cap slowly half a turn to allow pressure to escape.

Only check the coolant level when the vehicle is on a level surface and the engine has cooled down.

- ► Turn the SmartKey to position 2 in the ignition lock (⊳ page 141). On vehicles with KEYLESS-GO, press the Start/Stop button twice (⊳ page 141).
- ► Check the coolant temperature display in the instrument cluster. The coolant temperature must be below 158 °F (70 °C).



- ▶ Slowly turn cap (1) half a turn counterclockwise and allow excess pressure to escape.
- ► Turn cap (1) further counter-clockwise and remove it.
  - If the coolant is at the level of marker bar (3) in the filler neck when cold, there is enough coolant in coolant expansion tank (2).



If the coolant level is approximately 0.6 in (1.5 cm) above marker bar ③ in the fuel filler neck when warm, there is enough coolant in expansion tank ②.

- ► If necessary, add coolant that has been tested and approved by Mercedes-Benz.
- Replace cap ① and turn it clockwise as far as it will go.

For further information on coolant, see (> page 371).

# Adding washer fluid to the windshield washer system/headlamp cleaning system

# **↑** WARNING

Windshield washer concentrate is highly flammable. If it comes into contact with hot engine components or the exhaust system it could ignite. There is a risk of fire and injury. Make sure that no windshield washer concentrate is spilled next to the filler neck.



- ▶ To open: pull cap ① upwards by the tab.
- ► Add the premixed washer fluid.
- ➤ To close: press cap ① onto the filler neck until it engages.

The washer fluid reservoir is used for both the windshield washer system and the headlamp cleaning system.

The recommended minimum amount when topping up is 1 liter. If the water level drops below this, a message appears in the multifunction display prompting you to refill the washer fluid (▷ page 255).

Further information on windshield washer fluid/antifreeze (▷ page 372).

#### Care

#### **General notes**

- I For cleaning your vehicle, do not use any of the following:
  - · dry, rough or hard cloths
  - abrasive cleaning agents
  - solvents
  - cleaning agents containing solvents
     Do not scrub.

Do not touch the surfaces or protective films with hard objects, e.g. a ring or ice scraper. You could otherwise scratch or damage the surfaces and protective film.

# ⊕ Environmental note

Dispose of empty packaging and cleaning cloths in an environmentally responsible manner.

Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

Regular care of your vehicle is a condition for retaining the quality in the long term.

Use care products and cleaning agents recommended and approved by Mercedes-Benz.



#### **Exterior care**

#### Automatic car wash

# **↑** WARNING

Braking efficiency is reduced after washing the vehicle. There is a risk of an accident. After the vehicle has been washed, brake carefully while paying attention to the traffic conditions until full braking power is restored.

- II If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:
  - · when towing the vehicle
  - · in the car wash
- Never clean your vehicle in a Touchless Automatic Car Wash as these use special cleaning agents. These cleaning agents can damage the paintwork or plastic parts.
- Make sure that the automatic transmission is in position N when washing your vehicle in a tow-through car wash. The vehicle could be damaged if the transmission is in another position.
- Make sure that:
  - the side windows and the sliding sunroof are fully closed.
  - the ventilation/heating is switched off (the OFF button has been pressed).
  - the windshield wiper switch is in position 0.

Otherwise, the vehicle might be damaged.

You can wash the vehicle in an automatic car wash from the very start.

If the vehicle is very dirty, pre-wash it before cleaning it in an automatic car wash.

After using an automatic car wash, wipe off wax from the windshield and the wiper blades. This will prevent smears and reduce wiping noises caused by residue on the windshield.

# Washing by hand

In some countries, washing by hand is only allowed at specially equipped washing bays. Observe the legal requirements in all countries concerned.

- ▶ Do not use hot water and do not wash the vehicle in direct sunlight.
- ▶ Use a soft sponge to clean.
- ▶ Use a mild cleaning agent, such as a car shampoo approved by Mercedes-Benz.
- Thoroughly hose down the vehicle with a gentle jet of water.
- ▶ Do not point the water jet directly towards the air inlet.
- ▶ Use plenty of water and rinse out the sponge frequently.
- ► Rinse the vehicle with clean water and dry thoroughly with a chamois.
- ▶ Do not let the cleaning agent dry on the paintwork.

When using the vehicle in winter, remove all traces of road salt deposits carefully and as soon as possible.

#### Power washers



# / WARNING

The water jet from a circular jet nozzle (dirt blasters) can cause invisible exterior damage to the tires or chassis components. Components damaged in this way may fail unexpectedly. There is a risk of an accident. Do not use power washers with circular jet nozzles to clean the vehicle. Have damaged tires or chassis components replaced immediately.

Always maintain a distance of at least 11.8 in (30 cm) between the vehicle and the power washer nozzle. Information about the correct distance is available from the equipment manufacturer.



Move the power washer nozzle around when cleaning your vehicle.

Do not aim directly at any of the following:

- tires
- door gaps, roof gaps, joints, etc.
- · electrical components
- battery
- connectors
- lights
- · seals
- trim
- ventilation slots

Damaged seals or electrical components can lead to leaks or failures.

# Cleaning the wheels

- Do not use acidic wheel cleaning products to remove brake dust. This could damage wheel bolts and brake components.
- Do not park the vehicle for an extended period straight after cleaning it, particularly after having cleaned the wheels with wheel cleaner. Wheel cleaners could cause increased corrosion of the brake discs and brake pads/linings. For this reason, you should drive for a few minutes after cleaning. Braking heats the brake discs and the brake pads/linings, thus drying them. The vehicle can then be parked.

# Cleaning the paintwork

Scratches, corrosive deposits, areas affected by corrosion and damage caused by inadequate care cannot always be completely repaired. In such cases, visit a qualified specialist workshop.

- ► Remove dirt immediately, where possible, while avoiding rubbing too hard.
- ► Soak insect remains with insect remover and rinse off the treated areas afterwards.
- ► Soak bird droppings with water and rinse off the treated areas afterwards.

- Remove coolant, brake fluid, tree resin, oils, fuels and greases by rubbing gently with a cloth soaked in petroleum ether or lighter fluid.
- ▶ Use tar remover to remove tar stains.
- ▶ Use silicone remover to remove wax.
- Do not affix:
  - stickers
  - films
  - magnetic plates or similar items
     to painted surfaces. You could otherwise
     damage the paintwork.

If water no longer forms "beads" on the paint surface, use the paint care products recommended and approved by Mercedes-Benz. This is the case approximately every three to five months, depending on the climate conditions and the care product used. If the dirt has penetrated the paint surface or if the paintwork has become dull, then the paintwork should be cleaned. Use the cleaning product Paint Cleaner, which has been approved by Mercedes-Benz.

Do not use these care products in the sun or on the hood while the hood is hot.

► Use a suitable touch-up stick, e.g. MB Touch-Up Stick, to repair slight damage to the paintwork quickly and provisionally.

#### Matte finish care

If your vehicle has a clear matte finish, observe the following instructions in order to avoid damage to the paintwork due to incorrect care.

These notes also apply to light alloy wheels with a clear matte finish.

Never polish the vehicle or the light alloy wheels. Polishing causes the finish to shine.



- I The following may cause the paint to become shiny and thus reduce the matte effect:
  - Vigorous rubbing with unsuitable materials.
  - Frequent use of car washes.
  - · Washing the vehicle in direct sunlight.
- Never use paint cleaner, buffing or polishing products, or gloss preserver, e.g. wax. These products are only suitable for high-gloss surfaces. Their use on vehicles with matte finish leads to considerable surface damage (shiny, spotted areas). Always have paintwork repairs carried out at a qualified specialist workshop.
- Do not use wash programs with a hot wax treatment under any circumstances.
- 1 The vehicle should preferably be washed by hand using a soft sponge, car shampoo and plenty of water.
- Use only insect remover and car shampoo from the range of recommended and approved Mercedes-Benz care products.

# Cleaning the windows

#### **↑** WARNING

You could become trapped by the windshield wipers if they start moving while cleaning the windshield or wiper blades. There is a risk of injury.

Always switch off the windshield wipers and the ignition before cleaning the windshield or wiper blades.

- I Only fold the windshield wipers away from the windshield when vertical. Otherwise, you will damage the hood.
- Do not use dry cloths, abrasive products, solvents or cleaning agents containing solvents to clean the inside of the windows. Do not touch the insides of the windows with hard objects, e.g. an ice scraper or

- ring. There is otherwise a risk of damaging the windows.
- III Clean the water drainage channels of the windshield and the rear window at regular intervals. Deposits such as leaves, petals and pollen may under certain circumstances prevent water from draining away. This can lead to corrosion damage and damage to electronic components.
- ▶ Clean the inside and outside of the windows with a damp cloth and a cleaning product that is recommended and approved by Mercedes-Benz.

# Cleaning wiper blades



# **↑** WARNING

You could become trapped by the windshield wipers if they start moving while cleaning the windshield or wiper blades. There is a risk of injury.

Always switch off the windshield wipers and the ignition before cleaning the windshield or wiper blades.

- I Only fold the windshield wipers away from the windshield when vertical. Otherwise, you will damage the hood.
- Do not pull the wiper blade. Otherwise, the wiper blade could be damaged.
- Do not clean wiper blades too often and do not rub them too hard. Otherwise, the graphite coating could be damaged. This could cause wiper noise.
- Hold the wiper arm securely when folding back. The windshield could be damaged if the wiper arm smacks against it suddenly.
- ► Fold the windshield wiper arms away from the windshield.
- Carefully clean the wiper blades with a damp cloth.
- ► Fold the windshield wiper arms back again before switching on the ignition.



# Cleaning the exterior lighting


- Only use cleaning agents or cleaning cloths which are suitable for plastic light lenses. Unsuitable cleaning agents or cleaning cloths could scratch or damage the plastic light lenses.
- ► Clean the plastic lenses of the exterior lighting using a wet sponge and a mild cleaning agent, e.g. Mercedes-Benz car shampoo. Or clean the exterior lighting with cleaning cloths.

## Cleaning the mirror turn signals

- Only use cleaning agents or cleaning cloths that are suitable for plastic lenses. Unsuitable cleaning agents or cleaning cloths could scratch or damage the plastic lenses of the mirror turn signals.
- ► Clean the plastic lenses of the mirror turn signals using a wet sponge and a mild cleaning agent, e.g. Mercedes-Benz car shampoo. Cleaning cloths may be used as well.

# Cleaning the sensors

If you clean the sensors with a power washer, make sure that you keep a distance of at least 11.8 in (30 cm) between the vehicle and the power washer nozzle. Information about the correct distance is available from the equipment manufacturer.





► Clean sensors ① of the driving systems with water, car shampoo and a soft cloth.

# Cleaning the rear view camera

Do not clean the camera lens and the area around the rear view camera with a power washer.



► Use clear water and a soft cloth to clean camera lens (1).

# Cleaning the exhaust pipes

Do not clean the exhaust pipe with acidbased cleaning agents such as sanitary cleansers or wheel cleaners.

Impurities combined with the effects of road grit and corrosive environmental factors may cause flash rust to form on the surface. You can restore the original shine of the exhaust



tail pipe by cleaning it regularly, especially in winter and after washing.

Clean the exhaust tail pipes with a chrome care product tested and approved by Mercedes-Benz.

## Cleaning the trailer tow hitch

### **Environmental note**

Dispose of rags soaked in oil and grease in an environmentally responsible manner.

Observe the note on care provided by the trailer manufacturer.

The ball coupling must be cleaned if it becomes dirty or corroded.

- ▶ Remove rust on the ball of the ball coupling, e.g. with a wire brush.
- ▶ Remove dirt with a clean, lint-free cloth or a brush.
- ► After cleaning, lightly grease the ball of the ball coupling again.
- ▶ Check that the vehicle's trailer tow hitch is working properly.
- 1 You can also have the maintenance work on the ball coupling and the trailer tow hitch carried out by a qualified specialist workshop.

#### Interior care

# Cleaning the display

- For cleaning, do not use any of the following:
  - · alcohol-based thinner or gasoline
  - · abrasive cleaning agents
  - · commercially-available household cleaning agents

These may damage the display surface. Do not put pressure on the display surface when cleaning. This could lead to irreparable damage to the display.

- ▶ Before cleaning the display, make sure that it is switched off and has cooled down.
- Clean the display surface using a commercially available microfiber cloth and TFT/LCD display cleaner.
- ▶ Dry the display surface using a dry microfiber cloth.

# Cleaning the plastic trim

# **↑** WARNING

Care products and cleaning agents containing solvents cause surfaces in the cockpit to become porous. As a result, plastic parts may come loose in the event of air bag deployment. There is a risk of injury.

Do not use any care products and cleaning agents to clean the cockpit.

- Do not affix the following to plastic surfaces:
  - stickers
  - films
  - scented oil bottles or similar items You can otherwise damage the plastic.
- Do not allow cosmetics, insect repellent or sunscreen to come into contact with the plastic trim. This maintains the high-quality look of the surfaces.
- ▶ Wipe the plastic trim with a damp, lint-free cloth, e.g. a microfiber cloth.
- ► **Heavy soiling:** use care and cleaning products recommended and approved by Mercedes-Benz.

The surface may change color temporarily. Wait until the surface is dry again.

# Cleaning the steering wheel and gear or selector lever

► Thoroughly wipe with a damp cloth or use leather care agents that have been recommended and approved by Mercedes-Benz.



# Cleaning genuine wood and trim elements

- Do not use solvent-based cleaning agents such as tar remover, wheel cleaners. polishes or waxes. There is otherwise a risk of damaging the surface.
- Do not use chrome polish on trim pieces. The trim pieces have a chrome look but are mostly made of anodized aluminum and can lose their shine if chrome polish is used. Use a damp, lint-free cloth instead when cleaning the trim pieces.

If the chrome-plated trim pieces are very dirty, you can use a chrome polish. If you are unsure as to whether the trim pieces are chrome-plated or not, consult an authorized Mercedes-Benz Center

- ▶ Wipe the wooden trim and trim pieces with a damp, lint-free cloth, e.g. a microfiber cloth.
- ▶ Heavy soiling: use car care and cleaning products recommended and approved by Mercedes-Benz

# Cleaning the seat covers

#### General notes

- Do not use microfiber cloths to clean genuine leather, artificial leather or Alcantara® covers. If used often, these can damage the cover.
- 1 Note that regular care is essential to ensure that the appearance and comfort of the covers is retained over time.

#### Genuine leather seat covers

Leather is a natural product.

It exhibits natural surface characteristics, for example:

- · Differences in the texture
- Signs of stretching and marking
- Slight nuances of color

These are characteristics of leather and not material defects.

- I To retain the natural appearance of the leather, observe the following cleaning instructions:
  - Clean genuine leather covers carefully with a damp cloth and then wipe the covers down with a dry cloth.
  - · Make sure that the leather does not become soaked. It may otherwise become rough and cracked.
  - Only use leather care agents that have been tested and approved by Mercedes-Benz. You can obtain these from a qualified specialist workshop.

#### Seat covers of other materials

- Observe the following when cleaning:
  - · Clean artificial leather covers with a cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid).
  - Clean cloth covers with a microfiber. cloth moistened with a solution containing 1% detergent (e.g. dish washing liquid). Rub carefully and always wipe entire seat sections to avoid leaving visible lines. Leave the seat to dry afterwards. Cleaning results depend on the type of dirt and how long it has been there.
  - Clean Alcantara® covers with a damp cloth. Make sure that you wipe entire seat sections to avoid leaving visible lines.

# Cleaning the seat belts

#### **↑** WARNING

Seat belts can become severely weakened if bleached or dyed. This could cause the seat belts to tear or fail, for instance, in the event of an accident. This poses an increased risk of injury or fatal injury.

Never bleach or dye the seat belts.

Do not clean the seat belts using chemical cleaning agents. Do not dry the seat belts



by heating at temperatures above 176 °F (80 °C) or in direct sunlight.

► Use clean, lukewarm water and soap solution.

# Cleaning the headliner and carpets

- ► Headliner: if it is very dirty, use a soft brush or a cleaning agent recommended and approved by Mercedes-Benz.
- ► Carpets: use the carpet and textile cleaning agents recommended and approved by Mercedes-Benz.



Useful information	312
Where will I find?	312
Flat tire	312
Battery (vehicle)	314
Jump-starting	318
Towing and tow-starting	320
Fuses	323

# **Useful information**

- i This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- ① Read the information on qualified specialist workshops: (▷ page 27).

### Where will I find ...?

#### First-aid kit

▶ Open the tailgate.




- ► Remove first-aid kit ① from the stowage net.
- 1 Check the expiration date on the first-aid kit at least once a year. Replace the contents if necessary, and replace missing items.


### Vehicle tool kit

The vehicle tool kit can be found in the stowage well under the cargo compartment floor.

➤ To remove the cargo compartment stowage tray/cover: lift up the cargo compartment floor (▷ page 277).



- ▶ Remove stowage tray ① in the direction of the arrow.
- ▶ Remove cover ② in the direction of the arrow.



- 3 Lug wrench
- (4) Towing eye
- (5) Jack
- (6) Fuse allocation chart
- (7) Wheel bolts
- ® One pair of gloves
- Ratchet wrench
- (10) Tire inflation compressor
- (11) Valve extractor
- (12) Folding wheel chock

#### Flat tire

# Preparing the vehicle

Your vehicle may be equipped with:

 MOExtended tires (tires with run-flat properties) (⊳ page 313)



Vehicle preparation is not necessary on vehicles with MOExtended tires.

- •
- · Collapsible spare wheel
- an emergency spare wheel (only for certain countries) (▷ page 359)

Information on changing/mounting a wheel ( $\triangleright$  page 352).

- Stop the vehicle on solid, non-slippery and level ground, as far away as possible from traffic.
- ► Switch on the hazard warning lamps.
- ► Secure the vehicle against rolling away (> page 160).
- ▶ If possible, bring the front wheels into the straight-ahead position.
- ► Switch off the engine.
- ► Vehicles without KEYLESS-GO: remove the SmartKey from the ignition lock.
- ► Vehicles with KEYLESS-GO: open the driver's door.

The on-board electronics have status **0**, which is the same as the SmartKey having been removed.

- ► Vehicles with KEYLESS-GO: remove the Start/Stop button from the ignition lock (> page 141).
- All occupants must get out of the vehicle. Make sure that they are not endangered as they do so.
- Make sure that no one is near the danger area while a wheel is being changed. Anyone who is not directly assisting in the wheel change should, for example, stand behind the barrier.
- ► Get out of the vehicle. Pay attention to traffic conditions when doing so.
- ► Close the driver's door.

# MOExtended tires (tires with run-flat properties)

#### **General notes**

With MOExtended tires (tires with run flat characteristics), you can continue to drive your vehicle even if there is a total loss of pressure in one or more tires. The affected tire must not show any clearly visible damage.

You can recognize MOExtended tires by the MOExtended marking which appears on the sidewall of the tire. You will find this marking next to the tire size designation, the load-bearing capacity and the speed index (> page 346).

MOExtended tires may only be used in conjunction with an active tire pressure loss warning system or with an active tire pressure monitor.

# If the pressure loss warning message appears in the multifunction display:

- Observe the instructions in the display messages (⊳ page 252).
- Check the tire for damage.
- If driving on, observe the following notes.

The maximum driving distance is approximately 50 miles (80 km) when the vehicle is partially laden and approximately 18 miles (30 km) when the vehicle is fully laden.

In addition to the vehicle load, the driving distance possible depends upon:

- Speed
- · Road condition
- Outside temperature

The driving distance possible in run-flat mode may be reduced by extreme driving conditions/maneuvers, or it can be increased through a moderate style of driving.

The maximum permissible distance which can be driven in run-flat mode is counted from the moment the tire pressure loss warning appears in the multifunction display.



You must not exceed a maximum speed of 50 mph (80 km/h).

- 1 When replacing one or all tires, make sure that you use only tires:
  - of the size specified for the vehicle and
  - marked "MOExtended"

If a tire has gone flat and cannot be replaced with a MOExtended tire. a standard tire may be used as a temporary measure. Make sure that you use the proper size and type (summer or winter tire).

## Important safety notes

# **↑** WARNING

When driving in emergency mode, the driving characteristics deteriorate, e.g. when cornering, accelerating quickly and when braking. There is a risk of an accident.

Do not exceed the stated maximum speed. Avoid abrupt steering and driving maneuvers, and driving over obstacles (curbs, potholes, off-road). This applies in particular to a laden

Stop driving in emergency mode if:

- · you hear banging noises.
- the vehicle starts to shake.
- you see smoke and smell rubber.
- ESP® is intervening constantly.
- there are tears in the sidewalls of the tire.

After driving in emergency mode, have the wheel rims checked at a qualified specialist workshop with regard to their further use. The defective tire must be replaced in every case.

# **Battery (vehicle)**

### Important safety notes

Special tools and expert knowledge are required when working on the battery, e.g. removal and installing. You should therefore have all work involving the battery carried out at a qualified specialist workshop.

### **↑** WARNING

Work carried out incorrectly on the battery can, for example, lead to a short circuit and damage your vehicle's electronic system. This can disrupt driving safety systems such as ABS (anti-lock braking system) or ESP® (Electronic Stability Program).

- If ABS malfunctions, the wheels can lock during braking. This limits the steerability of the vehicle when braking and the braking distance may increase. There is a risk of accident.
- If ESP® malfunctions, the vehicle will not be stabilized if it starts to skid or a wheel starts to spin. There is a risk of accident.

You should therefore have all work involving the battery carried out at a qualified specialist workshop.



#### **↑** WARNING

Electrostatic build-up can lead to the creation of sparks, which could ignite the highly explosive gases of a battery. There is a risk of an explosion.

Before handling the battery, touch the vehicle body to remove any existing electrostatic build-up.

The highly flammable gas mixture forms when charging the battery as well as when jumpstarting.

Always make sure that neither you nor the battery is electrostatically charged. A buildup of electrostatic charge can be caused, for example:

- by wearing clothing made from synthetic fibers
- due to friction between clothing and seats
- if you push or pull the battery across the carpet or other synthetic materials
- if you wipe the battery with a cloth



### **↑** WARNING

Battery acid is caustic. There is a risk of injury. Avoid contact with the skin, eyes or clothing. Do not inhale any battery gases. Do not lean over the battery. Keep children away from batteries. Wash battery acid immediately with water and seek medical attention.

### **↑** WARNING

During the charging process, a battery produces hydrogen gas. If a short circuit occurs or sparks are created, the hydrogen gas can ignite. There is a risk of an explosion.

- Make sure that the positive terminal of a connected battery does not come into contact with vehicle parts.
- Never place metal objects or tools on a battery.
- It is important that you observe the described order of the battery terminals when connecting and disconnecting a battery.
- When jump-starting, make sure that the battery poles with identical polarity are connected.
- It is particularly important to observe the described order when connecting and disconnecting the jumper cables.
- Never connect or disconnect the battery terminals while the engine is running.

# **↑** WARNING

During charging and jump-starting, explosive gases can escape from the battery. There is a risk of an explosion.

Particularly avoid fire, open flames, creating sparks and smoking. Ensure there is sufficient ventilation while charging and jump-starting. Do not lean over a battery.



#### **Environmental note**



Batteries contain dangerous substances. It is against the law to dispose of them with the household rubbish. They must be collected separately and recycled to protect the environment



Dispose of batteries in an environmentally friendly manner. Take discharged batteries to a qualified specialist workshop or a special collection point for used batteries.

- Have the battery checked regularly at a qualified specialist workshop.
  - Observe the service intervals in the Maintenance Booklet or contact a qualified specialist workshop for more information.
- You should have all work involving the battery carried out at a qualified specialist workshop. In the exceptional case that it is necessary for you to disconnect the battery yourself, make sure that:
  - · you switch off the engine and remove the SmartKev. On vehicles with KEYLESS-GO, ensure that the ignition is switched off. Check that all the indicator lamps in the instrument cluster are off. Otherwise. electronic components, such as the alternator, may be damaged.
  - you first remove the negative terminal clamp and then the positive terminal clamp. Never swap the terminal clamps. Otherwise, the vehicle's electronic system may be damaged.
  - the transmission is locked in position P after disconnecting the battery. The vehicle is secured against rolling away. You can then no longer move the vehicle.

The battery and the cover of the positive terminal clamp must be installed securely during operation.

Comply with safety precautions and take protective measures when handling batteries.





Risk of explosion.



Fire, open flames and smoking are prohibited when handling the battery. Avoid creating sparks.



Battery acid is caustic. Avoid contact with skin, eyes or clothing. Wear suitable protective clothing. especially gloves, apron and faceguard.

Rinse any acid spills immediately with clear water. Contact a physician if necessary. Wear eye protection.





Keep children away.



Observe this Operator's Manual.

In order for the battery to achieve the maximum possible service life, it must always be sufficiently charged.

Have the battery condition of charge checked more frequently if you use the vehicle mainly for short trips or if you leave it standing idle for a lengthy period. Consult a qualified specialist workshop if you wish to leave your vehicle parked for a long period of time.

Like other batteries, the vehicle battery may discharge over time if you do not use the vehicle. In this case, have the battery disconnected at a qualified specialist workshop. You can also charge the battery with a charger recommended by Mercedes-Benz. Contact a qualified specialist workshop for further information.

1 Remove the SmartKey if you park the vehicle and do not require any electrical

- consumers. The vehicle will then use very little energy, thus conserving battery power.
- 1 If the power supply has been interrupted, e.g. if you reconnect the battery, you will have to:
  - set the clock; see the separate operating instructions.
    - On vehicles with COMAND and a navigation system, the clock is set automatically.
  - reset the panorama roof with power tilt/ sliding panel. (⊳ page 92)
  - reset the function for folding the exterior mirrors in/out automatically by folding the mirrors out once ( $\triangleright$  page 104)<sup>15</sup>.

# Charging the battery



# **↑** WARNING

During charging and jump-starting, explosive gases can escape from the battery. There is a risk of an explosion.

Particularly avoid fire, open flames, creating sparks and smoking. Ensure there is sufficient ventilation while charging and jump-starting. Do not lean over a battery.



# **↑** WARNING

Battery acid is caustic. There is a risk of injury. Avoid contact with the skin, eyes or clothing. Do not inhale any battery gases. Do not lean over the battery. Keep children away from batteries. Wash battery acid immediately with water and seek medical attention.



### **↑** WARNING

A discharged battery can freeze at temperatures below freezing point. When jump-starting the vehicle or charging the battery, gases can escape from the battery. There is a risk of an explosion.

<sup>15</sup> This function is only available in vehicles for Canada.



Allow the frozen battery to thaw out before charging it or jump-starting.

- Only charge the installed battery with a battery charger which has been tested and approved by Mercedes-Benz. These battery chargers allow the battery to be charged while still installed in the vehicle.
- Only use battery chargers with a maximum charging voltage of 14.8 V.
- Only charge the battery using the jumpstarting connection point.

The jump-starting connection point is in the engine compartment (▷ page 318).

- ▶ Open the hood (> page 300).
- ► Connect the battery charger to the positive terminal and ground point in the same order as when connecting the donor battery in the jump-starting procedure (> page 318).
- ► Read the battery charger's operating instructions before charging the battery.



# **Jump-starting**

For the jump-starting procedure, use only the jump-starting connection point, consisting of a positive terminal and an earth point, in the engine compartment.

# **MARNING**

Battery acid is caustic. There is a risk of injury.

Avoid contact with the skin, eyes or clothing. Do not inhale any battery gases. Do not lean over the battery. Keep children away from batteries. Wash battery acid immediately with water and seek medical attention.

# **↑** WARNING

During charging and jump-starting, explosive gases can escape from the battery. There is a risk of an explosion.

Particularly avoid fire, open flames, creating sparks and smoking. Ensure there is sufficient ventilation while charging and jump-starting. Do not lean over a battery.

### **↑** WARNING

During the charging process, a battery produces hydrogen gas. If a short circuit occurs or sparks are created, the hydrogen gas can ignite. There is a risk of an explosion.

- Make sure that the positive terminal of a connected battery does not come into contact with vehicle parts.
- Never place metal objects or tools on a battery.
- It is important that you observe the described order of the battery terminals when connecting and disconnecting a battery.
- When jump-starting, make sure that the battery poles with identical polarity are connected.
- It is particularly important to observe the described order when connecting and disconnecting the jumper cables.
- Never connect or disconnect the battery terminals while the engine is running.

# **↑** WARNING

Non-combusted fuel can collect in the exhaust system and ignite. There is a risk of fire. Avoid repeated and lengthy starting attempts.

Vehicles with a gasoline engine: avoid repeated and lengthy starting attempts. Otherwise, the catalytic converter could be damaged by non-combusted fuel.

Do not start the vehicle using a rapid charging device. If your vehicle's battery is discharged, the engine can be jump-started from another vehicle or from a second battery using jumper cables. Observe the following points:


- The battery is not accessible in all vehicles. If the other vehicle's battery is not accessible, jump-start the vehicle using a second battery or a jump-starting device.
- Vehicles with a gasoline engine: only jump-start the vehicle when the engine and exhaust system are cold.
- Do not start the engine if the battery is frozen. Let the battery thaw first.
- Jump-starting may only be performed from batteries with a nominal voltage of 12 V.



- Only use jumper cables which have a sufficient cross-section and insulated terminal clamps.
- If the battery is fully discharged, leave the battery that is being used to jump-start connected for a few minutes before attempting to start. This charges the battery slightly.
- Make sure that the two vehicles do not touch.

#### Make sure that:

- the jumper cables are not damaged.
- bare parts of the terminal clamp do not come into contact with other metal parts while the jumper cables are connected to the battery.
- the jumper cables cannot come into contact with parts such as the V-belt pulley or the fan. These parts move when the engine is started and while it is running.
- ► Apply the parking brake firmly.
- ▶ Shift the automatic transmission to position **P**.
- ▶ Switch off all electrical consumers (e.g. radio, blower, etc.).
- ▶ Open the hood (▷ page 300).



Position number (6) identifies the charged battery of the other vehicle or an equivalent jump-starting device.

- ► Slide cover ① of positive terminal ② in the direction of the arrow.
- ► Connect positive terminal ② on your vehicle to positive terminal ③ of donor battery ⑥ using the jumper cable, beginning with your own battery.
- $\blacktriangleright$  Start the engine of the donor vehicle and run it at idling speed.
- ► Connect negative terminal ④ of donor battery ⑥ to ground point ⑤ of your vehicle using the jumper cable, connecting the jumper cable to battery of other vehicle ⑥ first.
- ► Start the engine.
- ▶ Before disconnecting the jumper cables, let the engine run for several minutes.



- ▶ First, remove the jumper cables from earth point (5) and negative terminal (4), then from positive clamp (2) and positive terminal (3). Begin each time at the contacts on your own vehicle first.
- ▶ Close cover (1) of positive terminal (2) after removing the jumper cables.
- ▶ Have the battery checked at a qualified specialist workshop.
- 1 Jump-starting is not considered to be a normal operating condition.
- 1 Jumper cables and further information regarding jump-starting can be obtained at any qualified specialist workshop.

# Towing and tow-starting

# Important safety notes

### **↑** WARNING

You can no longer steer the vehicle if the steering wheel lock has been engaged. There is a risk of an accident.

Always switch off the ignition when towing the vehicle with a tow cable or a tow bar.

# **↑** WARNING

If the weight of the vehicle to be towed or towstarted is greater than the permissible gross weight of your vehicle:

- the towing eye could detach itself
- the vehicle/trailer combination could rollover.

There is a risk of an accident.

When towing or tow-starting another vehicle, its weight should not be greater than the permissible gross weight of your vehicle.

Information on your vehicle's gross vehicle weight rating can be found on the vehicle identification plate (⊳ page 364).

- If DISTRONIC PLUS or the HOLD function is activated, the vehicle brakes automatically in certain situations. To prevent damage to the vehicle, deactivate DISTRONIC PLUS and the HOLD function in the following or other similar situations:
  - · when towing the vehicle
  - in the car wash

- The vehicle can be towed a maximum of 30 miles (50km). The towing speed of 30 mph (50 km/h) must not be exceeded. If the vehicle has to be towed more than 30 miles (50km), the entire vehicle must be raised and transported.
- Only secure the tow rope or tow bar at the towing eyes. Otherwise, the vehicle could be damaged.
- Do not use the towing eyes for recovery purposes as this could damage the vehicle. If in doubt, recover the vehicle with a crane.
- When towing, pull away slowly and smoothly. If the tractive power is too high, the vehicles could be damaged.
- Do not tow with sling-type equipment. This could damage the vehicle.
- On vehicles with KEYLESS-GO, use the SmartKey instead of the Start/Stop button. Turn the SmartKey to position 2 in the ignition lock and shift the automatic transmission to N. Then, turn the SmartKey back to **0** and leave it in the ignition lock.

It is better to have the vehicle transported than to have it towed.

The automatic transmission must be in position N when the vehicle is being towed.



The battery must be connected and charged. Otherwise, you:

- cannot turn the SmartKey to position 2 in the ignition lock
- cannot shift the automatic transmission to position N
- Deactivate the automatic locking feature (⊳ page 80). You could otherwise be locked out when pushing or towing the vehicle.

# Installing/removing the towing eve

# Installing the towing eye

# **↑** WARNING

The exhaust tail pipe may be very hot. There is a risk of burns when removing the rear cover.

Do not touch the exhaust pipe. Take particular care when removing the rear cover.

Vehicles with a trailer tow hitch: if you intend to use the vehicle for towing, install the ball coupling and connect the towbar to it (⊳ page 210).

▶ Remove the towing eye from the vehicle tool kit (⊳ page 312).

The brackets for the screw-in towing eyes are located in the bumpers. They are under the covers at the front and at the rear on vehicles without a trailer coupling. On vehicles with a trailer coupling, the bracket is at the front under the cover.





Vehicles without the AMG Sports package



Vehicles with the AMG Sports package

- ▶ Press the mark on cover (1) inwards in the direction of the arrow
  - Rear bumpers on vehicles with the AMG Sports package: lift up cover (1) from the bumper by inserting a round, blunt object into the recess.
- ► Take cover (1) off the opening.
- ► Screw in and tighten the towing eye clockwise to the stop.

# Removing the towing eye

- ▶ Unscrew and remove the towing eye.
- ► Attach cover (1) to the bumper and press until it engages.
- ▶ Place the towing eye in the vehicle tool kit.



# Towing the vehicle with the rear axle raised

# Only possible for vehicles without 4MATIC.

When towing your vehicle with the rear axle raised, it is important that you observe the safety instructions (▷ page 320).

- The ignition must be switched off if you are towing the vehicle with the rear axle raised. Intervention by ESP® could otherwise damage the brake system.
- ➤ Switch on the hazard warning lamps (> page 113).
- ► Turn the SmartKey to position **0** in the ignition lock and remove the SmartKey from the ignition lock.
- ► When leaving the vehicle, take the SmartKey or the KEYLESS-GO key with you.

# Towing a vehicle with both axles on the ground

It is important that you observe the safety instructions when towing away your vehicle (> page 320).

- ► Switch on the hazard warning lamps (> page 113).
- i) When towing with the hazard warning lamps switched on, use the combination switch as usual to signal a change of direction. In this case, only the indicator lamps for the direction of travel flash. After resetting the combination switch, the hazard warning lamp starts flashing again.
- ► Turn the SmartKey to position 2 in the ignition lock.
- When the vehicle is stationary, depress the brake pedal and keep it depressed.
- ► Shift the automatic transmission to position N.
- ► Release the brake pedal.
- ► Release the parking brake.

# Transporting the vehicle

The towing eyes or trailer tow hitch can be used to pull the vehicle onto a trailer or transporter if you wish to transport it.

- ► Turn the SmartKey to position 2 in the ignition lock.
- ► Shift the automatic transmission to position **N**.

#### As soon as the vehicle has been loaded:

- ► Prevent the vehicle from rolling away by applying the parking brake.
- ► Shift the automatic transmission to position **P**.
- ► Turn the SmartKey to position **0** in the ignition lock and remove the SmartKey from the ignition lock.
- Secure the vehicle.
- Only lash the vehicle down by the wheels or wheel rims, not by parts of the vehicle such as axle or steering components.
  Otherwise, the vehicle could be damaged.

#### Notes on 4MATIC vehicles

Vehicles with 4MATIC must not be towed with either the front or the rear axle raised, as doing so will damage the transmission.

If the vehicle has transmission damage or damage to the front or rear axle, have it transported on a transporter or trailer.

# In the event of damage to the electrical system

If the battery is defective, the automatic transmission will be locked in position **P**. To shift the automatic transmission to position **N**, you must provide power to the vehicle's electrical system in the same way as when jump-starting (▷ page 318).

Have the vehicle transported on a transporter or trailer.



### Recovering a vehicle that has become stuck

Pull away smoothly, slowly, and in a straight line when pulling out a vehicle that has become stuck. Excessive tractive power could damage the vehicles.

If the drive wheels get trapped on loose or muddy ground, recover the vehicle with the utmost care, especially so if the vehicle is laden.

Never attempt to recover a vehicle with a trailer attached.

Pull out the vehicle backwards, if possible. using the tracks it made when it became stuck.

## Tow-starting (emergency engine starting)

I Vehicles with automatic transmission must not be started by tow-starting. This could otherwise damage the transmission.

You can find information on "Jump-starting" at (⊳ page 318).

#### **Fuses**

## Important safety notes



#### **↑** WARNING

If you manipulate or bridge a faulty fuse or if you replace it with a fuse with a higher amperage, the electric cables could be overloaded. This could result in a fire. There is a risk of an accident and injury.

Always replace faulty fuses with the specified new fuses having the correct amperage.

I Only use fuses that have been approved for Mercedes-Benz vehicles and which have the correct fuse rating for the system concerned. Otherwise, components or systems could be damaged.

The fuses in your vehicle serve to close down faulty circuits. If a fuse blows, all the

components on the circuit and their functions stop operating.

Blown fuses must be replaced with fuses of the same rating, which you can recognize by the color and value. The fuse ratings are listed in the fuse allocation chart.

If a newly inserted fuse also blows, have the cause traced and rectified at a qualified specialist workshop, e.g. an authorized Mercedes-Benz Center.

## Before changing a fuse

- Secure the vehicle against rolling away (⊳ page 160).
- Switch off all electrical consumers.
- ► Turn the SmartKey to position **0** in the ignition lock and remove it (⊳ page 141).

or

▶ On vehicles with KEYLESS-GO, make sure the ignition is switched off (> page 141).

All indicator lamps in the instrument cluster must be off.

The fuses are located in various fuse boxes:

- Fuse box on the driver's side of the dashboard
- Fuse box in the engine compartment on the left-hand side of the vehicle, when viewed in the direction of travel
- Fuse box in the stowage well under the cargo compartment floor on the right-hand side of the vehicle, when viewed in the direction of travel

The fuse allocation chart is located in the vehicle tool kit in the stowage compartment under the cargo compartment floor (⊳ page 312).

## Dashboard fuse box

Do not use a pointed object such as a screwdriver to open the cover in the dashboard. You could damage the dashboard or the cover.



- Make sure that no moisture can enter the fuse box when the cover is open.
- When closing the cover, make sure that it is lying correctly on the fuse box. Moisture seeping in or dirt could otherwise impair the operation of the fuses.




- ► **To open:** pull out cover ① slightly at the bottom in the direction of arrow ③.
- ▶ Pull cover ① outwards in the direction of arrow ② and remove it.
- ► **To close:** clip in cover ① on the front of the dashboard.
- ► Fold cover ① inwards until it engages.

## Fuse box in the engine compartment

## **↑** WARNING

When the hood is open and the windshield wipers are set in motion, you can be injured by the wiper linkage. There is a risk of injury. Always switch off the windshield wipers and the ignition before opening the hood.


- Make sure that no moisture can enter the fuse box when the cover is open.
- When closing the cover, make sure that it is lying correctly on the fuse box. Moisture seeping in or dirt could otherwise impair the operation of the fuses.
- ► Make sure that the windshield wipers are turned off.
- ▶ Open the hood.



- ► Use a dry cloth to remove any moisture from the fuse box.
- ▶ To open: take lines ② from the guides.
- ▶ Open clamps ①.
- ▶ Remove the fuse box cover forwards.
- ► To close: check whether the rubber seal is lying correctly in the cover.
- ► Insert the cover at the rear of the fuse box into the retainer.
- ► Fold down cover and close clamps ①.
- ► Secure lines ② in the guides.
- ▶ Close the hood

## Fuse box in the cargo compartment

- Make sure that no moisture can enter the fuse box when the cover is open.
- When closing the cover, make sure that it is lying correctly on the fuse box. Moisture seeping in or dirt could otherwise impair the operation of the fuses.
- ▶ Open the tailgate.





- ► **To open:** lift up cargo compartment floor ②(▷ page 277).
- ► Remove stowage compartment ①.
- ▶ Open cover ③ of fuse box downwards.





328
328
328
330
33
339
343
344
345
349
352
353
357
359



## **Useful information**

- 1 This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safetyrelated systems and functions.
- Read the information on qualified specialist workshops: (⊳ page 27).

### Important safety notes

#### **↑** WARNING

If wheels and tires of the wrong size are used, the wheel brakes or suspension components may be damaged. There is a risk of an accident.

Always replace wheels and tires with those that fulfill the specifications of the original part.

When replacing wheels, make sure to use the correct:

- · designation
- model

When replacing tires, make sure to use the correct:

- designation
- manufacturer
- model

## **↑** WARNING

A flat tire severely impairs the driving, steering and braking characteristics of the vehicle. There is a risk of accident.

Tires without run-flat characteristics:

- · do not drive with a flat tire.
- immediately replace the flat tire with your emergency spare wheel or spare wheel, or consult a qualified specialist workshop.

Tires with run-flat characteristics:

 pay attention to the information and warning notices on MOExtended tires (tires with run-flat characteristics).

Accessories that are not approved for your vehicle by Mercedes-Benz or are not being used correctly can impair the operating safetv.

Before purchasing and using non-approved accessories, visit a qualified specialist workshop and inquire about:

- suitability
- · legal stipulations
- · factory recommendations

Information on the dimensions and types of wheels and tires for your vehicle can be found in the "Wheel/tire combinations" section (⊳ page 357).

Information on air pressure for the tires on your vehicle can be found:

- on the vehicle's Tire and Loading Information placard on the B-pillar
- on the tire pressure label on the fuel filler flap
- in the "Tire pressure" section

Modification work on the brake system and wheels is not permitted. The use of wheel spacers or brake dust shields is not permitted. This invalidates the general operating permit for the vehicle.

 Further information on wheels and tires can be obtained at any qualified specialist workshop.

#### **Operation**

#### Information on driving

- If the vehicle is heavily loaded, check the tire pressures and correct them if necessary.
- When parking your vehicle, make sure that the tires do not get deformed by the curb



or other obstacles. If it is necessary to drive over curbs, speed humps or similar elevations, try to do so slowly and at an obtuse angle. Otherwise, the tires, particularly the sidewalls, may be damaged.

## Regular checking of wheels and tires

### **↑** WARNING

Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle. There is a risk of accident.

Check the tires regularly for signs of damage and replace any damaged tires immediately.

- · Regularly check the wheels and tires of your vehicle for damage (e.g. cuts, punctures, tears, bulges on tires and deformation or cracks or severe corrosion on wheels) at least once a month, as well as after driving off-road or on rough roads. Damaged wheels can cause a loss of tire pressure.
- Regularly check the tire tread depth and the condition of the tread across the whole width of the tire (▷ page 329). If necessary, turn the front wheels to full lock in order to inspect the inner side of the tire surface.
- All wheels must have a valve cap to protect the valve against dirt and moisture. Do not mount anything onto the valve other than the standard valve cap or other valve caps approved by Mercedes-Benz for your vehicle. Do not use any other valve caps or systems, e.g. tire pressure monitoring systems.
- Regularly check the pressure of all the tires including the emergency spare wheel or the spare wheel, particularly prior to long trips, and correct the pressure as necessary (⊳ page 331).

#### Tire tread

#### **↑** WARNING

Insufficient tire tread will reduce tire traction. The tire is no longer able to dissipate water. This means that on wet road surfaces, the risk of hydroplaning increases, in particular where speed is not adapted to suit the driving conditions. There is a risk of accident.

If the tire pressure is too high or too low, tires may exhibit different levels of wear at different locations on the tire tread. Thus, you should regularly check the tread depth and the condition of the tread across the entire width of all tires

Minimum tire tread depth for:

• Summer tires: ½ in (3 mm)

• M+S tires: 1/6 in (4 mm)

For safety reasons, replace the tires before the legally prescribed limit for the minimum tire tread depth is reached.

Treadwear indicators (TWI) are required by law. Six indicators are positioned on the tire tread. They are visible once the tread depth is approximately 1/16 in (1.6 mm). If this is the case, the tire is so worn that it must be replaced.



Bar indicator (1) for tread wear is integrated into the tire tread.



## Selecting, mounting and replacing tires

- Only mount tires and wheels of the same type and make.
  - Exception: it is permissible to install a different type or make in the event of a flat tire. Observe the "MOExtended tires (tires with run-flat characteristics)" section (⊳ page 313)
- Only mount tires of the correct size onto the wheels.
- After mounting new tires, break them in at moderate speeds for the first 60 miles (100 km), as they only reach their full performance after this distance.
- Do not drive with tires which have too little tread depth, as this significantly reduces the traction on wet roads (hydroplaning).
- Replace the tires after six years at the latest, regardless of wear. This also applies to the spare wheel/emergency spare wheel.

The service life of tires depends on the following factors amongst other things:

- · Driving style
- Tire pressure
- Distance covered

## MOExtended tires (tires with run-flat properties)

MOExtended tires (tires with run-flat properties) allow you to continue driving your vehicle even if one or more tires are entirely deflated.

MOExtended tires may only be used in conjunction with an active tire pressure loss warning system or with an active tire pressure monitor and on wheels specifically tested by Mercedes-Benz.

Notes on driving with MOExtended tires in the event of a flat tire can be found in the "Breakdown assistance" section (⊳ page 313).

#### Winter operation

#### Points to remember

Have your vehicle winterproofed at a qualified specialist workshop at the onset of winter.

Observe the notes in the "Changing a wheel" section (⊳ page 352).

#### **Driving with summer tires**

At temperatures below 45 °F (+7 °C), summer tires lose elasticity and therefore traction and braking power. Change the tires on your vehicle to M+S tires. Using summer tires at very cold temperatures could cause cracks to form, thereby damaging the tires permanently. Mercedes-Benz cannot accept responsibility for this type of damage.

#### M+S tires

#### **↑** WARNING

M+S tires with a tire tread depth of less than 1/6 in (4 mm) are not suitable for use in winter and do not provide sufficient traction. There is a risk of an accident.

M+S tires with a tread depth of less than 1/6 in (4 mm) must be replaced immediately.

At temperatures below 45 °F (+7 °C), use winter tires or all-season tires. Both types of tire are identified by the M+S marking.

Only winter tires bearing the A snowflake symbol in addition to the M+S marking provide the best possible grip in wintry road conditions. Only these tires will allow driving safety systems such as ABS and ESP® to function optimally in winter. These tires have been developed specifically for driving in

Use M+S tires of the same make and tread on all wheels to maintain safe handling characteristics.



Always observe the maximum permissible speed specified for the M+S tires you have mounted.

When you have mounted M+S tires:

- ► Check the tire pressures (> page 335).
- ▶ Vehicles for Canada: restart the tire pressure loss warning system (⊳ page 335).
- ▶ Vehicles for USA: restart the tire pressure monitor (⊳ page 336).

For more information on driving with the emergency spare wheel, see (⊳ page 359).

#### **Snow chains**



#### **↑** WARNING

If snow chains are installed to the front wheels, they may drag against the vehicle body or chassis components. This could cause damage to the vehicle or the tires. There is a risk of an accident.

To avoid hazardous situations:

- never install snow chains to the front
- · always install snow chains in pairs to the rear wheels.
- I On some tire sizes there is not enough space for snow chains. To avoid damage to the vehicle or tires, observe the "Wheel and tire combinations" section under "Tires and wheels".
- Vehicles with steel wheels: if you wish to mount snow chains on steel wheels. make sure that you remove the respective wheels' hubcaps first. The hubcaps may otherwise be damaged.

For safety reasons, Mercedes-Benz recommends that you only use snow chains that have been specially approved for your vehicle by Mercedes-Benz, or are of a corresponding standard of quality.

If you intend to mount snow chains, please bear the following points in mind:

- snow chains may not be mounted on all wheel/tire combinations. Permissible wheel-tire combinations (⊳ page 357).
- only use snow chains when driving on roads completely covered by snow. Remove the snow chains as soon as possible when you come to a road that is not snow-covered.
- · local regulations may restrict the use of snow chains. Observe the appropriate regulations if you wish to mount snow chains.
- do not exceed the maximum permissible speed of 30 mph (50 km/h).
- 1 You may wish to deactivate ESP®(⊳ page 66) when pulling away with snow chains installed. You can thereby allow the wheels to spin in a controlled manner, achieving an increased driving force (cutting action).

For more information on driving with the emergency spare wheel, see (⊳ page 359).

#### Tire pressure

## Tire pressure specifications

Operation with a trailer: the applicable value for the rear tires is the maximum tire pressure value stated in the table inside the fuel filler flap.



#### **↑** WARNING

Underinflated or overinflated tires pose the following risks:

- the tires may burst, especially as the load and vehicle speed increase.
- the tires may wear excessively and/or unevenly, which may greatly impair tire traction.
- the driving characteristics, as well as steering and braking, may be greatly impaired.

There is a risk of an accident.



Follow recommended tire inflation pressures and check the pressure of all the tires including the spare wheel:

- monthly, at least
- if the load changes
- before beginning a long journey
- under different operating conditions, e.g. off-road driving

If necessary, correct the tire pressure.

The recommended tire pressures for the tires mounted at the factory can be found on the labels described here.

1.) **Tire and Loading Information placard** on the B-pillar on the driver's side of the vehicle (> page 339).

The Tire and Loading Information placard contains the recommended tire pressures for cold tires on a fully loaded vehicle and for the maximum permissible vehicle speed.

The specifications given on the following Tire and Loading Information placard are examples. Tire pressure specifications are vehicle-specific and may deviate from the data shown here. The tire pressures applicable to your vehicle can be found on the Tire and Loading Information placard on your vehicle.

	DENISEIGNIEMEN	OADING INFOR	rmation Et le chargement
	EATING CAPACITY TO NOMBRE DE PLACES	AL 7 FRONT 2 1	MIDDLE 3 REAR 2
		rgo should never exceed r ent ne doit jamais dépas	
tire Pneu	SIZE DIMENSIONS	COLD TIRE PRESSURE PRESSION DES PNEUS À FROID	SEE OWNER'S MANUAL FOR
FRONT AVANT	255/40 ZR18 99YXL	200 KPA, 29 PSI	ADDITIONAL INFORMATION
REAR ARRIÈRE	285/35 ZR18 101YXL	200 KPA, 29 PSI	VOIR LE MANUEL DE L'USAGER
SPARE DE SECOURS	175/55-18 95P	420 KPA, 60 PSI	POUR PLUS DE RENSIGNEMENTS

P40.00-2205-31


① Recommended tire pressures

Option 2) **Tire pressure table** on the inside of the fuel filler flap.

The tire pressure table contains the recommended pressures for cold tires for


various operating conditions, i.e. differing load and speed conditions.

Specifications shown in the examples of tire pressure tables are for illustration purposes only. Tire pressure specifications are vehicle-specific and may deviate from the data shown here. Tire pressure specifications applicable to your vehicle are located in your vehicle's tire pressure table.



Example: tire pressure table for all tires permitted for this vehicle by the factory


If a tire size precedes a tire pressure, the tire pressure information following is only valid for that tire size. The load conditions "partially laden" and "fully laden" are defined in the table for different numbers of occupants and amounts of luggage. The actual number of seats may differ.



Example: tire pressure table with tire dimensions Some tire pressure tables show only the rim diameters instead of the full tire size, e.g. **R18**. The rim diameter is part of the tire size



and can be found on the tire sidewall (⊳ page 346).



P40.00-2184-31

If the tire pressures have been set to the lower values for lighter loads and/or lower road speeds, the pressures should be reset to the higher values:

- if you want to drive with an increased load and/or
- if you want to drive at higher road speeds.
- 1 The tire pressures for increased loads and/or higher road speeds, shown in the tire pressure table, may have a negative effect on driving comfort.
- for vehicles towing a trailer, the full load value on the tire pressure label located on the inside of the fuel filler flap is valid for the rear axle.

Option 3) The tire pressure for the emergency/collapsible spare wheel (depending on vehicle equipment) can be found:

- printed in yellow on the rim of the emergency/collapsible spare wheel
- in the "Wheel and tire combinations" section (⊳ page 357) in this Operator's Manual
- on the Tire and Loading Information placard on the B-pillar on the driver's side

If the tire pressure is not set correctly, this can lead to an excessive build up of heat and a sudden loss of pressure.

For more information, contact a qualified specialist workshop.

## Important notes on tire pressure



#### **↑** WARNING

If the tire pressure drops repeatedly, the wheel, valve or tire may be damaged. Tire pressure that is too low may result in a tire blow-out. There is a risk of an accident.

- Check the tire for foreign objects.
- Check whether the wheel is losing air or the valve is leaking.

If you are unable to rectify the damage, contact a qualified specialist workshop.



#### **↑** WARNING

If you fit unsuitable accessories onto tire valves, the tire valves may be overloaded and malfunction, which can cause tire pressure loss. Due to their design, retrofitted tire pressure monitors keep the tire valve open. This can also result in tire pressure loss. There is a risk of an accident.

Only screw the standard valve cap or other valve caps approved by Mercedes-Benz for your vehicle onto the tire valve.

To test tire pressure, use a suitable tire pressure gauge. The outer appearance of a tire does not permit any reliable conclusion about the tire pressure. On vehicles equipped with the electronic tire pressure monitoring system, the tire pressure can be checked using the on-board computer.

The tire temperature and pressure increase when the vehicle is in motion. This is dependent on the driving speed and the load.

Therefore, you should only correct tire pressures when the tires are cold.

The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has not been driven further than 1 mile (1.6 km)

The tire temperature changes depending on the outside temperature, the vehicle speed and the tire load. If the tire temperature



changes by 18 °F (10 °C), the tire pressure changes by approximately 10 kPa (0.1 bar/ 1.5 psi). Take this into account when checking the pressure of warm tires and only correct the tire pressure if it is too low for the current operating conditions. If you check the tire pressure when the tires are warm, the resulting value will be higher than if the tires were cold. This is normal. Do not reduce the tire pressure to the value specified for cold tires. The tire pressure would otherwise be too low.

Observe the recommended tire pressures for cold tires:

- on the Tire and Loading Information placard on the B-pillar on the driver's side
- in the tire pressure table on the inside of the fuel filler flap
- printed in yellow on the rim of the emergency/collapsible spare wheel (depending on vehicle equipment)

## Underinflated or overinflated tires

#### Underinflation



#### ★ WARNING

Tires with pressure that is too low can overheat and burst as a consequence. In addition, they also suffer from excessive and / or irregular wear, which can severely impair the braking properties and the driving characteristics. There is a risk of an accident. Avoid tire pressures that are too low in all the tires, including the spare wheel.

## Underinflated tires may:

- · wear quickly and unevenly
- have an adverse effect on fuel consumption
- · overheat, leading to tire defects
- · have an adverse effect on handling characteristics

#### Overinflation



# **MARNING**

Tires with excessively high pressure can burst because they are damaged more easily by road debris, potholes etc. In addition, they also suffer from irregular wear, which can severely impair the braking properties and the driving characteristics. There is a risk of an accident


Avoid tire pressures that are too high in all the tires, including the spare wheel.

#### Overinflated tires may:

- · have an adverse effect on handling characteristics
- wear guickly and unevenly
- be more susceptible to damage
- · have an adverse effect on ride comfort
- · increase the braking distance

#### Maximum tire pressures

Never exceed the maximum permissible tire inflation pressure. Always observe the recommended tire pressure for your vehicle when adjusting the tire pressure (⊳ page 331).



- (1) Example: maximum permissible tire pressure
- 1 The actual values for tires are vehiclespecific and may deviate from the values in the illustration.



#### Checking the tire pressures

#### Important safety notes

Observe the "tire pressure information" section (⊳ page 331).

Information on air pressure for the tires on your vehicle can be found:

- on the vehicle's Tire and Loading Information placard on the B-pillar
- on the tire pressure label on the fuel filler flap
- in the "Tire pressure information" section

## Checking tire pressures manually

To determine and set the correct tire pressure, proceed as follows:

- ► Remove the valve cap of the tire that is to be checked.
- Press the tire pressure gauge securely onto the valve.
- Read the tire pressure and compare it with the recommended value on the Tire and Loading Information placard on the B-pillar on the driver's side of your vehicle.
- ▶ If necessary, increase the tire pressure to the recommended value (> page 331).
- ▶ If the tire pressure is too high, release air by pressing down the metal pin in the valve using the tip of a pen, for example. Then, check the tire pressure again using the tire pressure gauge.
- ▶ Screw the valve cap onto the valve.
- ► Repeat these steps for the other tires.

# Tire pressure loss warning system (Canada only)

#### General notes

While the vehicle is in motion, the tire pressure loss warning system monitors the set tire pressure using the rotational speed of the wheels. This enables the system to detect significant pressure loss in a tire. If the speed

of rotation of a wheel changes as a result of a loss of pressure, a corresponding warning message will appear in the multifunction display.

You can recognize the tire pressure loss warning by the Run Flat Indicator Active Press 'OK' to Restart message which appears in the Service menu of the multifunction display. Further information on the message display can be found under "Restarting the tire pressure loss warning system" section (▷ page 336).

#### Important safety notes

The tire pressure warning system does not warn you of an incorrectly set tire pressure. Observe the notes on the recommended tire pressure (▷ page 331).

The tire pressure loss warning system does not replace the need to regularly check your vehicle's tire pressures, since an even loss of pressure on several tires at the same time cannot be detected by the tire pressure loss warning system.

The tire pressure monitor is not able to warn you of a sudden loss of pressure, e.g. if the tire is penetrated by a foreign object. In the event of a sudden loss of pressure, bring the vehicle to a halt by braking carefully. Avoid abrupt steering maneuvers.

The function of the tire pressure loss warning system is limited or delayed if:

- snow chains are mounted on your vehicle's tires.
- road conditions are wintry.
- you are driving on sand or gravel.
- you adopt a very sporty driving style (cornering at high speeds or driving with high rates of acceleration).
- you are towing a very heavy or large trailer.
- you are driving with a heavy load (in the vehicle or on the roof).



# Restarting the tire pressure loss warning system

Restart the tire pressure loss warning system if you have:

- · changed the tire pressure
- · changed the wheels or tires
- · mounted new wheels or tires
- ▶ Before restarting, consult the Tire and Loading Information placard on the B-pillar on the driver's side or the tire pressure table on the inside of the fuel filler flap to ensure the tire pressure in all four tires is set correctly for the current operating conditions.

The tire pressure loss warning system can only give reliable warnings if you have set the correct tire pressure. If an incorrect tire pressure is set, these incorrect values will be monitored.

- ► Observe the notes in the section on tire pressures (> page 331).
- ▶ Make sure that the SmartKey is in position  $2(\triangleright page 141)$  in the ignition lock .
- ► Press the or button to select the Service menu.
- ► Press the ▲ or ▼ button to select Tire Pressure.
- ► Press the OK button.

  The Run Flat Indicator Active
  Press 'OK' to Restart message
  appears in the multifunction display.

## If you wish to confirm the restart:

- ► Press the OK button.

  The Tire Pressure Now OK? message appears in the multifunction display.
- ▶ Press the or button to select Yes.
- ► Press the OK button.

  The Run Flat Indicator Restarted message appears in the multifunction display.

After a teach-in period, the tire pressure loss warning system will monitor the set tire pressures of all four tires.

## If you wish to cancel the restart:

▶ Press the 🛨 button.

or

- ▶ If the Tire Pressure Now OK? message appears, use the or button to select Cancel.
- Press the OK button.
  The tire pressure values stored at the last restart will continue to be monitored.

## Tire pressure monitor (USA only)

#### General notes

If a tire pressure monitor is installed, the vehicle's wheels have sensors that monitor the tire pressures in all four tires. The tire pressure monitor warns you if the pressure drops in one or more of the tires. The tire pressure monitor only functions if the correct sensors are installed to all wheels.

Information on tire pressures is displayed in the multifunction display. After a few minutes of driving, the current tire pressure of each tire is shown in the multifunction display.



Example: current tire pressure display

## Important safety notes

It is the driver's responsibility to set the tire pressure to that recommended for cold tires which is suitable for the operating situation (> page 331). Note that the correct tire pressure for the current operating situation must first be taught-in to the tire pressure monitor. If there is a substantial loss of



pressure, the warning threshold for the warning message is aligned to the reference values taught-in. Restart the tire pressure monitor after adjusting the pressure of the cold tires (> page 338). The current pressures are saved as new reference values. As a result, a warning message will appear if the tire pressure drops significantly.

The tire pressure monitor does not warn you of an incorrectly set tire pressure. Observe the notes on the recommended tire pressure (> page 331).

The tire pressure monitor is not able to warn you of a sudden loss of pressure, e.g. if the tire is penetrated by a foreign object. In the event of a sudden loss of pressure, bring the vehicle to a halt by braking carefully. Avoid abrupt steering maneuvers.

The tire pressure monitor has a yellow warning lamp in the instrument cluster for indicating pressure loss or a malfunction. Whether the warning lamp flashes or lights up indicates whether a tire pressure is too low or the tire pressure monitor is malfunctioning:

- if the warning lamp is lit continuously, the tire pressure on one or more tires is significantly too low. The tire pressure monitor is not malfunctioning.
- if the warning lamp flashes for around a minute and then remains lit constantly, the tire pressure monitor is malfunctioning.

### **↑** WARNING

Each tire, including the spare (if provided), should be checked at least once a month when cold and inflated to the pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door B-pillar or the tire pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or the tire pressure label, you should determine the proper tire pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring

system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires are significantly underinflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate if the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the warning lamp will flash for approximately a minute and then remain continuously illuminated. This sequence will be repeated every time the vehicle is started as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

i If the tire pressure monitor is malfunctioning, it may take more than ten minutes for the tire pressure warning lamp to inform you of the malfunction by flashing



for approximately one minute and then remaining lit.

When the malfunction has been rectified, the tire pressure warning lamp goes out after a few minutes of driving.

- 1 The tire pressure values indicated by the on-board computer may differ from those measured at a gas station with a pressure gauge. The tire pressures shown by the on-board computer refer to those measured at sea level. At high altitudes, the tire pressure values indicated by a pressure gauge are higher than those shown by the on-board computer. In this case, do not reduce the tire pressures.
- 1 The operation of the tire pressure monitor can be affected by interference from radio transmitting equipment (e.g. radio headphones, two-way radios) that may be being operated in or near the vehicle.

# Checking the tire pressure electronically

- ► Make sure that the SmartKey is in position **2**(▷ page 141) in the ignition lock .
- ▶ Press the or button on the steering wheel to select the Service menu.
- ► Press the ▲ or ▼ button to select Tire Pressure.
- ► Press the OK button.

  The current tire pressure of each tire is shown in the multifunction display.

If the vehicle has been parked for over 20 minutes, the Tire pressures will be displayed after driving a few minutes message appears.

After a teach-in process, the tire pressure monitor automatically detects new wheels or new sensors. As long as a clear allocation of the tire pressure value to the individual wheels is not possible, the Tire Pressure Monitor Active display message is shown

instead of the tire pressure display. The tire pressures are already being monitored.

is mounted, the system may continue to show the tire pressure of the wheel that has been removed for a few minutes. If this occurs, note that the value displayed for the position where the spare tire is mounted is not the same as the spare wheel/emergency spare wheel's current tire pressure.

# Tire pressure monitor warning messages

If the tire pressure monitor detects a significant pressure loss on one or more tires, a warning message is shown in the multifunction display. A warning tone also sounds and the tire pressure warning lamp lights up in the instrument cluster.

Each tire that is affected by a significant loss of pressure is highlighted with a color. If the following message appears in the multifunction display: Correct Tire

- Pressure:

  ➤ Check the tire pressure on all four wheels and correct it if necessary.
- 1 If the wheel positions on the vehicle are rotated, the tire pressures may be displayed for the wrong positions for a short time. This is rectified after a few minutes of driving, and the tire pressures are displayed for the correct positions.

## Restarting the tire pressure monitor

When you restart the tire pressure monitor, all existing warning messages are deleted and the warning lamps go out. The monitor uses the currently set tire pressures as the reference values for monitoring.

The tire pressure monitor must be restarted when you set the tire pressure to a new value (as a result of changed drive or load characteristics, for example). The tire



pressure monitor then monitors the new tire pressure values.

Restart the tire pressure monitor after you have set the tire pressure to the value recommended for the desired driving situation (⊳ page 331). Only correct tire pressures on cold tires. Comply with the recommended tire pressures on the Tire and Loading Information placard the B-pillar on the driver's side. Additional tire pressure values for driving at high speeds or with heavy loads can be found in the tire pressure table on the inside of the fuel filler flap.

- ▶ Make sure that the tire pressure is correct on all four wheels
- ▶ Make sure that the SmartKey is in position 2 in the ignition lock.
- ▶ Press the ◀ or ▶ button on the steering wheel to select the Service menu.
- ▶ Press the ▲ or ▼ button to select Tire Pressure.
- ▶ Press the OK button. The multifunction display shows the current tire pressure for the individual tires or the Tire pressures will be displayed after driving a few minutes message.
- ▶ Press the ▼ button. The Use Current Pressures as New Reference Values message appears in the multifunction display.

## If you wish to confirm the restart:

▶ Press the OK button. The Tire Press. Monitor Restarted message appears in the multifunction display.

After driving for a few minutes, the system checks whether the current tire pressures are within the specified range. The new tire pressures are then accepted as reference values and monitored.

#### If you wish to cancel the restart:

▶ Press the 🛨 button.

The tire pressure values stored at the last restart will continue to be monitored.

## Loading the vehicle

#### Instruction labels for tires and loads



#### **↑** WARNING

Overloaded tires can overheat, causing a blowout. Overloaded tires can also impair the steering and driving characteristics and lead to brake failure. There is a risk of accident. Observe the load rating of the tires. The load rating must be at least half of the GAWR of your vehicle. Never overload the tires by exceeding the maximum load.

Two instruction labels on your vehicle show the maximum possible load.

- (1) The Tire and Loading Information placard is on the B-pillar on the driver's side. The Tire and Loading Information placard shows the maximum permissible number of occupants and the maximum permissible vehicle load. It also contains details of the tire sizes and corresponding pressures for tires mounted at the factory.
- (2) The vehicle identification plate is on the B-pillar on the driver's side. The vehicle identification plate informs you of the gross vehicle weight rating. It is made up of the vehicle weight, all vehicle occupants, the fuel and the cargo. You can also find information about the maximum gross axle weight rating on the front and rear axle.

The maximum gross axle weight rating is the maximum weight that can be carried by one axle (front or rear axle). Never exceed the maximum load or the maximum gross axle weight rating for the front or rear axle





① B-pillar, driver's side

## Maximum permissible load

the specifications shown on the Tire and Loading Information placard in the illustration are examples. The maximum permissible load is vehicle-specific and may deviate from the data shown here. The maximum permissible load that applies for your vehicle can be found on your vehicle's Tire and Loading Information placard.


	RENSEIGNEMENT	OADING INFO	RMATION ET LE CHARGEMENT
	SEATING CAPACITY TO NOMBRE DE PLACES TO	AL 7 FRONT 2	MIDDLE 3 REAR 2
	weight of occupants and o es occupants et du charge		
TIRE PNEU	SIZE DIMENSIONS	COLD TIRE PRESSURE PRESSION DES PNEUS À FROID	SEE OWNER'S MANUAL FOR
FRONT AVANT	255/40 ZR18 99YXL	200 KPA, 29 PSI	ADDITIONAL INFORMATION
REAR ARRIÈRE	285/35 ZR18 101YXL	200 KPA, 29 PSI	VOIR LE MANUEL DE L'USAGER
SPARE DE SECOURS	175/55-18 95P	420 KPA, 60 PSI	POUR PLUS DE RENSIGNEMENTS

▶ Specification for maximum permissible load ① is listed on the Tire and Loading Information placard: "The combined weight of occupants and cargo should never exceed XXX kilograms or XXX lbs."

The gross weight of all vehicle occupants, load, luggage and trailer load/noseweight (if applicable) must not exceed the specified value.

#### **Number of seats**

1 The specifications shown on the Tire and Loading Information placard in the illustration are examples. The number of seats is vehicle-specific and can differ from the details shown. The number of seats in your vehicle can be found on the Tire and Loading Information placard.



Maximum number of seats ① indicates the maximum number of occupants allowed to travel in the vehicle. This information can be found on the Tire and Loading Information

## **Determining the correct load limit**

## Step-by-step instructions

placard.

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

➤ Step 1: Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on



- your vehicle's Tire and Loading Information placard.
- ► Step 2: Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- ► Step 3: Subtract the combined weight of the driver and passengers from XXX kilograms or XXX lbs.
- ➤ Step 4: The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs (1 400 750 (5 x 150) = 650 lbs).
- ▶ Step 5: Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.
- ▶ Step 6 (if applicable): If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Refer to this Operator's Manual to determine how this reduces the available cargo and luggage load capacity of your vehicle (> page 343).



## Example: steps 1 to 3

The following table shows examples on how to calculate total and cargo load capacities with varying seating configurations and number and size of occupants. The following examples use a load limit of 1 500 lbs (680 kg). **This is for illustration purposes only.** Make sure you are using the actual load limit for your vehicle stated on your vehicle's Tire and Loading Information placard ( $\triangleright$  page 340).

		Example 1	Example 2	Example 3
Step 1	Combined maximum weight of occupants and cargo (data from the Tire and Loading Information placard)	1500 lbs (680 kg)	1500 lbs (680 kg)	1500 lbs (680 kg)

		Example 1	Example 2	Example 3
Step 2	Number of people in the vehicle (driver and occupants)	5	3	1
	Distribution of the occupants	Front: 2 Rear: 3	Front: 1 Rear: 2	Front: 1
	Weight of the occupants	Occupant 1: 150 lbs (68 kg) Occupant 2: 180 lbs (82 kg) Occupant 3: 160 lbs (73 kg) Occupant 4: 140 lbs (63 kg) Occupant 5: 120 lbs (54 kg)	Occupant 1: 200 lbs (91 kg) Occupant 2: 190 lbs (86 kg) Occupant 3: 150 lbs (68 kg)	Occupant 1: 150 lbs (68 kg)
	Gross weight of all occupants	750 lbs (340 kg)	540 lbs (245 kg)	150 lbs (68 kg)



		Example 1	Example 2	Example 3
Step 3	Permissible load and trailer load/noseweight (maximum permissible load rating from the Tire and Loading Information placard minus the gross weight of all occupants)	1500 lbs (680 kg) - 750 lbs (340 kg) = 750 lbs (340 kg)	1500 lbs (680 kg) - 540 lbs (245 kg) = 960 lbs (435 kg)	1500 lbs (680 kg) - 150 lbs (68 kg) = 1350 lbs (612 kg)

The higher the weight of all the occupants, the smaller the maximum load for luggage. Further information can be found under "Towing a trailer" (> page 343).

### Vehicle identification plate

Even if you have calculated the total load carefully, you should still make sure that the gross vehicle weight rating and the gross axle weight rating are not exceeded. Details can be found on the vehicle identification plate on the B-pillar on the driver's side of the vehicle (> page 339).

Permissible gross vehicle weight: the gross weight of the vehicle, all passengers, load and trailer load/noseweight (if applicable) must not exceed the permissible gross vehicle weight.

**Gross axle weight rating:** the maximum permissible weight that can be carried by one axle (front or rear axle).

To ensure that your vehicle does not exceed the maximum permissible values (gross vehicle weight and maximum gross axle weight rating), have your loaded vehicle (including driver, occupants, cargo, and full trailer load if applicable) weighed on a suitable vehicle weighbridge.


## Trailer load/noseweight

The trailer load/noseweight affects the gross weight of the vehicle. If a trailer is attached,

the trailer load/noseweight is included in the load along with occupants and luggage. The trailer load/noseweight is usually approximately 8% of the gross weight of the trailer and its load.

## Maximum load rating

Do not overload the tires by exceeding the specified load limit. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side (> page 339).




The actual values for tires are vehiclespecific and may deviate from the values in the illustration.



Maximum tire load (1) is the maximum permissible weight for which the tire is approved.

## **Uniform Tire Quality Grading Standards**

## **Overview of Tire Quality Grading Standards**



Uniform Tire Quality Grading Standards are U.S. government specifications. Their purpose is to provide drivers with uniform reliable information on tire performance data. tire manufacturers have to grade tires using three performance factors: tread wear (1), tire traction (2) and heat resistance (3). All tires sold in North America are provided with the corresponding quality class mark on the sidewall of the tire, even though these regulations do not apply to Canada.

1 The actual values for tires are vehiclespecific and may deviate from the values in the illustration.

Where applicable, the tire grading information can be found on the tire sidewall between the tread shoulder and maximum tire width.

For example:

Treadwear	Traction	Temperature
200	AA	A

All passenger car tires must conform to the statutory safety requirements in addition to these grades.

#### Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified U.S. government course. For example, a tire graded 150 would wear one and one-half times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use. however, and may depart significantly from the norm, due to variations in driving habits, service practices and differences in road characteristics and climate conditions.

#### **Traction**

### **↑** WARNING

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on a wet surface as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The safe speed on a wet, snow covered or icy road is always lower than on dry road surfaces.

You should pay special attention to road conditions when temperatures are around the freezing point.

Mercedes-Benz recommends a minimum tread depth of  $\frac{1}{16}$  in (4 mm) for all four winter tires (⊳ page 330) to maintain normal driving characteristics in winter. Winter tires can



reduce the braking distance on snow-covered surfaces in comparison with summer tires. Stopping distance, however, is still considerably greater than when the road is not covered with ice or snow. Take appropriate care when driving.

Avoid wheelspin. This can lead to damage to the drive train

#### **Temperature**

#### **↑** WARNING


The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.

The temperature grades are A (the highest), B, and C. These represent the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

## Tire labeling

## Overview of tire labeling


The following markings are on the tire in addition to the tire name (sales designation) and the manufacturer's name:



- 1 Uniform Tire Quality Grading Standard (⊳ page 349)
- 2) DOT, Tire Identification Number (⊳ page 348)
- (3) Maximum tire load (⊳ page 343)
- (4) Maximum tire pressure (▷ page 334)
- ⑤ Manufacturer
- (6) Tire material (▷ page 349)
- (7) Tire size designation, load-bearing capacity and speed index (⊳ page 346)
- (8) Load index (▷ page 348)
- Tire name
- 1 Tire data is vehicle-specific and may deviate from the data in the example.



## Tire size designation, load-bearing capacity and speed rating



- 1 Tire width
- ② Nominal aspect ratio in %
- ③ Tire code
- (4) Rim diameter
- (5) Load bearing index
- 6 Speed rating
- Tire data is vehicle-specific and may deviate from the data in the example.

General: depending on the manufacturer's standards, the size imprinted in the tire wall may not contain any letters or may contain one letter that precedes the size description.

If there is no letter preceding the size description (as shown above): these are passenger vehicle tires according to European manufacturing standards.

If "P" precedes the size description: these are passenger vehicle tires according to U.S. manufacturing standards.

If "LT" precedes the size description: these are light truck tires according to U.S. manufacturing standards.

If "T" precedes the size description: these are compact emergency spare wheels at high tire pressure, to be used only temporarily in an emergency.

**Tire width:** tire width (1) shows the nominal tire width in millimeters.

Height-width ratio: aspect ratio (2) is the size ratio between the tire height and tire width and is shown in percent. The aspect

ratio is calculated by dividing the tire width by the tire height.

Tire code: tire code (3) specifies the tire type. "R" represents radial tires; "D" represents diagonal tires; "B" represents diagonal radial tires.

Optionally, tires with a maximum speed of over 149 mph (240 km/h) may have "ZR" in the size description, depending on the manufacturer (e.g. 245/40 ZR 18).

Rim diameter: rim diameter (4) is the diameter of the bead seat, not the diameter of the rim flange. The rim diameter is specified in inches (in).

**Load-bearing index:** load-bearing index (5) is a numerical code that specifies the maximum load-bearing capacity of a tire.

Do not overload the tires by exceeding the specified load limit. The maximum permissible load can be found on the vehicle's Tire and Loading Information placard on the B-pillar on the driver's side (⊳ page 339).

#### Example:

Load-bearing index 91 indicates a maximum load of 1.356 lb (615 kg) that the tires can bear. For further information on the maximum tire load in kilograms and lbs, see (⊳ page 343).

For further information on the load bearing index, see "Load index" (> page 348).

**Speed rating:** speed rating (6) specifies the approved maximum speed of the tire.

### **↑** WARNING

Exceeding the stated tire load-bearing capacity and the approved maximum speed could lead to tire damage or the tire bursting. There is a risk of accident.

Therefore, only use tire types and sizes approved for your vehicle model. Observe the tire load rating and speed rating required for your vehicle.

Regardless of the speed rating, always observe the speed limits. Drive carefully and



adapt your driving style to the traffic conditions.

Summer tires		
Index	Speed rating	
Q	up to 100 mph (160 km/h)	
R	up to 106 mph (170 km/h)	
S	up to 112 mph (180 km/h)	
Т	up to 118 mph (190 km/h)	
Н	up to 130 mph (210 km/h)	
V	up to 149 mph (240 km/h)	
W	up to 168 mph (270 km/h)	
Υ	up to 186 mph (300 km/h)	
ZRY	up to 186 mph (300 km/h)	
ZR(Y)	over 186 mph (300 km/h)	
ZR	over 149 mph (240 km/h)	

- Optionally, tires with a maximum speed of over 149 mph (240 km/h) may have "ZR" in the size description, depending on the manufacturer (e.g. 245/40 ZR18).
   The service specification is made up of load-bearing index (5) and speed rating (6).
- If the size description of your tire includes "ZR" and there are no service specifications, ask the tire manufacturer in order to find out the maximum speed. If a service specification is available, the maximum speed is limited according to the speed rating in the service specification. Example: 245/40 ZR 18 97 Y. In this example, "97 Y" is the service specification. The letter "Y" represents the speed rating. The maximum speed of the tire is limited to 186 mph (300 km/h).
- The size description for all tires with maximum speeds of over 186 mph

(300 km/h) must include "ZR", **and** the service specification must be given in parentheses. Example:

275/40 ZR 18 (99 Y). Speed rating "(Y)" indicates that the maximum speed of the tire is over 186 mph (300 km/h). Ask the tire manufacturer about the maximum speed.

All-weather tires and winter tires		
Index	Speed rating	
Q M+S <sup>16</sup>	up to 100 mph (160 km/h)	
T M+S <sup>16</sup>	up to 118 mph (190 km/h)	
H M+S <sup>16</sup>	up to 130 mph (210 km/h)	
V M+S <sup>16</sup>	up to 149 mph (240 km/h)	

1 Not all tires with the M+S marking provide the driving characteristics of winter tires. In addition to the M+S marking, winter tires also have the sometimes also have the sometimes are sometimes and sometimes also have the sometimes are sometimes also have the sometimes are sometimes also have the marking fulfill the requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) regarding snow traction, and were specially developed for driving on snow.

An electronic speed limiter prevents your vehicle from exceeding a speed of 130mph (210km/h).

The speed rating of tires mounted at the factory may be higher than the maximum speed that the electronic speed limiter permits.

Make sure that your tires have the required speed rating for your vehicle as specified in the "tires" section (▷ page 357), e.g. if you buy new tires.

Further information about reading tire data can be obtained from any qualified specialist workshop.



## Load index




1 Tire data is vehicle-specific and may deviate from the data in the example.

In addition to the load-bearing index, load index ① may be imprinted after the letters that identify speed rating  $\textcircled{6}(\triangleright \text{ page 346})$  on the sidewall of the tire.

- If no specification is given: no text (as in the example above), represents a standard load (SL) tire
- XL or Extra Load: represents a reinforced tire
- Light Load: represents a light load tire
- C, D, E: represents a load range that depends on the maximum load that the tire can carry at a certain pressure

## **DOT, Tire Identification Number (TIN)**

U.S. tire regulations prescribe that every manufacturer of new tires or retreader has to imprint a TIN in or on the sidewall of each tire produced.



The TIN is a unique identification number. The TIN enables tire manufacturers to inform purchasers of recalls and other safety-relevant matters. It makes it possible for the purchaser to easily identify the affected tires.

The TIN is made up of manufacturer identification code ②, tire size ③, tire type code ④ and manufacturing date ⑤.

1 Tire data is vehicle-specific and may deviate from the data in the example.

**DOT (Department of Transportation):** tire symbol ① indicates that the tire complies with the requirements of the U.S. Department of Transportation.

#### Manufacturer identification code:

manufacturer identification code ② provides details on the tire manufacturer. New tires have a code with two symbols. Retreaded tires have a code with four symbols.

For further information about retreaded tires, see (▷ page 328).

Tire size: identifier (3) describes the tire size.

**Tire type code:** tire type code (4) can be used by the manufacturer as a code to describe specific characteristics of the tire.

Date of manufacture: date of manufacture (5) provides information about the age of a tire. The first and second positions represent the week of manufacture, starting with "01" for the first calendar week. Positions three and four represent the year of manufacture. For example, a tire that is marked with "3208", was manufactured in week 32 in 2008.



#### Tire characteristics



1 Tire data is vehicle-specific and may deviate from the data in the example.

This information describes the type of tire cord and the number of layers in sidewall (1) and under tire tread (2).

# Definition of terms for tires and loading

# Tire ply composition and material used

Describes the number of plies or the number of layers of rubber-coated fabric in the tire tread and sidewall. These are made of steel, nylon, polyester and other materials.

#### Bar

Metric unit for tire pressure. 14.5038 pounds per square inch (psi) and 100 kilopascals (kPa) are the equivalent of 1 bar.

## **DOT (Department of Transportation)**

DOT marked tires fulfill the requirements of the United States Department of Transportation.

## Normal occupant weight

The number of occupants for which the vehicle is designed multiplied by 68 kilograms (150 lbs).

# Uniform Tire Quality Grading Standards

A uniform standard to grade the quality of tires with regards to tread quality, tire traction and temperature characteristics. Ratings are determined by tire manufacturers using U.S. government testing procedures. The ratings are molded into the sidewall of the tire.

#### Recommended tire pressure

The recommended tire pressure applies to the tires mounted at the factory.

The Tire and Loading Information placard contains the recommended tire pressures for cold tires on a fully loaded vehicle and for the maximum permissible vehicle speed.

The tire pressure table contains the recommended pressures for cold tires for various operating conditions, i.e. differing load and speed conditions.

# Increased vehicle weight due to optional equipment

This is the combined weight of all standard and optional equipment available for the vehicle, regardless of whether it is actually installed on the vehicle or not.

#### Rim

This is the part of the wheel on which the tire is mounted.



## **GAWR (Gross Axle Weight Rating)**

The GAWR is the maximum gross axle weight rating. The actual load on an axle must never exceed the gross axle weight rating. The gross axle weight rating can be found on the vehicle identification plate on the B-pillar on the driver's side.

### Speed rating

The speed rating is part of the tire identification. It specifies the speed range for which the tire is approved.

#### **GTW (Gross Trailer Weight)**

The GTW is the weight of a trailer including the weight of the load, luggage, accessories etc. on the trailer.

## **GVW (Gross Vehicle Weight)**

The gross vehicle weight includes the weight of the vehicle including fuel, tools, the spare wheel, accessories installed, occupants, luggage and the drawbar noseweight, if applicable. The gross vehicle weight must not exceed the gross vehicle weight rating GVWR as specified on the vehicle identification plate on the B-pillar on the driver's side.

# **GVWR (Gross Vehicle Weight Rating)**

The GVWR is the maximum permissible gross weight of a fully loaded vehicle (the weight of the vehicle including all accessories, occupants, fuel, luggage and the drawbar noseweight, if applicable). The gross vehicle weight rating is specified on the vehicle identification plate on the B-pillar on the driver's side.

#### Maximum loaded vehicle weight

The maximum weight is the sum of the curb weight of the vehicle, the weight of the accessories, the total load limit and the weight of the optional equipment installed at the factory.

## Kilopascal (kPa)

Metric unit for tire pressure. 6.9 kPa corresponds to 1 psi. Another unit for tire pressure is bar. 100 kilopascals (kPa) are the equivalent of 1 bar.

#### Load index

In addition to the load-bearing index, the load index may also be imprinted on the sidewall of the tire. This specifies the load-bearing capacity more precisely.

## **Curb weight**

The weight of a vehicle with standard equipment including the maximum capacity of fuel, oil and coolant. It also includes the airconditioning system and optional equipment if these are installed in the vehicle, but does not include passengers or luggage.

## Maximum load rating

The maximum load rating in kilograms or pounds is the maximum weight for which a tire is approved.

## Maximum permissible tire pressure

Maximum permissible tire pressure for one tire.



#### Maximum load on one tire

Maximum load on one tire. This is calculated by dividing the maximum axle load of one axle by two.

#### PSI (pounds per square inch)

A standard unit of measure for tire pressure.

#### Aspect ratio

Relationship between tire height and tire width in percent.

#### Tire pressure

This is pressure inside the tire applying an outward force to each square inch of the tire's surface. The tire pressure is specified in pounds per square inch (psi), in kilopascal (kPa) or in bar. The tire pressure should only be corrected when the tires are cold.

## Tire pressure of cold tires

The tires are cold:

- if the vehicle has been parked without direct sunlight on the tires for at least three hours and
- if the vehicle has not been driven further than 1 mile (1.6 km)

#### **Tread**

The part of the tire that comes into contact with the road.

#### Bead

The tire bead ensures that the tire sits securely on the wheel. There are several steel wires in the bead to prevent the tire from coming loose from the wheel rim.

#### Sidewall

The part of the tire between the tread and the bead.

## Weight of optional extras

The combined weight of those optional extras that weigh more than the replaced standard parts and more than 2.3 kg (5 lbs). These optional extras, such as high-performance brakes, level control, a roof rack or a high-performance battery, are not included in the curb weight and the weight of the accessories.

### **TIN (Tire Identification Number)**

This is a unique identifier which can be used by a tire manufacturer to identify tires, for example for a product recall, and thus identify the purchasers. The TIN is made up of the manufacturer's identity code, tire size, tire type code and the manufacturing date.

## Load bearing index

The load bearing index (also load index) is a code that contains the maximum load bearing capacity of a tire.

#### **Traction**

Traction is the result of friction between the tires and the road surface.

## TWR (Tongue Weight Rating)

The TWR specifies the maximum permissible weight that the ball coupling of the trailer tow hitch can support.



#### Treadwear indicators

Narrow bars (tread wear bars) that are distributed over the tire tread. If the tire tread is level with the bars, the wear limit of  $\frac{1}{16}$  in (1.6 mm) has been reached.

#### Occupant distribution

The distribution of occupants in a vehicle at their designated seating positions.

#### **Total load limit**

Nominal load and luggage load plus 68 kg (150 lbs) multiplied by the number of seats in the vehicle.

## Changing a wheel

#### Flat tire

You can find information on what to do in the event of a flat tire in the "Flat tire" section (⊳ page 312).

Information on driving with MOExtended tires in the event of a flat tire can be found under "MOExtended tires (tires with run-flat characteristics" (⊳ page 313).

## Rotating the wheels



## **↑** WARNING

Interchanging the front and rear wheels may severely impair the driving characteristics if the wheels or tires have different dimensions. The wheel brakes or suspension components may also be damaged. There is a risk of accident.

Rotate front and rear wheels only if the wheels and tires are of the same dimensions.

On vehicles equipped with a tire pressure monitor, electronic components are located in the wheel.

Tire-mounting tools should not be used near the valve. This could damage the electronic components.

Only have tires changed at a qualified specialist workshop.

Always observe the instructions and safety notes in the "Mounting a wheel" section (⊳ page 353).

The wear patterns on the front and rear tires differ, depending on the operating conditions. Rotate the wheels before a clear wear pattern has formed on the tires. Front tires typically wear more on the shoulders and the rear tires. in the center.

If your vehicle's tire configuration allows, you can rotate the wheels according to the intervals in the tire manufacturer's warranty book in your vehicle documents. If no warranty book is available, the tires should be rotated every 3,000 to 6,000 miles (5,000 to 10,000 km), or earlier if tire wear requires. Do not change the direction of wheel rotation.

Clean the contact surfaces of the wheel and the brake disc thoroughly every time a wheel is rotated. Check the tire pressures.

Information on changing tires and mounting the spare wheel (⊳ page 352).

#### **Direction of rotation**

Tires with a specified direction of rotation have additional benefits, e.g. if there is a risk of hydroplaning. You will only gain these benefits if the correct direction of rotation is maintained.

An arrow on the sidewall of the tire indicates its correct direction of rotation.

## Storing wheels

Store wheels that are not being used in a cool, dry and preferably dark place. Protect the tires from oil, grease, gasoline and diesel.



## Cleaning the wheels

#### **↑** WARNING

The water jet from a circular jet nozzle (dirt blasters) can cause invisible exterior damage to the tires or chassis components.

Components damaged in this way may fail unexpectedly. There is a risk of an accident.

Do not use power washers with circular jet nozzles to clean the vehicle. Have damaged tires or chassis components replaced immediately.

## Mounting a wheel

## Preparing the vehicle

- ► Stop the vehicle on solid, non-slippery and level ground.
- ► Apply the parking brake.
- ▶ Bring the front wheels into the straightahead position.
- ► Secure the vehicle against rolling away (⊳ page 160).
- ▶ Switch off the engine.
- ▶ Vehicles without KEYLESS-GO: remove the SmartKey from the ignition lock.
- ▶ Vehicles with KEYLESS-GO: open the driver's door.
  - The on-board electronics have status **0**, which is the same as the SmartKey having been removed.
- ▶ Vehicles with KEYLESS-GO: remove the Start/Stop button from the ignition lock (⊳ page 141).
- ▶ If included in the vehicle equipment, remove the tire-change tool kit from the vehicle.
- ► Secure the vehicle to prevent it from rolling away.

## Securing the vehicle to prevent it from rolling away









If your vehicle is equipped with a wheel chock, it can be found in the tire-change tool kit (⊳ page 312).

The folding wheel chock is an additional safety measure to prevent the vehicle from rolling away, for example when changing a wheel.

- ► Fold both plates upwards (1).
- ► Fold out lower plate ②.
- ► Guide the lugs on the lower plate fully into the openings in base plate (3).



Securing the vehicle on level ground

▶ On level ground: place chocks or other suitable items under the front and rear of the wheel that is diagonally opposite the wheel you wish to change.





Securing the vehicle on slight downhill gradients

► On light downhill gradients: place chocks or other suitable items in front of the wheels of the front and rear axle

#### Raising the vehicle

#### **↑** WARNING

If you do not position the jack correctly at the appropriate jacking point of the vehicle, the jack could tip over with the vehicle raised. There is a risk of injury.

Only position the jack at the appropriate jacking point of the vehicle. The base of the jack must be positioned vertically, directly under the jacking point of the vehicle.

The following must be observed when raising the vehicle:

- to raise the vehicle, only use the vehiclespecific jack that has been tested and approved by Mercedes-Benz. If used incorrectly, the jack could tip over with the vehicle raised.
- the jack is designed only to raise and hold the vehicle for a short time while a wheel is being changed. It is not suited for performing maintenance work under the vehicle.
- · avoid changing the wheel on uphill and downhill slopes.
- before raising the vehicle, secure it from rolling away by applying the parking brake and inserting wheel chocks. Never


- disengage the parking brake while the vehicle is raised.
- the jack must be placed on a firm, flat and non-slip surface. On a loose surface, a large, load-bearing underlay must be used. On a slippery surface, a non-slip underlay must be used, e.g. rubber mats.
- do not use wooden blocks or similar objects as a jack underlay. Otherwise, the jack will not be able to achieve its loadbearing capacity due to the restricted height.
- make sure that the distance between the underside of the tires and the ground does not exceed 1.2 inches (3 cm).
- never place your hands and feet under the raised vehicle.
- never lie under the raised vehicle.
- never start the engine when the vehicle is raised.
- never open or close a door or the tailgate when the vehicle is raised.
- make sure that no persons are present in the vehicle when the vehicle is raised.
- I The jack is designed exclusively for jacking up the vehicle at the jacking points. Otherwise, your vehicle could be damaged.







► Using lug wrench ①, loosen the bolts on the wheel you wish to change by about one full turn. Do not unscrew the bolts completely.




The jacking points are located just behind the wheel housings of the front wheels and just in front of the wheel housings of the rear wheels (arrows).

► Take the ratchet wrench out of the vehicle tool kit and place it on the hexagon nut of the jack so that the letters **AUF** are visible.



▶ Position jack ③ at jacking point ②.



P40.00-2138-31

- ► Turn ratchet wrench ④ until jack ③ sits completely on jacking point ② and the base of the jack lies evenly on the ground.
- ➤ Turn ratchet wrench ④ until the tire is raised a maximum of 1.2 in (3 cm) from the ground.

## Removing a wheel

- Do not place wheel bolts in sand or on a dirty surface. The bolt and wheel hub threads could otherwise be damaged when you screw them in.
- ▶ Unscrew the wheel bolts.
- ▶ Remove the wheel.

## Mounting a new wheel



#### **↑** WARNING

Oiled or greased wheel bolts or damaged wheel bolts/hub threads can cause the wheel



bolts to come loose. As a result, you could lose a wheel while driving. There is a risk of accident

Never oil or grease wheel bolts. In the event of damage to the threads, contact a qualified specialist workshop immediately. Have the damaged wheel bolts or hub threads replaced/renewed. Do not continue driving.


## **↑** WARNING

If you tighten the wheel bolts or wheel nuts when the vehicle is raised, the jack could tip over. There is a risk of injury.

Only tighten the wheel bolts or wheel nuts when the vehicle is on the ground.

Always pay attention to the instructions and safety notes in the "Changing a wheel" section (⊳ page 352).

Only use wheel bolts that have been designed for the wheel and the vehicle. For safety reasons. Mercedes-Benz recommends that vou only use wheel bolts which have been approved for Mercedes-Benz vehicles and the respective wheel.



- 1) Wheel bolts for all wheels supplied by the factory
- (2) Wheel bolts for the collapsible spare wheel
- Always use wheel bolts (2) to mount the collapsible spare wheel. Using other wheel bolts to mount the collapsible spare wheel could damage the brake system.

Be sure to use the original-length wheel bolts when re-mounting the original wheel after it has been repaired.

I To prevent damage to the paintwork, hold the wheel securely against the wheel hub while screwing in the first wheel bolt.



- Clean the wheel and wheel hub contact. surfaces.
- ▶ Place the new wheel on the wheel hub and push it on.
- ▶ Tighten the wheel bolts until they are finger-tight.
- ▶ Inflate the collapsible spare wheel (⊳ page 360).

Only then lower the vehicle.

## Lowering the vehicle




## **↑** WARNING

The wheels could work loose if the wheel nuts and bolts are not tightened to the specified tightening torque. There is a risk of accident. Have the tightening torque immediately checked at a qualified specialist workshop after a wheel is changed.

Inflate the collapsible spare wheel using the tire inflation compressor before lowering the vehicle. The wheel rim could otherwise be damaged.





- Place the ratchet wrench onto the hexagon nut of the jack so that the letters AB are visible.
- ► Turn the ratchet wrench until the vehicle is once again standing firmly on the ground.
- ▶ Place the jack to one side.
- ➤ Tighten the wheel bolts evenly in a crosswise pattern in the sequence indicated (① to ⑤). The tightening torque must be 110 lb-ft (150 Nm).
- ➤ Turn the jack back to its initial position and store it together with the rest of the tirechange tool kit in the cargo compartment.
- ► Transport the faulty wheel in the cargo compartment.
- ► Check the tire pressure of the newly mounted wheel and adjust it if necessary.

  Observe the recommended tire pressure (> page 331).

For further information on stowing the collapsible spare wheel, see ( $\triangleright$  page 361).

1 Vehicles with tire pressure monitor: all wheels mounted must be equipped with functioning sensors.

#### Wheel and tire combinations

#### **General notes**

I For safety reasons, Mercedes-Benz recommends that you only use tires and wheels which have been approved by Mercedes-Benz specifically for your vehicle.

These tires have been specially adapted for use with the control systems, such as ABS or ESP®, and are marked as follows:

- MO = Mercedes-Benz Original
- MOE = Mercedes-Benz Original Extended (tires featuring run-flat characteristics)
- MO1 = Mercedes-Benz Original (only certain AMG tires)

Mercedes-Benz Original Extended tires may only be used on wheels that have been specifically approved by Mercedes-Benz.

Only use tires, wheels or accessories tested and approved by Mercedes-Benz. Certain characteristics, e.g. handling, vehicle noise emissions or fuel consumption, may otherwise be adversely affected. In addition, when driving with a load, tire dimension variations could cause the tires to come into contact with the bodywork and axle components. This could result in damage to the tires or the vehicle. Mercedes-Benz accepts no liability for damage resulting from the use of tires,

Information on tires, wheels and approved combinations can be obtained from any qualified specialist workshop.

wheels or accessories other than those

tested and approved.

- Retreaded tires are neither tested nor recommended by Mercedes-Benz, since previous damage cannot always be detected on retreaded tires. As a result, Mercedes-Benz cannot guarantee vehicle safety if retreaded tires are mounted. Do not mount used tires if you have no information about their previous usage.
- 1 The recommended pressures for various operating conditions can be found:
  - on the Tire and Loading Information placard with the recommended tire pressures on the B-pillar on the driver's side
  - in the tire pressure table on the inside of the fuel filler flap



Observe the notes on recommended tire pressures under various operating conditions (> page 331).

Check tire pressures regularly, and only when the tires are cold. Comply with the maintenance recommendations of the tire manufacturer in the vehicle document wallet.

- 1 Notes on the vehicle equipment always equip the vehicle with:
  - tires of the same size on a given axle (left/right)
  - the same type of tires at a given time (summer tires, winter tires, MOExtended tires)
- On the following pages, you can find information on approved wheel rims and tire sizes for equipping your vehicle with winter tires. Winter tires are not available at the factory as standard equipment or optional extras.

If you would like to equip your vehicle with approved winter tires, you may also, in certain circumstances, require rims of the appropriate size. The size of the approved winter tires may deviate from that of the standard tires. This is dependent on the model and the equipment installed at the factory.

The tires and wheel rims, as well as further information, can be obtained at a qualified specialist workshop.

- Overview of abbreviations used in the following tire tables:
  - · BA: both axles
  - FA: front axle
  - RA: rear axle

In the following table, the wheel/tire combinations are assigned to the vehicle models through variants, e.g. V1, V2 etc.:

- V1 GLK 250 BlueTEC, GLK 350<sup>17</sup>, GLK 350 4MATIC<sup>17</sup>
- 1 Not all wheel and tire combinations are available at the factory for all countries.



Tires			
	Summer tires	Alloy wheels	V1
FA	235/50 R 19 99 V <sup>18</sup>	7.5 J x 19 H2 Wheel offset: 1.85 in (47 mm)	•
RA	255/45 R 19 100 V <sup>18, 19</sup>	8.5 J x 19 H2 Wheel offset: 2.05 in (52 mm)	

	All-weather tires	Alloy wheels	V1
ВА	235/60 R17 102 H M+S <sup>18</sup>	7.5 J x 17 H2 Wheel offset: 1.87 in (47.5 mm)	•
ВА	235/50 R19 99 H M+S <sup>18</sup>	7.5 J x 19 H2 Wheel offset: 1.85 in (47 mm)	•
ВА	235/50 R19 99 H M+S MOExtended <sup>20</sup>	7.5 J x 19 H2 Wheel offset: 1.85 in (47 mm)	•
ВА	235/45 R20 100 H XL M+S <sup>18</sup>	8.0 J x 20 H2 Wheel offset: 1.77 in (45 mm)	•

	All-terrain tires	Alloy wheels	V1
ВА	235/60 R17 102 H M+S <sup>18</sup>	7.5 J x 17 H2 Wheel offset: 1.87 in (47.5 mm)	•

	Winter tires	Alloy wheels	V1
ВА	235/60 R17 102 H M+S 🔌 18	7.5 J x 17 H2	•
	_	Wheel offset: 1.87 in (47.5 mm)	

# **Emergency spare wheel**

# Important safety notes



#### **↑** WARNING

The wheel or tire size as well as the tire type of the spare wheel or emergency spare wheel and the wheel to be replaced may differ. Mounting an emergency spare wheel may

severely impair the driving characteristics. There is a risk of an accident.

To avoid hazardous situations:

- · adapt your driving style accordingly and drive carefully.
- never mount more than one spare wheel or emergency spare wheel that differs in size.

<sup>18</sup> USA: not for GLK 250 BlueTFC.

<sup>19</sup> Use of snow chains is not permitted. Observe the notes in the "Snow chains" section.

<sup>&</sup>lt;sup>20</sup> MOExtended tires (tires featuring run-flat characteristics) only in combination with an activated tire pressure loss warning system.

- only use a spare wheel or emergency spare wheel of a different size briefly.
- do not switch ESP® off.
- have a spare wheel or emergency spare wheel of a different size replaced at the nearest qualified specialist workshop.
   Observe that the wheel and tire dimensions as well as the tire type must be correct.

When using an emergency spare wheel or spare wheel of a different size, you must not exceed the maximum speed of 50 mph (80 km/h).

Snow chains must not be mounted on emergency spare wheels.

#### **General notes**

You should regularly check the pressure of the emergency spare wheel, particularly prior to long trips, and correct the pressure as necessary ( $\triangleright$  page 331). The applicable value is found on the wheel or under "Technical data" ( $\triangleright$  page 357).

1 When you are driving with the collapsible spare wheel mounted, the tire pressure loss warning system or the tire pressure monitor cannot function reliably. Only restart the tire pressure loss warning system/the tire pressure monitor when the damaged wheel has been replaced with a new wheel.

# Vehicles with tire pressure monitor:

after mounting an emergency spare wheel, the system may still display the tire pressure of the removed wheel for a few minutes. The value displayed for the mounted emergency spare wheel is not the same as the current tire pressure of the emergency spare wheel.

An emergency spare wheel may also be mounted against the direction of rotation. Observe the time restriction on use as well as the speed limitation specified on the emergency spare wheel.


Replace the tires after six years at the latest, regardless of wear. This also applies to the emergency spare wheel.

## Collapsible spare wheel

# Removing the collapsible emergency spare wheel

The collapsible spare wheel can be found in the stowage well under the cargo compartment floor.

► Lift the cargo compartment floor up (> page 277).




- ▶ Remove stowage compartment (1).
- ► Turn retaining screw ② counter-clockwise and remove it.
- ▶ Remove collapsible spare wheel ③.
- ► Take the wheel bolts for the collapsible spare wheel from the vehicle tool kit.

For further information on changing a wheel and mounting the spare wheel, see (> page 312).

# Inflating the collapsible spare wheel

II Inflate the collapsible spare wheel using the tire inflation compressor before lowering the vehicle. The wheel rim could otherwise be damaged.





- ▶ Pull connector ④ and the air hose out of the housing.
- ► Remove the cap from the valve on the collapsible spare wheel.
- ► Screw union nut ① on the air hose onto the valve.
- ► Make sure on/off switch ⑤ of the tire inflation compressor is set to **0**.
- ▶ Insert plug ④ into the socket of the cigarette lighter (▷ page 280) or into a 12 V power socket (▷ page 280) in your vehicle.
- ► Make sure that the SmartKey is in position 1(> page 141) in the ignition lock.
- ► Press on/off switch ⑤ on the tire inflation compressor to I.

The tire inflation compressor is switched on. The tire is inflated. The tire pressure is shown on pressure gauge ③.

■ Do not operate the tire inflation compressor for longer than eight minutes at a time without a break. It may otherwise overheat.

The tire inflation compressor can be operated again once it has cooled down.

► Inflate the tire to the specified tire pressure.

The specified tire pressure is printed on the yellow label of the emergency spare wheel.

▶ When the specified tire pressure has been reached, press on/off switch ⑤ on the electric air pump to 0.

The tire inflation compressor is switched off.

- ► Turn the SmartKey to position **0** in the ignition lock.
- ▶ If the tire pressure is higher than the specified pressure, press pressure release button ② until the correct tire pressure has been reached.
- ► Unscrew union nut ① on the air hose from the valve.
- ► Screw the cap onto the valve of the collapsible spare wheel again.
- ▶ Stow plug ④ and the air hose in the lower section of the blower housing.
- ► Stow the tire inflation compressor in the vehicle.

#### Stowing a used collapsible spare wheel

Take the following steps to stow a used collapsible spare wheel. Otherwise, the collapsible spare wheel will not fit in the spare wheel well. Mercedes-Benz recommends that you have this work carried out at a qualified specialist workshop.

- Only place the collapsible spare wheel in the vehicle when it is dry. Otherwise, moisture may get into the vehicle.
- ► Remove the valve extractor from the vehicle tool kit
- ▶ Unscrew the valve cap from the valve.
- ► Unscrew the valve insert from the valve and release the air.
- Fully deflating the tires can take a few minutes.
- ▶ Screw the valve insert back into the valve.
- Screw the valve cap back on.
- ► Place the valve extractor back into the vehicle tool kit.
- Stow the collapsible spare wheel in the emergency spare wheel well under the cargo compartment and fasten in place.



Technical data		
Collapsible spare wheel		
Tires	Wheels	V1
185/75 - 17 98 P Tire pressure: 280 kPa (2.8 bar/41 psi)	6.0 B x 17 H2 ET 25	•

1 The specified tire pressure is printed in yellow on the emergency spare wheel.



Useful information	364
Information regarding technical	
data	364
Warranty	364
Identification plates	364
Service products and filling capaci-	
ties	36
Vehicle data	373
Trailer tow hitch	374

# **Useful information**

- i) This Operator's Manual describes all models and all standard and optional equipment of your vehicle available at the time of publication of the Operator's Manual. Country-specific differences are possible. Please note that your vehicle may not be equipped with all features described. This also applies to safety-related systems and functions.
- Read the information on qualified specialist workshops: (▷ page 27).

# Information regarding technical data

1 The data stated here specifically refers to a vehicle with standard equipment. Consult a Mercedes-Benz Center for the data for all vehicle variants and trim levels.

# Warranty

Your vehicle is covered under the terms of the warranties printed in the Service and Warranty Information booklet.

Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:

- New Vehicle Limited Warranty
- Emission Systems Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island and Vermont Emission Control System Warranty
- State warranty enforcement laws (Lemon Laws)

Replacement parts and accessories are covered by the Mercedes-Benz Parts and

Accessories warranties. These are available at any authorized Mercedes-Benz Center.

If you lose the Service and Warranty
Information booklet, contact an authorized
Mercedes-Benz Center to arrange a
replacement. It will be mailed to you.


### **Identification plates**

Vehicle identification plate with vehicle identification number (VIN)



▶ Open the driver's door. You will see vehicle identification plate ①.






Example: vehicle identification plate (USA only)



Example: vehicle identification plate (Canada only)

- ② Paint code
- 3 VIN
- 1 The data shown on the identification plate is example data. This data is different for every vehicle and can deviate from the data shown here. You can find the data applicable to your vehicle on the vehicle identification plate.

#### VIN




- ► Slide the right-hand front seat to its rearmost position.
- ► Fold floor covering ① upwards. You will see VIN ②.

The VIN can also be found in the following locations:

- on the lower edge of the windshield
   (▷ page 365)
- on the vehicle identification plate (> page 364)

## **Engine number**



- Emission control information plate, including the certification of both federal and Californian emissions standards
- ② Engine number (stamped into the crankcase)
- 3 VIN (on the lower edge of the windshield)

# Service products and filling capacities

#### Important safety notes

# **⚠ WARNING**

Service products may be poisonous and hazardous to health. There is a risk of injury. Comply with instructions on the use, storage and disposal of service products on the labels of the respective original containers. Always store service products sealed in their original containers. Always keep service products out of the reach of children.



#### **Environmental note**

Dispose of service products in an environmentally responsible manner.

Service products include the following:

- Fuels (e.g. gasoline, diesel)
- Exhaust gas aftertreatment additives, e.g. DFF
- Lubricants (e.g. engine oil, transmission oil)
- Coolant
- Brake fluid
- Windshield washer fluid
- Climate control system refrigerant

Comply with all valid regulations with respect to handling, storing, and disposing of service fluids.

Components and service products must be matched. You should therefore only use products that have been tested and approved by Mercedes-Benz.

Information about tested and approved products can be obtained from an authorized Mercedes-Benz Center or on the Internet at http://bevo.mercedes-benz.com.

You can recognize service products approved by Mercedes-Benz by the following inscription on the containers:

- MB-Freigabe (e.g. MB-Freigabe 229.51)
- MB Approval (e.g. MB Approval 229.51)

Other designations or recommendations indicate a level of quality or a specification in accordance with an MB Sheet number (e.g. MB 229.5). They have not necessarily been approved by Mercedes-Benz.

# **Fuel**

#### Important safety notes



# **↑** WARNING

Fuel is highly flammable. If you handle fuel incorrectly, there is a risk of fire and explosion.

You must avoid fire, open flames, creating sparks and smoking. Switch off the engine and, if applicable, the auxiliary heating before refueling.



#### 

Fuel is poisonous and hazardous to health. There is a risk of injury.

You must make sure that fuel does not come into contact with your skin, eyes or clothing and that it is not swallowed. Do not inhale fuel vapors. Keep fuel away from children.

If you or others come into contact with fuel, observe the following:

- Wash away fuel from skin immediately using soap and water.
- If fuel comes into contact with your eyes, immediately rinse them thoroughly with clean water. Seek medical assistance without delay.
- If fuel is swallowed, seek medical assistance without delay. Do not induce vomiting.
- Immediately change out of clothing which has come into contact with fuel.

#### Tank capacity

Model	Total capacity
GLK 250 BlueTEC	15.6 US gal (59.0 l)
All other models	17.4 US gal (66.0 l)

Model	Of which reserve
All models	approx. 2.1 US gal (8.0 l)



#### Gasoline

#### Fuel grade

- Do not use diesel to refuel vehicles with a gasoline engine. Do not switch on the ignition if you accidentally refuel with the wrong fuel. Otherwise, the fuel will enter the fuel system. Even small amounts of the wrong fuel could result in damage to the fuel system and the engine. The repair costs are high. Notify a qualified specialist workshop and have the fuel tank and fuel lines drained completely.
- premium-grade gasoline as this avoids damaging the catalytic converter.

  If engine running problems are apparent, have the cause checked immediately and repaired. Excess unburned fuel can otherwise enter the catalytic converter, leading to overheating and possibly causing a fire.

You should only refuel with unleaded

- I To ensure the longevity and full performance of the engine, only premium-grade unleaded gasoline may be used. If there is no premium-grade unleaded gasoline available and regular unleaded gasoline must be used, please observe the following precautions:
  - only fill the fuel tank to half full with regular unleaded gasoline and fill the rest with premium-grade unleaded gasoline as soon as possible.
  - do not drive at the maximum speed.
  - avoid sudden acceleration.
  - if the vehicle is carrying a light load, e.g. two passengers without luggage, do not allow the engine to rev above 3000 rpm.
  - if the vehicle is fully loaded or is being operated in mountainous terrain, do not depress the accelerator pedal further than <sup>2</sup>/<sub>3</sub> of the pedal travel.

Only refuel using premium-grade unleaded gasoline with a minimum octane rating of 91.

Reformulated Gasoline (RFG) and/or unleaded gasoline with additives can be used. The concentration of additives in the fuel, however, must not exceed 10%, e.g.:

- Ethanol
- TAME
- ETBE
- IPA
- TBA

For MTBE, the concentration should not exceed 15%.

The concentration of methanol in gasoline, including other additives, must not exceed 3%.

Using mixtures of methanol and ethanol is not permitted. Gasohol, a mixture of 10% ethanol and 90% unleaded gasoline may be used.

All of these blends must fulfill the fuel

- requirements, e.g.:

   knock resistance
- boiling point
- vapor pressure

You will usually find information about the fuel grade on the pump. If you cannot find the label on the pump, ask the staff for assistance.

1 For more information, contact a qualified specialist workshop.

Information on refueling (⊳ page 154).

#### **Additives**

Operating the engine with fuel additives can increase wear and tear to the fuel system high-pressure pump and lead to contamination of the entire fuel system. The repair costs are high. This does not include additives for the removal and prevention of residue buildup. gasoline must only be mixed with additives recommended by Mercedes-Benz. More information about recommended additives can be obtained from any authorized Mercedes-Benz Center.



One of the main problems of poor fuel quality is the forming of deposits that are created during the gasoline combustion process. Mercedes-Benz recommends that you use branded fuels that have additives.

If you use fuels without these additives over a longer period of time, carbon deposits may build up. These deposits form at the inlet valves and in the combustion chamber in particular.

This could lead to engine problems, e.g.:

- · longer engine warm-up phase
- uneven idle
- engine noise
- misfiring
- loss of power

Carbon deposits may form if the availability of gasoline with relevant additives is insufficient (in certain regions). In this case, Mercedes-Benz recommends additives approved for use in Mercedes-Benz vehicles; see http://bevo.mercedes-benz.com.

For a list of approved products, consult an authorized Mercedes-Benz Center. Comply with the instructions for use on the product

Do not mix other fuel additives with fuel. This causes unnecessary costs and could damage the engine.

#### Diesel

#### Fuel grade



### **↑** WARNING

If you mix diesel fuel with gasoline, the flash point is lower than that of pure diesel fuel. When the engine is running, exhaust system components could overheat without being noticed. There is a risk of fire.

Never refuel with gasoline. Never mix gasoline with diesel fuel.

I Only use commercially available vehicular ULTRA-LOW SULFUR DIESEL FUEL (ULSD, 15 ppm maximum sulfur content) that

- meets the ASTM D975 standard. If you do not refuel with ULSD, you may damage the BlueTEC exhaust gas aftertreatment system of the vehicle.
- Do not use gasoline to refuel vehicles with a diesel engine. Do not mix diesel fuel with gasoline, kerosene or paraffin. This may otherwise result in damage to the fuel system and engine.

You will usually find information about the fuel grade on the pump. If you cannot find the label on the pump, ask the staff for assistance.

1 For further information, consult a qualified specialist workshop or on the Internet at http://www.mbusa.com (USA only).

Information on refueling (▷ page 154).

#### Bio-diesel - FAME (fatty acid methyl ester)

Mercedes-Benz USA approves the use of biodiesel B5 for all BlueTEC diesel engines. The concentration of bio-diesel in the ULSD may not exceed 5% by volume.

Pure bio-diesel and diesel fuel with a higher percentage of bio-diesel, such as B20, can damage the engine and the fuel system. For this reason, they are not approved.

For more information, consult the gas station staff. The bio-diesel B5 label on the gasoline pump must clearly state that the standard for ULSD has been fulfilled. If the label is not clear, do not refuel the vehicle.

Do not refuel your vehicle with fuels unless they have been approved by Mercedes-Benz. Information on refueling (⊳ page 155).

#### Low outside temperatures

 Diesel fuel with improved cold flow properties is available during the winter months. Further information about fuel properties can be obtained from oil companies, e.g. at gas stations.



#### **DEF**

#### Important safety notes

Comply with the important safety notes for service products when handling DEF (> page 365).

DEF is a water-soluble fluid for the exhaust gas aftertreatment of diesel engines. It is:

- · not poisonous
- · colorless and odorless
- not flammable

When you open the DEF container, small amounts of ammonia vapor may be released.

Ammonia vapors have a pungent odor and are particularly irritating to the skin, to mucous membranes and to the eyes. You may experience a burning sensation in your eyes, nose and throat. Coughing and watering of the eyes are possible.

Do not inhale ammonia vapors. Fill the DEF tank only in well-ventilated areas.

#### Low outside temperatures

DEF freezes at a temperature of approximately 12 °F (-11 °C). The vehicle is delivered from the factory equipped with a DEF preheating system. Winter operation can thus be guaranteed even at temperatures below 12 °F (-11 °C).

#### **Additives**

Only use DEF in accordance with ISO 22241. Do not use additives with DEF and do not dilute DEF with water. This may destroy the BlueTEC exhaust gas aftertreatment system.

# **Purity**

- I Impurities in DEF (e.g. due to other service products, cleaning agents or dust) lead to:
  - · increased emission values
  - damage to the catalytic converter

- · engine damage
- malfunctions in the BlueTEC exhaust gas aftertreatment system

Assuring the purity of DEF is particularly important with respect to avoiding malfunctions in the BlueTEC exhaust gas aftertreatment system.

If DEF is pumped out of the DEF tank, e.g. during repair work, it must not be returned to the tank. The purity of the fluid can no longer be guaranteed.

#### Filling capacities

Model	Total capacity
GLK 250 BlueTEC	7.3 US gal (27.5 l)

#### **Engine oil**

#### **General notes**

Never use engine oil or an oil filter of a specification other than is necessary to fulfill the prescribed service intervals. Do not change the engine oil or oil filter in order to achieve longer replacement intervals than those prescribed. You could otherwise cause engine damage or damage to the exhaust gas aftertreatment.

Follow the instructions in the service interval display regarding the oil change. Otherwise, you may damage the engine and the exhaust gas aftertreatment.

When handling engine oil, observe the important safety notes on service products (> page 365).

The engine oils are matched to the performance of Mercedes-Benz engines and service intervals. You should therefore only use engine oils and oil filters that are approved for vehicles with maintenance systems.

For a list of approved engine oils and oil filters, consult an authorized Mercedes-Benz



Center. Or visit the website http://bevo.mercedes-benz.com.

The table shows which engine oils have been approved for your vehicle.

Model	Engine model	MB Approval
GLK 350 BlueEFFICIENCY GLK 350 4MATIC BlueEFFICIENCY	276	229.5
GLK 250 BlueTEC	651	228.51, 229.31, 229.51

MB approval is indicated on the oil containers.

#### Filling capacities


The following values refer to an oil change including the oil filter.

Model	Capacity
All models	6.9 US qt (6.5 l)

#### **Additives**

■ Do not use any additives in the engine oil. This could damage the engine.

# **Engine oil viscosity**



Viscosity describes the flow characteristics of a fluid. If an engine oil has a high viscosity,

this means that it is thick; a low viscosity means that it is thin.

Select an engine oil with an SAE classification (viscosity) suitable for the prevailing outside temperatures. The table shows you which SAE classifications are to be used. The low-temperature characteristics of engine oils can deteriorate significantly, e.g. as a result of aging, soot and fuel deposits. It is therefore strongly recommended that you carry out regular oil changes using an approved engine oil with the appropriate SAE classification.

#### **Brake fluid**

# **↑** WARNING

The brake fluid constantly absorbs moisture from the air. This lowers the boiling point of the brake fluid. If the boiling point of the brake fluid is too low, vapor pockets may form in the brake system when the brakes are applied hard. This would impair braking efficiency. There is a risk of an accident.

You should have the brake fluid renewed at the specified intervals.

When handling brake fluid, observe the important safety notes on service products (> page 365).

The brake fluid change intervals can be found in the Maintenance Booklet.

Only use brake fluid approved by Mercedes-Benz according to MB Approval 331.0.

Information about approved brake fluid can be obtained at any qualified specialist workshop or on the Internet at http://bevo.mercedes-benz.com.

• Have the brake fluid regularly replaced at a qualified specialist workshop and the replacement confirmed in the Maintenance Booklet.



#### Coolant

#### Important safety notes



#### **↑** WARNING

If antifreeze comes into contact with hot components in the engine compartment, it may ignite. There is a risk of fire and injury. Let the engine cool down before you add antifreeze. Make sure that antifreeze is not spilled next to the filler neck. Thoroughly clean the antifreeze from components before starting the engine.

I Only add coolant that has been premixed with the desired antifreeze protection. You could otherwise damage the engine.

Further information on coolants can be found in the Mercedes-Benz Specifications for Service Products, MB Specifications for Service Products 310.1, e.g. on the Internet at

http://bevo.mercedes-benz.com. Or contact a qualified specialist workshop.

Always use a suitable coolant mixture, even in countries where high temperatures prevail.

Otherwise, the engine cooling system is not sufficiently protected from corrosion and overheating.

When handling coolant, observe the important safety notes on service products (⊳ page 365).

The coolant is a mixture of water and antifreeze/corrosion inhibitor. It performs the following tasks:

- corrosion protection
- antifreeze protection
- · raising the boiling point

If the coolant has antifreeze protection down to -35 °F (-37 °C), the boiling point of the coolant during operation is approximately 266 °F (130 °C).

The antifreeze/corrosion inhibitor concentration in the engine cooling system should:

- be at least 50%. This will protect the engine cooling system against freezing down to approximately -35 °F (-37 °C).
- not exceed 55% (antifreeze protection down to -49 °F [-45 °C]). Otherwise, heat will not be dissipated as effectively.

If the vehicle has lost coolant, add equal amounts of water and antifreeze/corrosion inhibitor

Mercedes-Benz recommends an antifreeze/ corrosion inhibitor concentrate in accordance with MB Specifications for Service Products 310.1.

The coolant is checked with every maintenance interval at a qualified specialist workshop.

1 When the vehicle is first delivered, it is filled with a coolant mixture that ensures adequate antifreeze and corrosion protection.

# Filling capacities

Model	Capacity
GLK 250 BlueTEC	approx. 10.6 US qt (10.0 l)
GLK 350 BlueEFFICIENCY GLK 350 4MATIC BlueEFFICIENCY	approx. 8.9 US qt (8.4 I)

1 Use MB 325.0 or MB 326.0 corrosion inhibitor/antifreeze.



# Windshield washer system and headlamp cleaning system

# Important safety notes

#### **↑** WARNING

Windshield washer concentrate is highly flammable. If it comes into contact with hot engine components or the exhaust system it could ignite. There is a risk of fire and injury. Make sure that no windshield washer concentrate is spilled next to the filler neck.

- I Only use washer fluid that is suitable for plastic lamp lenses, e.g. MB SummerFit or MB WinterFit. Unsuitable washer fluid could damage the plastic lenses of the headlamps.
- Do not add distilled or de-ionized water to the washer fluid container. Otherwise, the level sensor may be damaged.
- II Only MB SummerFit and MB WinterFit washer fluid should be mixed together. The spray nozzles may otherwise become blocked.

When handling washer fluid, observe the important safety notes on service products (⊳ page 365).

At temperatures above freezing:

- ▶ Fill the washer fluid reservoir with a mixture of water and windshield washer fluid, e.g. MB SummerFit.
- ► Add 1 part MB SummerFit to 100 parts water.

At temperatures below freezing:

▶ Fill the washer fluid reservoir with a mixture of water and washer fluid, e.g. MB WinterFit.

Adapt the mixing ratio to the outside temperature.

- Down to 14 °F (-10 °C): mix 1 part MB WinterFit with 2 parts water.
- Down to -4 °F (-20 °C): mix 1 part MB WinterFit with 1 part water.
- Down to -20.2 °F (-29 °C): mix 2 parts MB WinterFit with 1 part water.
- 1 Add windshield washer fluid, e.g. MB SummerFit or MB WinterFit, to the washer fluid all vear round.

# Climate control system refrigerant

#### Important safety notes

#### Type of refrigerant

Your vehicle's climate control system can be filled with refrigerants R-134a or R-1234vf.

The instruction label about types of refrigerants can be found on the radiator cross member.

# Refrigerant R-134a

I Only use refrigerant R-134a and PAG oil (part number A0019890803) which has been approved by Mercedes-Benz. The approved R-134a PAG oil may not be mixed with other conventional PAG oils. Otherwise, the climate control system may be damaged.

Service work, such as topping-up refrigerant or replacing components, may only be carried out at a qualified specialist workshop. All applicable regulations must be adhered to, SAE standard J639 included.

Always have work on the climate control system carried out at a qualified specialist workshop.

# Refrigerant R-1234yf

I Only use refrigerant R-1234yf and PAG oil (part number A0009890606) which has been approved by Mercedes-Benz. The



approved R-1234yf PAG oil may not be mixed with other conventional PAG oils. Otherwise, the climate control system may be damaged.

Service work, such as topping-up refrigerant or replacing components, may only be carried out at a qualified specialist workshop. All applicable regulations, such as SAE standards J639, J2842 and J2845 must be adhered to.

Always have work on the climate control system carried out at a qualified specialist workshop.

#### Refrigerant instruction label





Example: refrigerant instruction label

- Warning symbol
- ② Refrigerant filling capacity
- ③ Applicable SAE standards
- PAG oil part number
- 5 Type of refrigerant

Warning symbols (1) indicate:

- possible dangers
- the flammability of refrigerant (R-1234yf)
- that it is necessary to have maintenance work carried out at a qualified specialist workshop

# Filling capacities

All models	Capacity
Refrigerant	$660 \pm 10 \text{ g}$ (23.3 ± 0.4 oz)
PAG oil	110 g (3.9 oz)

# Vehicle data

#### General notes

Please note that for the specified vehicle data:

- the heights specified may vary as a result of:
- tires
- load
- condition of the suspension
- optional equipment
- the indicated ground clearance refers to the vehicle when loaded and ready to drive, including:
  - driver (68 kg)
  - all fluids (fuel tank 100% full)



# **Dimensions and weights**



P72.20-3149-31

Model	① Opening height	② Max. headroom
GLK 250 BlueTEC 4MATIC	82.2 in (2087 mm)	77.0 in (1955 mm)
All other models	82.1 in (2086 mm)	76.9 in (1954 mm)

Missing values were not available at time of going to print.

All models	
Vehicle length	178.6 in (4536 mm)
Vehicle width including exterior mirrors	79.4 in (2016 mm)
Wheelbase	108.5 in (2755 mm)
Turning radius	38.2 ft (11.65 m)
Maximum roof load	


GLK 250 BlueTEC	
Vehicle height	66.7 in (1694 mm)
Ground clearance	8.0 in (204 mm)

GLK 350 BlueEFFICIENCY GLK 350 4MATIC BlueEFFICIENCY	
Vehicle height	66.7 in (1693 mm)
Ground clearance	8.2 in (208 mm)

# Trailer tow hitch

# **Mounting dimensions**

If you have a trailer tow hitch retrofitted, changes to the engine cooling system and drive train may be necessary, depending on the vehicle type.



Anchorage points for the trailer tow hitch (example)

- Anchorage points
- (2) Rear axle center line

#### **Trailer loads**

Missing values were not available at time of going to print.



	All models
Permissible trailer load, unbraked	
Permissible trailer load, braked <sup>21</sup>	
Maximum drawbar noseweight <sup>22</sup>	
Permissible rear axle load when towing a trailer	

<sup>22</sup> The drawbar noseweight is not included in the trailer load.



 $<sup>^{21}\,\</sup>mathrm{At}$  a minimum gradient-climbing capability of 12% from a standstill.



#### **Publication details**

#### Internet

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following websites:

http://www.mbusa.com (USA only) http://www.mercedes-benz.ca (Canada only)

# **Editorial office**

You are welcome to forward any queries or suggestions you may have regarding this Operator's Manual to the technical documentation team at the following address:

Daimler AG, HPC: CAC, Customer Service, 70546 Stuttgart, Germany

<sup>©</sup>Daimler AG: Not to be reprinted, translated or otherwise reproduced, in whole or in part, without written permission from Daimler AG.



Order no. 6515 0790 13 Part no. 204 584 23 83 Edition B 2013

